Self Diagnosis Supported model

# SERVICE MANUAL LA-1A CHASSIS

| MODEL | COMMANDER | DEST. | CHASSIS NO. |
|---|---|---|---|
| KF-50XBR800 | RM-Y912 | US | |
| KF-50XBR800 | RM-Y912 | Canadian | |
| KF-60XBR800 | RM-Y912 | US | |
| KF-60XBR800 | RM-Y912 | Canadian | |

| MODEL | COMMANDER | DEST. | CHASSIS NO. |
|---|---|---|---|



KF-50XBR800/KF-60XBR800



RM-Y912

LCD PROJECTION TV

SONY®

## SPECIFICATIONS

| | | |
|---|---|---|
| Projection System | 3 LCD Panels, 1 lens projection system | |
| LCD Panel | 1.35 inch TFT LCD panel Approx. 3.15 million dots (1,049,088 pixels) | |
| Projection Lens | High Performance, large diameter hybrid lens F2.4 | |
| Antenna | 75 ohm external terminal for VHF/UHF | |
| Lamp | UHP lamp, 100W<br>XL-2000U | |
| Television System | NTSC, American TV Standard | |
| Screen Size (measured diagonally) | KF-50XBR800: 50 inches, KF-60XBR800: 60 inches | |
| Channel Coverage | | |
| VHF | 2-13 | |
| UHF | 14-69 | |
| CATV | 1-125 | |
| Power Requirements | 120V, 60 Hz | |
| Number of Inputs/Outputs | | |
| DVI-HDTV 1 terminal | 3.3 V T.M.D.S., 50 ohms | |
| | The DVI-HDTV input terminal is compliant with the EIA-861 standard and is not intended for use with personal computers. | |
| Video (IN) | 4 | 1 Vp-p, 75 ohms unbalanced, sync negative |
| S Video (IN) | 3 | Y: 1 Vp-p, 75 ohms unbalanced, sync negative<br>C: 0.286 Vp-p (Burst signal), 75 ohms |
| Audio (IN) | 6 | 500 mVrms (100% modulation)<br>Impedance: 47 kiloohms |
| AUDIO (VAR/FIX) | 1 | 500 mVrms at the maximum volume setting (Variable)<br>500 mVrms (Fixed)<br>Impedance (output): 2 kiloohms |
| MONITOR OUT | 1 | Video: 1 Vp-p 75 ohms unbalanced, Sync negative<br>Audio: 500 mVrms (100% modulation)<br>Impedance (output): 1 kiloohms |
| CONTROL S (IN/OUT) | 1 | minijacks |
| Component Video Input | 2 (Y, $P_B$ , $P_R$) | Y: 1.0 Vp-p, 75 ohms unbalanced, sync negative<br>$P_B$: 0.7 Vp-p, 75 ohms<br>$P_R$: 0.7 Vp-p, 75 ohms |
| RF Inputs | 2 | |
| Converter | 1 | |
| Speaker Output | 15 W × 2 | |
| Dimensions (W × H × D) | KF-50XBR800: 1,376 × 964 × 415 mm (54 $^1/_4$ × 38 × 16 $^3/_8$ inches)<br>KF-60XBR800: 1,618 × 1,103 × 542 mm (63 $^3/_4$ × 43 $^1/_2$ × 21 $^3/_8$ inches) | |
| Mass | KF-50XBR800: 50 kg (110 lb 4 oz), KF-60XBR800: 66 kg (145 lb 8 oz) | |
| Power Consumption | | |
| In Use | 220 W | |
| In Standby | Under 1 W | |
| Supplied Accessories | | |
| Remote Control | RM-Y912 | |
| AAA Batteries | 2 supplied for remote control | |
| Cleaning Cloth | 1 | |
| Hex key wrench | 1 | |
| Brackets with screws | 2 | |
| Optional Accessories | | |

| | |
|---|---|
| TV Stand | SU-GW1 |
| Lamp | XL-2000U |
| AV Cable | VMC-810/820/830 HG |
| Audio Cable | RKC-515HG |
| Control S Cable | RK-G69HG |
| Component Video Cable | VMC-10/30 HG |
| AV Receiver | STR-V555ES or equivalent |
| Memory Stick media | 8MB (MSA-8A), 16MB (MSA-16A), 32MB (MSA-32A), 64MB (MSA-64A), |
| | 128MB (MSA-128A) |

Design and specifications are subject to change without notice.

# SAFETY CHECK-OUT

( US model only )

After correcting the original service problem, perfom the following safety checks before releasing the set to the customer:

1. Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
3. Check that all control knobs, shields, covers, ground straps, and mounting hardware have been replaced. Be absolutely certain that you have replaced all the insulators.
4. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
5. Look for parts which, through functioning, show obvious signs of deterioration. Point them out to the customer and recom mend their replacement.
6. Check the line cords for cracks and abrasion. Recommend the replacement of any such line cord to the customer.
7. Check the condition of the monopole antenna (if any). Make sure the end is not broken off, and has the plastic cap on it. Point out the danger of impalement on a broken antenna to the customer, and recommend the antenna's replacement.
8. Check the B+ and HV to see they are at the values specified. Make sure your instruments are accurate;be suspicious of your HV meter if sets always have low HV.
9. Check the antenna temminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.

## LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5mA (500 microampers) . Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to usc these instruments.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. NearIy all battery operated digital multimeters that have a 2V AC range are suitable. (See Fig. A)

## HOW TO FIND A GOOD EARTH GROUND

A cold-water pipe is guaranteed earth ground;the cover-plate retaining screw on most AC outlet boxes is also at earth ground. If the retaining screw is to be used as your earth-ground, verify that it is at ground by measuring the resistance between it and a cold-water pipe with an ohmmeter. The reading should be zero ohms. If a cold-water pipe is not accessible, connect a 60-l00 watts trouble light (not a neon lamp) between the hot side of the receptacle and the retaining screw. Try both slots, if necessary, to locate the hot side of the line, the lamp should light at normal brilliance if the screw is at ground potential. (See Fig. B)




*Fig. A. Using an AC voltmeter to check AC leakage.*




*Fig. B. Checking for earth ground.*

**CAUTION**

These servicing instructions are for use by qualified service personnel only.
To reduce the risk of electric shock, do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so.

(CAUTION)
SHORT CIRCUIT THE ANODE OF THE PICTURE TUBE AND THE ANODE CAP TO THE METAL CHASSIS, CRT SHIELD, OR CARBON PAINTED ON THE CRT, AFTER REMOVING THE ANODE.

WARNING!!
AN ISOLATION TRANSFORMER SHOULD BE USED DURING ANY SERVICE TO AVOID POSSIBLE SHOCK HAZARD, BECAUSE OF LIVE CHASSIS.
THE CHASSIS OF THIS RECEIVER IS DIRECTLY CONNECTED TO THE AC POWER LINE.

SAFETY-RELATED COMPONENT WARNING!!
COMPONENTS IDENTIFIED BY SHADING AND MARK ⚠ ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY. CIRCUIT ADJUSTMENTS THAT ARE CRITICAL TO SAFE OPERATION ARE IDENTIFIED IN THIS MANUAL. FOLLOW THESE PROCEDURES WHENEVER CRITICAL COMPONENTS ARE REPLACED OR IMPROPER OPERATION IS SUSPECTED.

(ATTENTION)
APRES AVOIR DECONNECTE LE CAP DE L'ANODE, COURTCIRCUITER L'ANODE DU TUBE CATHODIQUE ET CELUI DE L'ANODE DU CAP AU CHASSIS METALLIQUE DE L'APPAREIL, OU AU COUCHE DE CARBONE PEINTE SUR LE TUBE CATHODIQUE OU AU BLINDAGE DU TUBE CATHODIQUE.

ATTENTION!!
AFIN D'EVITER TOUT RISQUE DELECTROCUTION PROVENANT D'UN CHÁSSIS SOUS TENSION, UN TRANSFORMATEUR D'ISOLEMENT DOIT ETRE UTILISÉ LORS DE TOUT DEPANNAGE.
LE CHÁSSIS DE CE RECEPTEUR EST DIRECTEMENT RACCORDÉ Á L'ALIMENTATION SECTEUR.

ATTENTION AUX COMPOSANTS RELATIFS ÁLA SÉCURITÉ!!
LES COMPOSANTS IDENTIFIÉS PAR UNE FRAME ET PAR UNE MAPQUE ⚠ SUR LES SCHÉMAS DE PRINCIPE, LES VUES EXPLOSÉES ET LES LISTES DE PIECES SONT D'UNE IMPORTANCE CRITIQUE POUR LA SÉCURITÉ DU FONCTIONNEMENT. NE LES REMPLACER QUE PAR DES COMPOSANTS SONY DONT LE NUMÉRO DE PIÉCE EST INDIQUÉ DANS LE PRÉSENT MANUEL OU DANS DES SUPPLÉMENTS PUBLIÉS PAR SONY. LES RÉGLAGES DE CIRCUIT DONT L'IMPORTANCE EST CRITIQUE POUR LA SÉCURITÉ DU FONCTIONNEMENT SONT IDENTIFIES DANS LE PRÉSENT MANUEL. SUIVRE CES PROCÉDURES LORS DE CHAQUE REMPLACEMENT DE COMPOSANTS CRITIQUES, OU LORSQU'UN MAUVAIS FONCTIONNEMENT SUSPECTÉ.

## TABLE OF CONTENTS


| Section | Title | Page |
|---|---|---|
| **1. SELF DIAGNOSIS FUNCTION** | | 8 |
| **2. DISASSEMBLY** | | |
| 2-1. | Rear Cover Assembly | 11 |
| 2-2. | OU Bracket Removal | 11 |
| 2-3. | Service Position | 11 |
| 2-4. | Power Block Removal | 11 |
| 2-5. | Optical Unit Block Assembly Removal | 12 |
| 2-6. | UD Board, Terminal Board Assembly Removal | 12 |
| 2-7. | U, M, BB, BC Boards Removal | 13 |
| 2-8. | G Board Removal | 13 |
| 2-9. | A Board Removal | 14 |
| 2-10. | T Board Removal | 14 |
| 2-11. | Control Panel Block Assembly Removal | 14 |
| 2-12. | H3 Board Removal | 14 |
| 2-13. | H2 Board Removal | 15 |
| 2-14. | Screen Mirror Block Assembly Removal | 15 |
| 2-15. | H1 Board Removal | 15 |
| **3. ELECTRICAL ADJUSTMENTS** | | |
| 3-1. | Electrical Adjustment by Remote Commander | 16 |
| 3-1-1. | Method of Setting the Service Adjustment Mode | 16 |
| 3-1-2. | Service Mode Adjustment | 16 |
| 3-1-3. | Memory Write Confirmation Method | 16 |
| 3-1-4. | Adjusting Buttons and Indicator | 17 |
| 3-1-5. | Service Mode List | 18 |
| 3-2. | Chassis Picture Quality Adjustment | 65 |
| 3-2-1. | White Level Adjustment | 65 |
| 3-2-2. | Sub Color/Sub Hue Adjustment | 66 |
| 3-2-3. | Hi-Level/Cut-Off Adjustment | 68 |
| 3-3. | Vertical Stripe Adjustment | 68 |
| 3-4. | Sub Bright Adjustment | 69 |
| 3-5. | Screen Center Adjustment | 69 |
| 3-6. | Favorites Adjustment | 69 |
| **4. DIAGRAMS** | | |
| 4-1. | Block Diagram (1) | 70 |
| | Block Diagram (2) | 71 |
| | Block Diagram (3) | 72 |
| | Block Diagram (4) | 73 |
| | Block Diagram (5) | 74 |
| | Block Diagram (6) | 75 |
| | Block Diagram (7) | 76 |
| | Block Diagram (8) | 77 |
| | Block Diagram (9) | 78 |
| | Block Diagram (10) | 79 |
| 4-2. | Frame Schematic Diagram | 80 |
| 4-3. | Circuit Boards Location | 81 |
| 4-4. | Schematic Diagrams and Printed Wiring Boards | 81 |
| (1) | Schematic Diagram of A (1/4) Board | 82 |
| (2) | Schematic Diagram of A (2/4) Board | 83 |
| (3) | Schematic Diagram of A (3/4) Board | 84 |
| (4) | Schematic Diagram of A (4/4) Board | 85 |
| (5) | Schematic Diagram of BB (1/10) Board | 86 |
| (6) | Schematic Diagram of BB (2/10) Board | 87 |
| (7) | Schematic Diagram of BB (3/10) Board | 88 |
| (8) | Schematic Diagram of BB (4/10) Board | 89 |
| (9) | Schematic Diagram of BB (5/10) Board | 90 |
| (10) | Schematic Diagram of BB (6/10) Board | 91 |
| (11) | Schematic Diagram of BB (7/10) Board | 92 |
| (12) | Schematic Diagram of BB (8/10) Board | 93 |
| (13) | Schematic Diagram of BB (9/10) Board | 94 |
| (14) | Schematic Diagram of BB (10/10) Board | 95 |
| (15) | Schematic Diagram of BC (1/5) Board | 96 |
| (16) | Schematic Diagram of BC (2/5) Board | 97 |
| (17) | Schematic Diagram of BC (3/5) Board | 98 |
| (18) | Schematic Diagram of BC (4/5) Board | 99 |
| (19) | Schematic Diagram of BC (5/5) Board | 100 |
| (20) | Schematic Diagram of BF Board | 101 |
| (21) | Schematic Diagram of BM-1C (1/3) Board | 102 |
| (22) | Schematic Diagram of BM-1C (2/3) Board | 103 |
| (23) | Schematic Diagram of BM-1C (3/3) Board | 104 |
| (24) | Schematic Diagram of G Board | 105 |
| (25) | Schematic Diagrams of H1, H2, H3 and T Boards | 106 |

| Section | Title | Page |
|---|---|---|
| (26) | Schematic Diagram of M (1/4) Board | 107 |
| (27) | Schematic Diagram of M (2/4) Board | 108 |
| (28) | Schematic Diagram of M (3/4) Board | 109 |
| (29) | Schematic Diagram of M (4/4) Board | 110 |
| (30) | Schematic Diagram of U (1/3) Board | 111 |
| (31) | Schematic Diagram of U (2/3) Board | 112 |
| (32) | Schematic Diagram of U (3/3) Board | 113 |
| (33) | Schematic Diagram of UD (1/2) Board | 114 |
| (34) | Schematic Diagram of UD (2/2) Board | 115 |
| | Printed Wiring Boards | |
| | • A Board | 116 |
| | • BB Board | 118 |
| | • BC Board | 120 |
| | • BM-1C Board | 120 |
| | • G Board | 122 |
| | • H1 and T Boards | 124 |
| | • H2 Board | 125 |
| | • H3 Board | 126 |
| | • M Board | 127 |
| | • U Board | 128 |
| | • UD Board | 130 |
| 4-5 | Waveforms | 131 |
| 4-6 | IC Block Diagrams | 132 |
| 4-7 | Semiconductors | 134 |

**5. EXPLODED VIEWS**

| | | |
|---|---|---|
| 5-1. | Screen Mirror Block Section | 136 |
| 5-2. | Cabinet Section | 137 |
| 5-3. | Main Section | 138 |
| 5-4. | Optical Unit Section | 139 |

**6. ELECTRICAL PARTS LIST** ..... 140

# SECTION 1
# SELF DIAGNOSIS FUNCTION

## 1. Summary of Self-Diagnosis Function

- This device includes a self-diagnosis function.
- In case of abnormalities, the STANDBY indicator automatically blinks. It is possible to predict the abnormality location by the number of blinks. The Instruction Manual describes blinking of the STANDBY indicator.
- If the symptom is not reproduced sometimes in case of a malfunction, there is recording of whether a malfunction was generated or not. Operate the remote command to confirm the matter on the screen and to predict the location of the abnormality.

## 2. Diagnosis Items and Prediction of Malfunction Location

- When a malfunction occurs the STANDBY indicator only blinks for one of the following diagnosis items. In case of two or more malfunctions, the item which first occurred blinks. If the malfunctions occurred simultaneously, the item with the lower blink count blinks first.
- The screen display displays the results regarding all the diagnosis items listed below. The display " 0 " means that no malfunctions occurred.

| Diagnosis Item | No. of times STANDBY/STEREO indicator blinks | Probable Cause Location | Detected symptoms |
|---|---|---|---|
| Power does not turn on | 0 | • Power cord is not plugged in.<br>• Fuse is burned out (F1601) (G board) | • Power does not come on.<br>• No power is supplied to the unit.<br>• AC power supply is faulty. |
| Lamp cover error | 3 times | • Lamp cover is not attached securely. | • No picture/No sound |
| FAN stopped | 4 times | • FAN1 or FAN2 power is not supplied. (A board)<br>• FAN connector is not attached securely. | • No picture/No sound |
| Lamp driver error | 5 times | • Lamp driver is faulty. | • No picture/No sound |
| Low B error | 6 times | • +5 V is not supplied. (G board) | • No picture/No sound |
| Audio error | 9 times | • Audio ±15 V line is shorted. (A, G board)<br>• IC1203 or IC1204 is faulty. (A board)<br>• PS1601 or 1602 is opened. (G board) | • No picture/No sound |
| Lamp error | LAMP LED flashes | • Lamp for the light souce burns out. | • No picture/No sound |

## 3. Blinking count display of STANDBY indicator




* One blink is not used for self-diagnosis.

•EXAMPLE

<Diagnosis Items> <Number of Blinks>

• Lamp Cover 3 times

• FAN 4 times




**Release of STANDBY indicator blinking.**

- The STANDBY indicator blinking display is released by removing the plug from the power or leaving for 2 minutes.

## 4. Self-Diagnosis screen displays

- In cases of malfunctions where it is not possible to determine the symptom such as when the power goes off occasionally or when the screen disappears occasionally, there is a screen display on whether the malfunction occurred or not in the past (and whether the detection circuit operated or not) in order to allow confirmation.

**<Screen Display Method>**

- Quickly press the remote command button in the following order from the standby state.

DISPLAY ➡ Channel 5 ➡ VOL – ➡ POWER

⇧

Be aware that this differs from the method of entering the service mode (volume + ).

**Self-Diagnosis screen display**

MAIN

```
Self Diagnosis

 6:Low B        0
 9:AUDIO        1
101:WDT         0
```

Move the ioystick ⬅ / ➡

LCD ENGINE

```
SELF DIAGNOSIS
 1:LAMP         1
 3:LAMP COVER   0
 4:FAN          0
 5:LAMP DRIVER  0
201:WDT-ENGINE  0
```

Numeral “1” means a fault was detected one time or more.

Numeral “0” means that no fault was detected.

## 5. Self-Diagnosis Screen Display

- The results display is not automatically cleared. In case of repairs and after repairs, check the self-diagnosis screen and be sure to return the results display to “ 0 ”.
- If the results display is not returned to “ 0 ” it will not be possible to judge a new malfunction after completing repairs.

**<Method of Clearing Results Display>**

1. Power off (Set to the standby mode)
2. DISPLAY ➡ Channel 5 ➡ VOL + ➡ POWER (Service Mode)
3. Channel 8 ➡ ENTER (Test reset = Factory preset condition)

**<Method of Ending Self-Diagnosis Screen>**

- When ending the self-diagnosis screen completely, turn the power switch OFF on the remote commander or the main unit.

## 6. Self-Diagnosis function operation

| | |
|---|---|
| 3 : Lamp Cover | When lamp cover SW is opened then pin ④ of CN1012 on the A board is high, LCD Engine μ-com (IC9502) detects it and make turn off the lamp. |
| 4 : FAN Stop | When FAN1 or FAN2 is stopped then pin ⑧ or ⑩ of CN1012 on the A board is high, LCD Engine μ-com (IC9502) detects it and make turn off the lamp. |
| 5 : Lamp Driver | When lamp is not turned on then pin ㉙ of LCD Engine μ-com (IC9502) is high, checks pin ㉘ of LCD Engine μ-com . If pin ㉘ is low, it is judged no High Voltage. |
| 6 : Low B | Detect +5 V line failure. |
| 9 : Audio | When DC is appeared by audio amp failure at speaker line.<br>Then it is detected by MAIN μ-com (IC9004) and it turns off the main power. |
| LAMP : Lamp error | When lamp is not turned on then pin ㉙ of LCD Engine μ-com (IC9502) is high, checks pin ㉘ of LCD Engine μ-com.<br>If pin ㉘ is high, it is judged lamp is burned out. |

### Self-Diagnosis block diagram



# SECTION 2
# DISASSEMBLY

## 2-1. REAR COVER ASSEMBLY




## 2-2. OU BRACKET REMOVAL




## 2-3. SERVICE POSITION




## 2-4. POWER BLOCK REMOVAL



## 2-5. OPTICAL UNIT BLOCK ASSEMBLY REMOVAL

Note: Be careful about the no dust or dirt are on the surface contacts the optical unit block assembly.

- Clean the periphery of the set.
- Clean the periphery of the optical unit block assembly in the set (the inside of the control panel, the surface contacts between the optical unit block assembly and the bottom cabinet and periphery).







## 2-6. UD BOARD, TERMINAL BOARD ASSEMBLY REMOVAL


⑧ Two screws (+BVTP 3 x 12)
⑨ UD board
⑥ Claw
② Bracket M
⑦Terminal board assembly
① Screw (+BVTP 4 x 16)
⑤ RF antenna switch
④ Two washers
③ Nine screws (+BVTP 3 x 12)

## 2-7. U, M, BB, BC BOARDS REMOVAL




## 2-8. G BOARD REMOVAL



## 2-9. A BOARD REMOVAL




## 2-10. T BOARD REMOVAL




## 2-11. CONTROL PANEL BLOCK ASSEMBLY REMOVAL




## 2-12. H3 BOARD REMOVAL



## 2-13. H2 BOARD REMOVAL




## 2-14. SCREEN MIRROR BLOCK ASSEMBLY REMOVAL




## 2-15. H1 BOARD REMOVAL



# SECTION 3

# ELECTRICAL ADJUSTMENTS

## 3-1. ELECTRICAL ADJUSTMENT BY REMOTE COMMANDER

By using remote commander (RM-Y910K), all circuit adjustments can be made.

**NOTE : Test Equipment Required.**

1. Pattern Generator (with component outputs)
2. Oscilloscope
3. Digital multimeter

### 3-1-1. Method of Setting the Service Adjustment Mode

1. Standby mode. (Power off)
2. [DISPLAY] → [5] → [VOL (+)] → [TV POWER] on the remote commander.
   (Press each button within a second.)
   The following service screen will appear.







<LCD PROJECTOR ENGINE>

### 3-1-2. Service Mode Adjustment

1. The SCREEN displays the item being adjusted.
2. Press "①" or "④" on the remote commander to select the adjustment item.
3. Press "③" or "⑥" on the remote commander to change the data.
4. Press "②" or "⑤" on the remote commander to select the category. Every time you press "②" (Category up), Service mode changes in the order as shown below.




5. If you want to recover the latest values press "⓪" then "[ENTER]" to read the memory.
6. Press "[MUTING]" then "[ENTER]" to write into memory.
7. Turn power off.

Note: Press "⑧" then "[ENTER]" on the remote commander to set the shipping conditions or turn set off and on to exit.

### 3-1-3. Memory Write Confirmation Method

1. After adjustment, turn power off with the remote commander.
2. Turn power on and set to service mode.
3. Call the adjusted items again and confirm they were adjusted.

### 3-1-4. Adjusting Buttons and Indicator




RM-Y912

**FUNCTION OF KEYS ON COMMANDER**

- ① : Changes adjustment item. (item No. moves up)
- ④ : Changes adjustment item. (item No. moves down)
- ② : Changes adjustment category. (category moves up)
- ⑤ : Changes adjustment category. (category moves down)
- ③ : Changes data value. (up)
- ⑥ : Changes data value. (down)

Commander Function

| Button | Mode | Description |
|---|---|---|
| MUTING + ENTER | WRITE | Writes data to NVM. |
| ⓪ + ENTER | READ | Reads data from NVM. |
| ⑧ + ENTER | RESET | Set the shipping condition. |
| ⑦ + ENTER | INT– | Service data initialization. Not stored. (Be sure not to use usually) |

## 3-1-5. Service Mode List

Note: • shaded items are fixed. There is no need to change data. Others are different a little in the sets individually. Basically, there is no need to change data, too.

### 3D-COMB

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | NRMD | Noise reduction mode setting | 0 - 3 | Table 1 | |
| 1 | CLKS | System clock setting | 0 - 3 | 1 | |
| 2 | NSDS | Selection for standard/non-standard signal processing | 0 - 3 | 0 | |
| 3 | MSS | Selection for inter-frame/inter-line processing | 0 - 3 | 0 | |
| 4 | KILS | Killer processing selection | 0 - 3 | Table 2 | |
| 5 | FRZE | | | 0 | |
| 6 | EXCS | | | 1 | |
| 7 | CDL | C-signal phase with respect to the Y-signal | 0 - 7 | 4 | |
| 8 | DYCO | DY detection coring level (Y motion detedtion coring) | 0 - 15 | Table 3 | |
| 9 | DYGA | DY detection gain (Y motion detection gain) | 0 - 15 | Table 3 | |
| 10 | DCCO | DC detection coring level (C motion detedtion coring) | 0 - 15 | Table 3 | |
| 11 | DCGA | DC detection gain (C motion detection gain) | 0 - 15 | Table 3 | |
| 12 | WSC | Amount of noise detection coring | 0 - 3 | 1 | |
| 13 | WSS | | | 0 | |
| 14 | VAPG | V aperture compensation gain | 0 - 7 | Table 4 | |
| 15 | VAPI | V aperture compensation convergence point | 0 - 31 | Table 4 | |
| 16 | TEST | Test bit (0: Normal mode, 1: Test mode) (*forbidden setting) | 0, 1 | 0 | |
| 17 | YPFT | Y peeking filter (BPF) center frequency | 0 - 3 | Table 5 | |
| 18 | YPFG | Y peeking filter (BPF) gain | 0 - 15 | Table 5 | |
| 19 | SEDC | | | 0 | |
| 20 | SEDY | | | 1 | |
| 21 | YHCO | Y output high frequency component coring | 0 - 3 | 1 | |
| 22 | YHCG | Y output high frequency component coring gain | 0, 1 | 1 | |
| 23 | SYSP | | | 0 | |
| 24 | TES2 | | | 0 | |

Table 1

| No. | Item | RF | CV | | YC | |
|---|---|---|---|---|---|---|
| | | | STANDARD/NONSTANDERD SIGNAL | Others | STANDARD/NONSTANDERD SIGNAL | Others |
| 0 | NRMD | 0 | 0 | 1 | 2 | 3 |

Table 2

| No. | Item | RF/CV/YC | | Others |
|---|---|---|---|---|
| | | CXA2103-1 | | |
| | | 1 | 0 | |
| 4 | KILS | 2 | 1 | 1 |

Table 3

| No. | Item | NRMD=0 | NRMD=1 | NRMD=2 | NRMD=3 |
|---|---|---|---|---|---|
| 8 | DYCO | 2 | 2 | 2 | 2 |
| 9 | DYGA | 10 | 10 | 10 | 10 |
| 10 | DCCO | 5 | 5 | 5 | 5 |
| 11 | DCGA | 5 | 5 | 5 | 5 |

Table 4

| No. | Item | VIVID | STANDARD | PRO | Mild |
|---|---|---|---|---|---|
| 14 | VAPG | 0 | 0 | 0 | 0 |
| 15 | VAPI | 0 | 0 | 0 | 0 |

Table 5

| No. | Item | RF | | | | VIDEO1-4 | | | | TWIN |
|---|---|---|---|---|---|---|---|---|---|---|
| | | VIVID | STANDARD | PRO | Mild | VIVID | STANDARD | PRO | Mild | |
| 17 | YPFT | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 |
| 18 | YPFG | 7 | 7 | 7 | 7 | 8 | 8 | 8 | 8 | 6 |

## 2103-1

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | YLEV | Y out gain | 0 - 63 | Table 1 | |
| 1 | CLEV | Cb & Cr out gain | 0 - 63 | Table 1 | |
| 2 | SCON | Sub contrast | 0 - 15 | Table 2 | |
| 3 | SCOL | Sub color | 0 - 15 | Table 2 | |
| 4 | SHUE | Sub hue | 0 - 15 | Table 2 | |
| 5 | YDLY | Y/C delay time | 0 - 3 | Table 2 | |
| 6 | SHAP | Sharpness | 0 - 15 | Table 3 | |
| 7 | SHF0 | Sharpness f0 selector | 0 - 3 | Table 3 | |
| 8 | PREO | Sharpness pre/over-shoot ratio | 0 - 3 | Table 3 | |
| 9 | BPF0 | Chroma band filter f0 setting | 0 - 3 | Table 4 | |
| 10 | BPFQ | Chroma band filter Q setting | 0 - 3 | Table 4 | |
| 11 | BPSW | Chroma band filter on/off | 0, 1 | Table 2 | |
| 12 | TRAP | Y block chroma trap filter on/off | 0, 1 | Table 4 | |
| 13 | LPF | Y/Cb/Cr output LPF on/off | 0, 1 | Table 4 | |
| 14 | AFCG | AFC loop gain (PLL between H sync & H VCO) | 0, 1 | Table 5 | |
| 15 | CDMD | V count down system mode selector | 0 - 3 | Table 5 | |
| 16 | SSMD | H & V sync slide level setting | 0 - 3 | Table 5 | |
| 17 | HMSK | Masking of macrovision signal on/off | 0, 1 | Table 6 | |
| 18 | HALI | H automatic adjustment on/off | 0, 1 | Table 7 | |
| 19 | PPHA | H TIM phase adjustment video | 0 - 15 | Table 6 | |
| 20 | CBOF | Cb/EXT Cb offset | 0 - 63 | Table 1 | |
| 21 | CROF | Cr/EXT Cr offset | 0 - 63 | Table 1 | |
| 22 | CBO2 | | | Table 8 | |
| 23 | CRO2 | | | Table 8 | |
| 24 | ATPD | Auto-pedestal inflection point | 0 - 3 | Table 9 | |
| 25 | DCTR | DC transmission ratio | 0 - 3 | Table 9 | |

Table 1

| No. | Item | other | | Single/Mild | |
|---|---|---|---|---|---|
| | | RF/Video1-4 | Video5-7 | RF/Video1-4 | Video5-7 |
| 0 | YLEV | 25 | 29 | 42 | 46 |
| 1 | CLEV | 7 | 20 | 43 | 58 |
| 20 | CBOF | 39 | 38 | 31 | 35 |
| 21 | CROF | 27 | 34 | 28 | 35 |

Table 2

| No. | Item | RF | Others |
|---|---|---|---|
| 2 | SCON | 7 | 9 |
| 3 | SCOL | 5 | 6 |
| 4 | SHUE | 4 | 6 |
| 5 | YDLY | 0 | 0 |
| 11 | BPSW | 1 | 0 |

Table 3

| No. | Item | Others | CV/YC | V5/V6 | DVI-480I |
|---|---|---|---|---|---|
| 6 | SHAP | 6 | 8 | 5 | 5 |
| 7 | SHF0 | 1 | 3 | 3 | 3 |
| 8 | PREO | 0 | 3 | 0 | 0 |

Table 4

| No. | Item | RF | C Video | S Video | Component-480i |
|---|---|---|---|---|---|
| 9 | BPF0 | 3 | 0 | 0 | 0 |
| 10 | BPFQ | 0 | 0 | 0 | 0 |
| 12 | TRAP | 0 | 0 | 0 | 0 |
| 13 | LPF | 1 | 1 | 1 | 1 |

Table 5

| No. | Item | RF | Video1-4 | Others |
|---|---|---|---|---|
| 14 | AFCG | 1 | 0 | 0 |
| 15 | CDMD | 3 | 3 | 3 |
| 16 | SSMD | 0 | 0 | 0 |

Table 6

| No. | Item | RF | Video1-4 | Video5-6 | DVI |
|---|---|---|---|---|---|
| 17 | HMSK | 0 | 1 | 1 | 0 |
| 19 | PPHA | 7 | 7 | 7 | 7 |

Table 7

| No. | Item | RF |
|---|---|---|
| 18 | HALI | 0 |

Table 8

| No. | Item | DVI | DVI-mild |
|---|---|---|---|
| 22 | CBO2 | 38 | 32 |
| 23 | CRO2 | 34 | 32 |

Table 9

| No. | Item | Single | Twin | | | |
|---|---|---|---|---|---|---|
| | | | BLK0 | BLK1 | BLK2 | BLK3 |
| 24 | ATPD | 0 | 0 | 1 | 0 | 0 |
| 25 | DCTR | 0 | 0 | 2 | 0 | 0 |

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | YLEV | Y out gain | | Table 1 | |
| 1 | CLEV | Cb & Cr out gain | | Table 1 | |
| 2 | SCON | Sub contrast | | Table 2 | |
| 3 | SCOL | Sub color | | Table 2 | |
| 4 | SHUE | Sub hue | | Table 2 | |
| 5 | YDLY | Y/C delay time | | Table 2 | |
| 6 | SHAP | Sharpness | | Table 3 | |
| 7 | SHF0 | Sharpness f0 selector | | Table 3 | |
| 8 | PREO | Sharpness pre/over-shoot ratio | | Table 3 | |
| 9 | BPF0 | Chroma band filter f0 setting | | Table 3 | |
| 10 | BPFQ | Chroma band filter Q setting | | Table 3 | |
| 11 | BPSW | Chroma band filter on/off | | Table 3 | |
| 12 | TRAP | Y block chroma trap filter on/off | | Table 3 | |
| 13 | LPF | Y/Cb/Cr output LPF on/off | | Table 3 | |
| 14 | AFCG | AFC loop gain (PLL between H sync & H VCO) | | Table 4 | |
| 15 | CDMD | V count down system mode selector | | Table 4 | |
| 16 | SSMD | H & V sync slide level setting | | Table 4 | |
| 17 | HMSK | Masking of macrovision signal on/off | | Table 4 | |
| 18 | HALI | H automatic adjustment on/off | | Table 4 | |
| 19 | PPHA | H TIM phase adjustment video | | Table 4 | |
| 20 | CBO1 | | | Table 1 | |
| 21 | CRO1 | | | Table 1 | |

Table 1

| No. | Item | RF/Video | |
|---|---|---|---|
| | | VDO | DRC |
| 0 | YLEV | 28 | 35 |
| 1 | CLEV | 15 | 20 |
| 20 | CBO1 | 36 | 26 |
| 21 | CRO1 | 37 | 36 |

Table 2

| No. | Item | RF | Video |
|---|---|---|---|
| 2 | SCON | 7 | 8 |
| 3 | SCOL | 8 | 8 |
| 4 | SHUE | 5 | 8 |
| 5 | YDLY | 0 | 0 |

Table 3

| No. | Item | RF | C Video | S Video |
|---|---|---|---|---|
| 6 | SHAP | 6 | 6 | 8 |
| 7 | SHF0 | 0 | 1 | 0 |
| 8 | PREO | 3 | 3 | 3 |
| 9 | BPF0 | 0 | 0 | 0 |
| 10 | BPFQ | 0 | 0 | 0 |
| 11 | BPSW | 0 | 0 | 0 |
| 12 | TRAP | 0 | 0 | 0 |
| 13 | LPF | 1 | 1 | 1 |

Table 4

| No. | Item | RF | Video |
|---|---|---|---|
| 14 | AFCG | 1 | 0 |
| 15 | CDMD | 3 | 3 |
| 16 | SSMD | 0 | 0 |
| 17 | HMSK | 0 | 1 |
| 18 | HALI | 0 | 0 |
| 19 | PPHA | 7 | 7 |

## PIC-BOOST1

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | BSET | Data table selection | 0 - 15 | Table 1 | |
| 1 | AMS | Amplitude mode selection | 0, 1 | 1 | |
| 2 | DEMO | Demonstration mode on/off | 0, 1 | 0 | |
| 3 | SN | Steepness correction | 0 - 63 | 0 | |

Table 1-1

| No. | Item | Single | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | RF | | | | Video | | | | Component | | | |
| | | Vivid | Standard | Movie | Mild | Vivid | Standard | Movie | Mild | Vivid | Standard | Movie | Mild |
| 0 | BSET | 2 | 4 | 6 | 10 | 5 | 7 | 8 | 11 | 1 | 3 | 9 | 12 |

Table 1-2

| No. | Item | Single | | | | Twin | | | |
|---|---|---|---|---|---|---|---|---|---|
| | | DVI | | | | - | | | |
| | | Vivid | Standard | Movie | Mild | Vivid | Standard | Movie | Mild |
| 0 | BSET | 1 | 3 | 9 | 12 | 0 | 0 | 0 | 0 |

## PIC-BOOST2

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | LWID | Line width correction | 0 - 63 | Table 1 | |
| 1 | STEP | Steeness correction | 0 - 63 | Table 1 | |
| 2 | CRNG | Coring level | 0 - 63 | Table 1 | |
| 3 | VDC | Video dependent coring on/off | 0, 1 | Table 1 | |
| 4 | OSP | Overrule smart peaking | 0, 1 | Table 1 | |
| 5 | BOST | Black offset compensation on/off | 0, 1 | Table 1 | |
| 6 | ABST | Adaptive black stretch | 0 - 63 | Table 1 | |
| 7 | VGAM | Variable gamma | 0 - 63 | Table 1 | |
| 8 | NLMP | Non-linearity amplifier | 0 - 63 | Table 1 | |
| 9 | PKNG | Peaking amplitude | 0 - 63 | Table 1 | |
| 10 | CFS | Color filter selection | 0, 1 | Table 1 | |
| 11 | FHS | Line frequency selection | 0, 1 | Table 1 | |
| 12 | LDH | Luminance determined histogram | 0, 1 | Table 1 | |
| 13 | SNOW | Snow color adjustment by green stretch | 0, 1 | Table 1 | |
| 14 | WLB | Window letterbox format | 0, 1 | 0 | |

Table 1

| No. | Item | BSET:0 | BSET:1 | BSET:2 | BSET:3 | EST:4 | BSET:5 | BSET:6 | BSET:7 | BSET:8 | BSET:9 | BSET:10 | BSET:11 | BSET:12 | BSET:13 | BSET:14 | BSET:15 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| 0 | LWID | 0 | 31 | 31 | 31 | 31 | 31 | 31 | 31 | 31 | 31 | 31 | 31 | 31 | 31 | 31 | 31 |
| 1 | STEP | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 2 | CRNG | 0 | 15 | 15 | 12 | 10 | 10 | 10 | 5 | 5 | 5 | 20 | 10 | 10 | 15 | 5 | 15 |
| 3 | VDC | 0 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| 4 | OSP | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 5 | BOST | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 6 | ABST | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 7 | VGAM | 32 | 28 | 31 | 24 | 31 | 26 | 28 | 25 | 28 | 28 | 31 | 25 | 24 | 27 | 31 | 22 |
| 8 | NLMP | 0 | 26 | 27 | 21 | 18 | 24 | 10 | 28 | 10 | 10 | 18 | 28 | 21 | 22 | 7 | 18 |
| 9 | PKNG | 0 | 31 | 10 | 32 | 20 | 36 | 25 | 31 | 25 | 25 | 10 | 32 | 32 | 35 | 20 | 42 |
| 10 | CFS | 0 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| 11 | FHS | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 12 | LDH | 0 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| 13 | SNOW | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |

PIC-BOOST3

| No. | Item | Function | Data range | BSET:0 | BSET:1 | BSET:2 | BSET:3 | EST:4 | BSET:5 | BSET:6 | BSET:7 | BSET:8 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| 0 | CDS | Color dependent sharpness on/off | 0, 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| 1 | CTI | Color transient improvement on/off | 0, 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 2 | WPO | White-point stretch on/off | 0, 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| 3 | DBL | Blue stretch on/off | 0, 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 4 | GBL | Blue stretch gain | 0, 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 5 | SBL | Blue stretch size | 0, 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 6 | DSK | Dynamic skin tone on/off | 0, 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 7 | ASK | Dynamic skin tone angle | 0, 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 8 | WSK | Dynamic skin tone width | 0, 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 9 | SSK | Dynamic skin tone size | 0, 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 10 | DGR | Green enhancement on/off | 0, 1 | 0 | 1 | 1 | 0 | 0 | 1 | 0 | 0 | 0 |
| 11 | GGR | Green enhancement gain | 0, 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 12 | WGR | Green enhancement width | 0, 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 13 | SGR | Green enhancement size | 0, 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 14 | CDLY | Chrominance delay | 0 - 7 | 4 | 7 | 7 | 7 | 7 | 4 | 7 | 4 | 4 |

| No. | Item | Function | Data range | BSET:9 | BSET:10 | BSET:11 | BSET:12 | BSET:13 | BSET:14 | BSET:15 |
|---|---|---|---|---|---|---|---|---|---|---|
| 0 | CDS | Color dependent sharpness on/off | 0, 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| 1 | CTI | Color transient improvement on/off | 0, 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 2 | WPO | White-point stretch on/off | 0, 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| 3 | DBL | Blue stretch on/off | 0, 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 4 | GBL | Blue stretch gain | 0, 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 5 | SBL | Blue stretch size | 0, 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 6 | DSK | Dynamic skin tone on/off | 0, 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 7 | ASK | Dynamic skin tone angle | 0, 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 8 | WSK | Dynamic skin tone width | 0, 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 9 | SSK | Dynamic skin tone size | 0, 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 10 | DGR | Green enhancement on/off | 0, 1 | 0 | 0 | 0 | 0 | 1 | 0 | 0 |
| 11 | GGR | Green enhancement gain | 0, 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 12 | WGR | Green enhancement width | 0, 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 13 | SGR | Green enhancement size | 0, 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 14 | CDLY | Chrominance delay | 0 - 7 | 7 | 7 | 7 | 7 | 4 | 5 | 4 |

2170P-1 (KF-50XBR800)

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | RDRV | | | Table 1 | |
| 1 | GDRV | | | Table 1 | |
| 2 | BDRV | | | Table 1 | |
| 3 | RCUT | | | Table 1 | |
| 4 | GCUT | | | Table 1 | |
| 5 | BCUT | | | Table 1 | |
| 6 | YOSW | | | Table 2 | |
| 7 | TCOF | | | 0 | |
| 8 | YOF | | | Table 2 | |
| 9 | CBOF | | | Table 1 | |
| 10 | CROF | | | Table 1 | |
| 11 | SBRT | | | 31 | |
| 12 | WBSW | | | 0 | |
| 13 | DCOL | | | Table 3 | |

Table 1

| No. | Item | other | | VIDEO 1-4 | | VIDEO 5-7 | | | | | Twin | MS |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | 480I | | 480P,VGA | 720P | 1080I | | |
| | | NOT Mild | Mild | NOT Mild | Mild | NOT Mild | Mild | | | | | |
| 0 | RDRV | 45 | 45 | 45 | 45 | 45 | 45 | 45 | 46 | 45 | 45 | 45 |
| 1 | GDRV | 45 | 45 | 45 | 45 | 45 | 45 | 45 | 46 | 45 | 45 | 45 |
| 2 | BDRV | 45 | 45 | 45 | 45 | 45 | 45 | 45 | 46 | 45 | 45 | 45 |
| 3 | RCUT | 31 | 31 | 31 | 31 | 31 | 31 | 31 | 31 | 31 | 31 | 31 |
| 4 | GCUT | 28 | 28 | 28 | 28 | 28 | 28 | 28 | 28 | 28 | 28 | 28 |
| 5 | BCUT | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 |
| 9 | CBOF | 33 | 33 | 33 | 33 | 33 | 33 | 40 | 38 | 37 | 33 | 33 |
| 10 | CROF | 32 | 32 | 32 | 32 | 32 | 32 | 39 | 38 | 37 | 32 | 32 |

Table 2

| No. | Item | RF/V1-V4 | DVI | OTHER |
|---|---|---|---|---|
| 6 | YOSW | 1 | 1 | 0 |
| 8 | YOF | 0 | 0 | 7 |

Table 3

| No. | Item | COOL | NEUTRAL | WARM |
|---|---|---|---|---|
| 13 | DCOL | 0 | 0 | 0 |

2170P-2 (KF-50XBR800)

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | UPCG | | | Table 1 | |
| 1 | UBRG | | | Table 1 | |
| 2 | UCOL | | | Table 1 | |
| 3 | UHUE | | | Table 1 | |
| 4 | USHP | | | Table 1 | |
| 5 | UTMP | | | Table 1 | |
| 6 | UPOG | | | Table 2 | |
| 7 | UBOG | | | Table 2 | |
| 8 | UCOF | | | Table 2 | |
| 9 | UHOF | | | Table 2 | |
| 10 | SHOF | | | Table 2 | |
| 11 | PICO | | | Table 3 | |
| 12 | RGBS | | | Table 3 | |
| 13 | BLKB | | | 3 | |
| 14 | RGBL | | | 0 | |
| 15 | YLMT | | | 3 | |
| 16 | AGNG | | | Table 4 | |
| 17 | AKBO | | | 0 | |
| 18 | CLPP | | | 3 | |
| 19 | CLPG | | | 0 | |
| 20 | CLPS | | | 0 | |
| 21 | PPAD | | | 3 | |
| 22 | SYNP | | | 0 | |
| 23 | HVBT | | | 0 | |

Table 1

| No. | Item | Vivid | Standard | PRO | Mild |
|---|---|---|---|---|---|
| 0 | UPCG | 63 | 55 | 31 | 43 |
| 1 | UBRG | 27 | 31 | 31 | 31 |
| 2 | UCOL | 35 | 31 | 31 | 31 |
| 3 | UHUE | 31 | 31 | 31 | 31 |
| 4 | USHP | 35 | 33 | 31 | 25 |
| 5 | UTMP | 2 | 1 | 1 | 1 |

Table 2-1

| No. | Item | RF | | | | Video | | | | Component 480i | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild |
| 6 | UPOG | 31 | 31 | 38 | 36 | 31 | 33 | 38 | 36 | 31 | 31 | 38 | 36 |
| 7 | UBOG | 33 | 35 | 19 | 33 | 33 | 28 | 16 | 28 | 32 | 32 | 31 | 32 |
| 8 | UCOF | 31 | 33 | 31 | 32 | 32 | 34 | 31 | 34 | 31 | 31 | 32 | 30 |
| 9 | UHOF | 31 | 31 | 31 | 31 | 32 | 31 | 31 | 31 | 31 | 30 | 30 | 30 |
| 10 | SHOF | 27 | 30 | 31 | 37 | 26 | 27 | 31 | 35 | 24 | 26 | 31 | 37 |

Table 2-2

| No. | Item | Component 480p | | | | Component 720p | | | | Component 1080i | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild |
| 6 | UPOG | 31 | 34 | 38 | 32 | 31 | 31 | 38 | 33 | 31 | 31 | 38 | 33 |
| 7 | UBOG | 33 | 32 | 30 | 31 | 23 | 31 | 31 | 31 | 23 | 31 | 31 | 31 |
| 8 | UCOF | 31 | 31 | 31 | 31 | 28 | 28 | 31 | 28 | 28 | 28 | 31 | 28 |
| 9 | UHOF | 32 | 31 | 31 | 31 | 33 | 33 | 31 | 33 | 33 | 33 | 31 | 33 |
| 10 | SHOF | 31 | 33 | 29 | 31 | 29 | 33 | 31 | 34 | 29 | 33 | 31 | 34 |

Table 2-3

| No. | Item | Twin | | | | MS1,2 | | | | VGA |
|---|---|---|---|---|---|---|---|---|---|---|
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | |
| 6 | UPOG | 31 | 31 | 38 | 31 | 31 | 31 | 38 | 33 | 31 |
| 7 | UBOG | 36 | 31 | 29 | 31 | 23 | 31 | 31 | 31 | 31 |
| 8 | UCOF | 26 | 29 | 31 | 28 | 28 | 28 | 31 | 28 | 31 |
| 9 | UHOF | 31 | 31 | 31 | 31 | 33 | 33 | 31 | 33 | 31 |
| 10 | SHOF | 31 | 37 | 31 | 24 | 29 | 33 | 31 | 34 | 31 |

Table 3

| No. | Item | Blanking | | Power OFF |
|---|---|---|---|---|
| | | ON | OFF | |
| 11 | PICO | 1 | 1 | 0 |
| 12 | RGBS | 0 | 7 | 0 |

Table 4

| No. | Item | AGING | |
|---|---|---|---|
| | | ON | OFF |
| 16 | AGNG | 2 | 0 |

2170P-3 (KF-50XBR800)

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | SYSM | | | Table 1 | |
| 1 | VMLV | | | 7 | |
| 2 | VMCR | | | Table 1 | |
| 3 | VMLM | | | Table 1 | |
| 4 | VMF0 | | | Table 1 | |
| 5 | VMDL | | | Table 1 | |
| 6 | SHF0 | | | Table 1 | |
| 7 | PROV | | | Table 1 | |
| 8 | F1LV | | | Table 1 | |
| 9 | LTLV | | | Table 1 | |
| 10 | LTMD | | | Table 1 | |
| 11 | CTLV | | | Table 1 | |
| 12 | UBOF | | | Table 1 | |
| 13 | MIDE | | | Table 3 | |
| 14 | VM | | | Table 2 | |
| 15 | VMH | | | Table 2 | |
| 16 | VMM | | | Table 2 | |
| 17 | VML | | | Table 2 | |
| 18 | VGAP | | | Table 2 | |
| 19 | VGAS | | | 0 | |
| 20 | VGAB | | | 0 | |
| 21 | VGAC | | | 0 | |
| 22 | VGAV | | | 5 | |

Table 1-1

| No. | Item | RF | | | | VIDEO1-4 | | | | VIDEO 5-7 480I | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild |
| 0 | SYSM | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| 2 | VMCR | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 3 | VMLM | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 4 | VMF0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 5 | VMDL | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 6 | SHF0 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| 7 | PROV | 3 | 3 | 3 | 3 | 0 | 0 | 0 | 0 | 3 | 3 | 3 | 3 |
| 8 | F1LV | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 9 | LTLV | 3 | 1 | 0 | 2 | 2 | 1 | 0 | 2 | 2 | 1 | 0 | 2 |
| 10 | LTMD | 1 | 1 | 0 | 1 | 1 | 1 | 0 | 1 | 1 | 1 | 0 | 1 |
| 11 | CTLV | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 1 | 0 | 0 |
| 12 | UBOF | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

Table 1-2

| No. | Item | VIDEO 5-7 | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | 480P | | | | 720P | | | | 1080I | | | |
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild |
| 0 | SYSM | 1 | 1 | 1 | 1 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 |
| 2 | VMCR | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 3 | VMLM | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 4 | VMF0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 5 | VMDL | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 6 | SHF0 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| 7 | PROV | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 8 | F1LV | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 9 | LTLV | 2 | 1 | 0 | 2 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 10 | LTMD | 1 | 1 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 11 | CTLV | 0 | 0 | 0 | 0 | 1 | 1 | 0 | 0 | 1 | 1 | 0 | 0 |
| 12 | UBOF | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

Table 1-3

| No. | Item | MS1, 2 | | | | Twin | | | | VGA |
|---|---|---|---|---|---|---|---|---|---|---|
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | |
| 0 | SYSM | 3 | 3 | 3 | 3 | 2 | 2 | 2 | 2 | 1 |
| 2 | VMCR | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 3 | VMLM | 3 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 4 | VMF0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 5 | VMDL | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 6 | SHF0 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| 7 | PROV | 3 | 3 | 3 | 3 | 2 | 2 | 2 | 2 | 3 |
| 8 | F1LV | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 9 | LTLV | 0 | 0 | 0 | 0 | 2 | 2 | 0 | 0 | 0 |
| 10 | LTMD | 0 | 0 | 0 | 0 | 1 | 1 | 0 | 0 | 0 |
| 11 | CTLV | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 12 | UBOF | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

Table 2

| No. | Item | Vivid | Standard | PRO | Mild |
|---|---|---|---|---|---|
| 14 | VM | 3 | 0 | 0 | 1 |
| 15 | VMH | 15 | 0 | 13 | 13 |
| 16 | VMM | 10 | 0 | 8 | 8 |
| 17 | VML | 6 | 0 | 4 | 4 |

Table 3-1

| No. | Item | other | | | | VIDEO1-4 | | | | VIDEO5,6 | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | | | | | 480I | | | |
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild |
| 13 | MIDE | 7 | 5 | 0 | 2 | 12 | 11 | 8 | 9 | 17 | 16 | 13 | 14 |

Table 3-2

| No. | Item | VIDEO5,6 | | | | VIDEO5,6 | | | | VIDEO5,6 | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | 480P | | | | 720P | | | | 1080I | | | |
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild |
| 13 | MIDE | 22 | 21 | 18 | 19 | 32 | 31 | 28 | 29 | 27 | 26 | 23 | 20 |

Table 3-3

| No. | Item | DVI | | | | DVI | | | | DVI | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | 480I | | | | 480P | | | | 720P | | | |
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild |
| 13 | MIDE | 17 | 16 | 13 | 14 | 22 | 21 | 18 | 19 | 32 | 31 | 28 | 29 |



RM-Y912

Table 3-4

| No. | Item | DVI 1080I | | | | MS1 | | | | MS2 | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild |
| 13 | MIDE | 27 | 26 | 23 | 20 | 27 | 26 | 23 | 20 | 54 | 54 | 54 | 54 |

Table 3-5

| No. | Item | Twin | | | | VGA |
|---|---|---|---|---|---|---|
| | | Vivid | Standard | PRO | Mild | |
| 13 | MIDE | 57 | 56 | 53 | 54 | 1 |

## 2170P-4 (KF-50XBR800)

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | SCOL | | | Table 1 | |
| 1 | SHUE | | | Table 1 | |
| 2 | YCON | | | Table 2 | |
| 3 | SPIC | | | Table 1 | |
| 4 | SPIO | | | 7 | |
| 5 | SCLO | | | 7 | |
| 6 | SHUO | | | 7 | |
| 7 | PIC | | | Table 3 | |
| 8 | BRT | | | Table 3 | |
| 9 | RYR | | | Table 4 | |
| 10 | RYB | | | Table 4 | |
| 11 | GYR | | | Table 4 | |
| 12 | GYB | | | Table 4 | |
| 13 | GAMM | | | Table 5 | |
| 14 | GAMS | | | Table 6 | |
| 15 | GAMR | | | Table 6 | |
| 16 | GAMG | | | Table 6 | |
| 17 | GAMB | | | Table 6 | |
| 18 | BLK | | | Table 5 | |
| 19 | DCTR | | | Table 7 | |
| 20 | APED | | | Table 7 | |
| 21 | DSBO | | | Table 7 | |
| 22 | IDSW | | | 0 | |
| 23 | ABLM | | | Table 7 | |
| 24 | ABLT | | | Table 9 | |
| 25 | SPOF | | | 0 | |
| 26 | DPSQ | | | Table 7 | |
| 27 | LRGB | | | 0 | |
| 28 | RROF | | | Table 8 | |
| 29 | RBOF | | | Table 8 | |
| 30 | GROF | | | Table 8 | |
| 31 | GBOF | | | Table 8 | |

Table 1

| No. | Item | other | Video1-4 | VIDEO5,6 | | DVI | | Twin | MS |
|---|---|---|---|---|---|---|---|---|---|
| | | | | 480i | Others | 480I | Others | | |
| 0 | SCOL | 31 | 31 | 29 | 32 | 30 | 30 | 31 | 31 |
| 1 | SHUE | 31 | 31 | 30 | 30 | 30 | 31 | 31 | 31 |
| 3 | SPIC | 7 | 8 | 11 | 10 | 11 | 10 | 2 | 10 |

Table 2

| No. | Item | MS | Others |
|---|---|---|---|
| 2 | YCON | 0 | 0 |

Table 3

| No. | Item | Vivid | Standard | PRO | Mild |
|---|---|---|---|---|---|
| 7 | PIC | 55 | 55 | 55 | 63 |
| 8 | BRT | 31 | 31 | 31 | 31 |

Table 4

| No. | Item | other | Video1-4 | VIDEO5,6 | | VIDEO5,6 | | DVI | | | | | Twin | MS |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | 480i | 480P | 720P | 1080I | 480i | 480P | 720P | 1080I | VGA | | |
| 9 | RYR | 2 | 10 | 2 | 10 | 4 | 4 | 8 | 8 | 6 | 6 | 8 | 8 | 6 |
| 10 | RYB | 10 | 10 | 10 | 10 | 12 | 12 | 13 | 13 | 13 | 13 | 13 | 13 | 13 |
| 11 | GYR | 8 | 11 | 11 | 12 | 10 | 10 | 11 | 8 | 8 | 8 | 8 | 8 | 8 |
| 12 | GYB | 4 | 3 | 3 | 5 | 5 | 5 | 3 | 2 | 4 | 4 | 2 | 4 | 4 |

Table 5-1

| No. | Item | other | | | | VIDEO1- 4 | | | | VIDEO5,6 480I | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | Vivid | Standard | PRO | Mild | | Standard | PRO | Mild | Vivid | Standard | PRO | Mild |
| 13 | GAMM | 9 | 6 | 6 | 6 | 2 | 2 | 6 | 2 | 6 | 2 | 4 | 2 |
| 18 | BLK | 11 | 12 | 0 | 12 | 5 | 7 | 0 | 7 | 4 | 6 | 0 | 6 |

Table 5-2

| No. | Item | VIDEO5,6 480P | | | | VIDEO5,6 720P | | | | VIDEO5,6 1080I | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild |
| 13 | GAMM | 4 | 2 | 4 | 4 | 8 | 2 | 4 | 2 | 8 | 2 | 4 | 2 |
| 18 | BLK | 8 | 9 | 0 | 10 | 3 | 4 | 0 | 4 | 3 | 4 | 0 | 4 |

Table 5-3

| No. | Item | DVI 480I | | | | DVI 480P | | | | DVI 720P | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild |
| 13 | GAMM | 6 | 2 | 4 | 2 | 4 | 2 | 4 | 4 | 8 | 4 | 4 | 4 |
| 18 | BLK | 4 | 6 | 0 | 6 | 8 | 9 | 0 | 10 | 3 | 2 | 0 | 2 |

Table 5-4

| No. | Item | DVI 1080I | | | | MS | | | | Twin | | | | VGA |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | |
| 13 | GAMM | 8 | 4 | 4 | 4 | 8 | 4 | 4 | 4 | 8 | 4 | 4 | 4 | 0 |
| 18 | BLK | 3 | 2 | 0 | 2 | 3 | 2 | 0 | 2 | 1 | 1 | 0 | 1 | 0 |

Table 6-1

| No. | Item | GAMM | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| | | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
| 14 | GAMS | 7 | 7 | 7 | 7 | 7 | 7 | 7 | 7 |
| 15 | GAMR | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
| 16 | GAMG | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
| 17 | GAMB | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |

Table 6-2

| No. | Item | GAMM | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| | | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 |
| 14 | GAMS | 7 | 7 | 7 | 7 | 7 | 7 | 7 | 7 |
| 15 | GAMR | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 14 |
| 16 | GAMG | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 14 |
| 17 | GAMB | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 14 |

Table 7-1

| No. | Item | BLK | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| | | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
| 19 | DCTR | 0 | 5 | 4 | 8 | 8 | 8 | 5 | 5 |
| 20 | APED | 0 | 1 | 1 | 2 | 1 | 3 | 1 | 2 |
| 21 | DSBO | 7 | 7 | 7 | 7 | 7 | 7 | 7 | 7 |
| 23 | ABLM | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 |
| 26 | DPSQ | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

Table 7-2

| No. | Item | BLK | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| | | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 |
| 19 | DCTR | 8 | 4 | 4 | 8 | 5 | 0 | 0 | 0 |
| 20 | APED | 2 | 1 | 1 | 1 | 1 | 0 | 0 | 0 |
| 21 | DSBO | 7 | 7 | 7 | 7 | 7 | 7 | 7 | 7 |
| 23 | ABLM | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 26 | DPSQ | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

Table 8

| No. | Item | NT/SHIFT | | HD/SHIFT | |
|---|---|---|---|---|---|
| | | Neutral | Warm | Neutral | Warm |
| 28 | RROF | 10 | 15 | 9 | 15 |
| 29 | RBOF | 8 | 9 | 7 | 9 |
| 30 | GROF | 7 | 4 | 7 | 5 |
| 31 | GBOF | 7 | 10 | 7 | 9 |

Table 9

| No. | Item | SINGLE | Others |
|---|---|---|---|
| 24 | ABLT | 0 | 0 |

## 2170D-1 (KF-50XBR800)

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | VPOS | | | 26 | |
| 1 | VSIZ | | | 19 | |
| 2 | VSZO | | | Table 1 | |
| 3 | VLIN | | | Table 2 | |
| 4 | VSCO | | | Table 2 | |
| 5 | VCEN | | | 31 | |
| 6 | VPIN | | | Table 3 | |
| 7 | MVPN | | | 0 | |
| 8 | NSCO | | | 31 | |
| 9 | HTPZ | | | 15 | |
| 10 | MHTZ | | | 0 | |
| 11 | ZOOM | | | Table 4 | |
| 12 | APSW | | | Table 5 | |
| 13 | ASPT | | | Table 5 | |
| 14 | SCRL | | | Table 5 | |
| 15 | UVLN | | | Table 2 | |
| 16 | LVLN | | | Table 2 | |

Table 1

| No. | Item | HD_FULL/VC 1080I | Others |
|---|---|---|---|
| 2 | VSZO | 2 | 0 |

Table 2

| No. | Item | Wide Zoom | Others |
|---|---|---|---|
| 3 | VLIN | 7 | 7 |
| 4 | VSCO | 10 | 10 |
| 15 | UVLN | 4 | 4 |
| 16 | LVLN | 4 | 4 |

Table 3

| No. | Item | Normal | Others |
|---|---|---|---|
| 6 | VPIN | 15 | 15 |

Table 4

| No. | Item | Wide Zoom | Zoom | Others |
|---|---|---|---|---|
| 11 | ZOOM | 0 | 0 | 0 |

Table 5

| No. | Item | Wide Zoom | Zoom | Full | HD_FULL | VC 1080 | Normal |
|---|---|---|---|---|---|---|---|
| 12 | APSW | 1 | 1 | 1 | 0 | 0 | 1 |
| 13 | ASPT | 24 | 47 | 47 | 47 | 47 | 47 |
| 14 | SCRL | 31 | 31 | 31 | 31 | 31 | 31 |

## 2170D-2 (KF-50XBR800)

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | HCNT | | | 31 | |
| 1 | HPOS | | | Table 1 | |
| 2 | HSIZ | | | Table 2 | |
| 3 | SLIN | | | Table 2 | |
| 4 | MPIN | | | Table 2 | |
| 5 | PIN | | | Table 2 | |
| 6 | PINO | | | Table 3 | |
| 7 | UCP | | | Table 2 | |
| 8 | LCP | | | Table 2 | |
| 9 | UXCG | | | 1 | |
| 10 | LXCG | | | 1 | |
| 11 | UXCP | | | 2 | |
| 12 | LXCP | | | 2 | |
| 13 | XCPP | | | 0 | |
| 14 | PPHA | | | Table 2 | |
| 15 | VANG | | | 31 | |
| 16 | LANG | | | 31 | |
| 17 | VBOW | | | 31 | |
| 18 | LBOW | | | 31 | |

Table 1

| No. | Item | HD_FULL/VC_1080I | Others |
|---|---|---|---|
| 1 | HPOS | 35 | 27 |

Table 2

| No. | Item | Wide Zoom | Others |
|---|---|---|---|
| 2 | HSIZ | 49 | 40 |
| 3 | SLIN | 10 | 5 |
| 4 | MPIN | 10 | 7 |
| 5 | PIN | 40 | 35 |
| 7 | UCP | 31 | 35 |
| 8 | LCP | 31 | 35 |
| 14 | PPHA | 20 | 20 |

Table 3

| No. | Item | Wide Zoom | Zoom | HD_FULL | FULL | Normal/VC1080I |
|---|---|---|---|---|---|---|
| 6 | PINO | 7 | 7 | 7 | 7 | 7 |

## 2170D-3 (KF-50XBR800)

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | HBLK | | | 1 | |
| 1 | LBLK | | | Table 1 | |
| 2 | RBLK | | | Table 1 | |
| 3 | VBLK | | | Table 4 | |
| 4 | TBLK | | | Table 2 | |
| 4 | TBLK | | | Table 3 | |
| 5 | BBLK | | | Table 2 | |
| 5 | BBLK | | | Table 3 | |
| 6 | AFCM | | | Table 1 | |
| 7 | JUMP | | | Table 5 | |
| 8 | VDJP | | | Table 6 | |
| 9 | VDST | | | Table 1 | |
| 10 | AKBT | | | Table 6 | |

Table 1

| No. | Item | HD_FULL/VC1080I | Others |
|---|---|---|---|
| 1 | LBLK | 57 | 63 |
| 2 | RBLK | 20 | 20 |
| 6 | AFCM | 2 | 3 |
| 9 | VDST | 1 | 0 |

Table 2

| No. | Item | Wide Zoom | Zoom | Full | HD_FULL | VC 1080 |
|---|---|---|---|---|---|---|
| 4 | TBLK | 7 | 7 | 4 | 4 | 12 |
| 5 | BBLK | 7 | 7 | 8 | 6 | 13 |

Table 3

| No. | Item | Normal |
|---|---|---|
| 4 | TBLK | 8 |
| 5 | BBLK | 13 |

Table 4

| No. | Item | Wide Zoom | Zoom | Full | Normal VC1080I |
|---|---|---|---|---|---|
| 3 | VBLK | 0 | 0 | 1 | 1 |

Table 5

| No. | Item | Normal/VC 1080I | Others |
|---|---|---|---|
| 7 | JUMP | 1 | 1 |

Table 6

| No. | Item | Wide Zoom | Zoom | Full/Normal | HD_Full/ VC1080I |
|---|---|---|---|---|---|
| 8 | VDJP | 1 | 1 | 0 | 1 |
| 10 | AKBT | 15 | 15 | 15 | 10 |

## 2170D-4 (KF-50XBR800)

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | QPAM | | | Table 1 | |
| 1 | QPAV | | | Table 1 | |
| 2 | QPAP | | | Table 1 | |
| 3 | QPDC | | | Table 1 | |
| 4 | QPDV | | | Table 1 | |
| 5 | QPDP | | | Table 1 | |
| 6 | CPY1 | | | 0 | |
| 7 | DF | | | 31 | |
| 8 | DQP | | | 31 | |
| 9 | DHMT | | | 0 | |

Table 1

| No. | Item | Normal/VC 1080I | Others |
|---|---|---|---|
| 0 | QPAM | 17 | 17 |
| 1 | QPAV | 31 | 31 |
| 2 | QPAP | 7 | 7 |
| 3 | QPDC | 20 | 20 |
| 4 | QPDV | 60 | 60 |
| 5 | QPDP | 7 | 5 |

2170D-5 (KF-50XBR800)

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | VFRQ | | | 1 | |
| 1 | VON | | | 1 | |
| 2 | EWDC | | | 0 | |
| 3 | MS15 | | | 0 | |
| 4 | HFRQ | | | Table 1 | |
| 5 | HFRX | | | Table 1 | |
| 6 | VMPS | | | Table 1 | |
| 7 | INTR | | | Table 1 | |
| 8 | VLNL | | | Table 1 | |
| 9 | VLNH | | | Table 1 | |
| 10 | AGCS | | | 0 | |

Table 1

| No. | Item | Single 720P/1080I | Others |
|---|---|---|---|
| 4 | HFRQ | 80 | 90 |
| 5 | HFRX | 38 | 41 |
| 6 | VMPS | 0 | 0 |
| 7 | INTR | 0 | 1 |
| 8 | VLNL | 1 | 2 |
| 9 | VLNH | 70 | 62 |

2170P-1 (KF-60XBR800)

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | RDRV | | | Table 1 | |
| 1 | GDRV | | | Table 1 | |
| 2 | BDRV | | | Table 1 | |
| 3 | RCUT | | | Table 1 | |
| 4 | GCUT | | | Table 1 | |
| 5 | BCUT | | | Table 1 | |
| 6 | YOSW | | | Table 2 | |
| 7 | TCOF | | | 0 | |
| 8 | YOF | | | Table 2 | |
| 9 | CBOF | | | Table 1 | |
| 10 | CROF | | | Table 1 | |
| 11 | SBRT | | | 31 | |
| 12 | WBSW | | | 0 | |
| 13 | DCOL | | | Table 3 | |

Table 1

| No. | Item | other | | VIDEO 1-4 | | VIDEO 5-7 | | | | | Twin | MS |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | 480I | | 480P,VGA | 720P | 1080I | | |
| | | NOT Mild | Mild | NOT Mild | Mild | NOT Mild | Mild | | | | | |
| 0 | RDRV | 45 | 45 | 45 | 45 | 45 | 45 | 45 | 45 | 45 | 45 | 45 |
| 1 | GDRV | 45 | 45 | 45 | 45 | 45 | 45 | 45 | 45 | 45 | 45 | 45 |
| 2 | BDRV | 45 | 45 | 45 | 45 | 45 | 45 | 45 | 45 | 45 | 45 | 45 |
| 3 | RCUT | 31 | 31 | 31 | 31 | 31 | 31 | 31 | 31 | 31 | 31 | 31 |
| 4 | GCUT | 28 | 28 | 28 | 28 | 28 | 28 | 28 | 28 | 28 | 28 | 28 |
| 5 | BCUT | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 |
| 9 | CBOF | 33 | 33 | 33 | 33 | 33 | 33 | 40 | 38 | 37 | 33 | 33 |
| 10 | CROF | 32 | 32 | 32 | 32 | 32 | 32 | 39 | 38 | 37 | 32 | 32 |

Table 2

| No. | Item | RF/V1-V4 | DVI | OTHER |
|---|---|---|---|---|
| 6 | YOSW | 1 | 1 | 0 |
| 8 | YOF | 0 | 0 | 7 |

Table 3

| No. | Item | COOL | NEUTRAL | WARM |
|---|---|---|---|---|
| 13 | DCOL | 3 | 0 | 0 |

2170P-2 (KF-60XBR800)

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | UPCG | | | Table 1 | |
| 1 | UBRG | | | Table 1 | |
| 2 | UCOL | | | Table 1 | |
| 3 | UHUE | | | Table 1 | |
| 4 | USHP | | | Table 1 | |
| 5 | UTMP | | | Table 1 | |
| 6 | UPOG | | | Table 2 | |
| 7 | UBOG | | | Table 2 | |
| 8 | UCOF | | | Table 2 | |
| 9 | UHOF | | | Table 2 | |
| 10 | SHOF | | | Table 2 | |
| 11 | PICO | | | Table 3 | |
| 12 | RGBS | | | Table 3 | |
| 13 | BLKB | | | 3 | |
| 14 | RGBL | | | 0 | |
| 15 | YLMT | | | 3 | |
| 16 | AGNG | | | Table 4 | |
| 17 | AKBO | | | 0 | |
| 18 | CLPP | | | 3 | |
| 19 | CLPG | | | 0 | |
| 20 | CLPS | | | 0 | |
| 21 | PPAD | | | 3 | |
| 22 | SYNP | | | 0 | |
| 23 | HVBT | | | 0 | |

Table 1

| No. | Item | Vivid | Standard | PRO | Mild |
|---|---|---|---|---|---|
| 0 | UPCG | 63 | 55 | 31 | 43 |
| 1 | UBRG | 27 | 31 | 31 | 31 |
| 2 | UCOL | 35 | 31 | 31 | 31 |
| 3 | UHUE | 31 | 31 | 31 | 31 |
| 4 | USHP | 35 | 33 | 31 | 25 |
| 5 | UTMP | 2 | 1 | 1 | 1 |

Table 2-1

| No. | Item | RF | | | | Video | | | | Component | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | | | | | 480i | | | |
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild |
| 6 | UPOG | 31 | 31 | 38 | 36 | 31 | 33 | 38 | 36 | 31 | 31 | 38 | 36 |
| 7 | UBOG | 33 | 32 | 19 | 33 | 34 | 31 | 18 | 31 | 32 | 33 | 31 | 33 |
| 8 | UCOF | 31 | 31 | 31 | 32 | 32 | 32 | 31 | 32 | 31 | 31 | 31 | 29 |
| 9 | UHOF | 31 | 31 | 31 | 31 | 31 | 31 | 31 | 31 | 31 | 31 | 31 | 31 |
| 10 | SHOF | 27 | 30 | 31 | 37 | 26 | 27 | 31 | 35 | 24 | 26 | 31 | 37 |

Table 2-2

| No. | Item | Component | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | 480p | | | | 720p | | | | 1080i | | | |
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild |
| 6 | UPOG | 31 | 34 | 38 | 32 | 31 | 31 | 38 | 33 | 31 | 31 | 38 | 33 |
| 7 | UBOG | 33 | 32 | 30 | 31 | 22 | 31 | 31 | 31 | 22 | 31 | 31 | 31 |
| 8 | UCOF | 31 | 31 | 31 | 31 | 30 | 28 | 31 | 28 | 30 | 28 | 31 | 28 |
| 9 | UHOF | 32 | 31 | 31 | 31 | 32 | 33 | 31 | 33 | 32 | 33 | 31 | 33 |
| 10 | SHOF | 31 | 33 | 29 | 31 | 29 | 33 | 31 | 34 | 29 | 33 | 31 | 34 |

Table 2-3

| No. | Item | Twin | | | | MS1,2 | | | | VGA |
|---|---|---|---|---|---|---|---|---|---|---|
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | |
| 6 | UPOG | 31 | 31 | 38 | 31 | 31 | 31 | 38 | 33 | 31 |
| 7 | UBOG | 36 | 31 | 29 | 31 | 22 | 31 | 31 | 31 | 31 |
| 8 | UCOF | 26 | 29 | 31 | 28 | 30 | 28 | 31 | 28 | 31 |
| 9 | UHOF | 31 | 31 | 31 | 31 | 32 | 33 | 31 | 33 | 31 |
| 10 | SHOF | 31 | 37 | 31 | 24 | 29 | 33 | 31 | 34 | 31 |

Table 3

| No. | Item | Blanking | | Power OFF |
|---|---|---|---|---|
| | | ON | OFF | |
| 11 | PICO | 1 | 1 | 0 |
| 12 | RGBS | 0 | 7 | 0 |

Table 4

| No. | Item | AGING | |
|---|---|---|---|
| | | ON | OFF |
| 16 | AGNG | 2 | 0 |

2170P-3 (KF-60XBR800)

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | SYSM | | | Table 1 | |
| 1 | VMLV | | | 7 | |
| 2 | VMCR | | | Table 1 | |
| 3 | VMLM | | | Table 1 | |
| 4 | VMF0 | | | Table 1 | |
| 5 | VMDL | | | Table 1 | |
| 6 | SHF0 | | | Table 1 | |
| 7 | PROV | | | Table 1 | |
| 8 | F1LV | | | Table 1 | |
| 9 | LTLV | | | Table 1 | |
| 10 | LTMD | | | Table 1 | |
| 11 | CTLV | | | Table 1 | |
| 12 | UBOF | | | Table 1 | |
| 13 | MIDE | | | Table 3 | |
| 14 | VM | | | Table 2 | |
| 15 | VMH | | | Table 2 | |
| 16 | VMM | | | Table 2 | |
| 17 | VML | | | Table 2 | |
| 18 | VGAP | | | 5 | |
| 19 | VGAS | | | 0 | |
| 20 | VGAB | | | 0 | |
| 21 | VGAC | | | 0 | |
| 22 | VGAV | | | 5 | |

Table 1-1

| No. | Item | RF | | | | VIDEO 1-4 | | | | VIDEO 5-7 480I | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild |
| 0 | SYSM | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| 2 | VMCR | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 3 | VMLM | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 4 | VMF0 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 5 | VMDL | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 6 | SHF0 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| 7 | PROV | 3 | 3 | 3 | 3 | 0 | 0 | 0 | 0 | 3 | 3 | 3 | 3 |
| 8 | F1LV | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 9 | LTLV | 3 | 1 | 0 | 2 | 2 | 1 | 0 | 2 | 2 | 1 | 0 | 2 |
| 10 | LTMD | 1 | 1 | 0 | 1 | 1 | 1 | 0 | 1 | 1 | 1 | 0 | 1 |
| 11 | CTLV | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 1 | 0 | 0 |
| 12 | UBOF | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

Table 1-2

| No. | Item | VIDEO 5-7 | | | | | | | | MS 1, 2 | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | 720P | | | | 1080I | | | | | | | |
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild |
| 0 | SYSM | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 |
| 2 | VMCR | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 3 | VMLM | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 3 | 0 | 0 | 0 |
| 4 | VMF0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 5 | VMDL | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 6 | SHF0 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| 7 | PROV | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 3 | 3 | 3 | 3 |
| 8 | F1LV | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 9 | LTLV | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 10 | LTMD | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 11 | CTLV | 1 | 1 | 0 | 0 | 1 | 1 | 0 | 0 | 0 | 0 | 0 | 0 |
| 12 | UBOF | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

Table 1-3

| No. | Item | Twin | | | | VGA |
|---|---|---|---|---|---|---|
| | | Vivid | Standard | PRO | Mild | |
| 0 | SYSM | 2 | 2 | 2 | 2 | 1 |
| 2 | VMCR | 0 | 0 | 0 | 0 | 0 |
| 3 | VMLM | 0 | 0 | 0 | 0 | 0 |
| 4 | VMF0 | 0 | 0 | 0 | 0 | 0 |
| 5 | VMDL | 0 | 0 | 0 | 0 | 0 |
| 6 | SHF0 | 1 | 1 | 1 | 1 | 1 |
| 7 | PROV | 2 | 2 | 2 | 2 | 3 |
| 8 | F1LV | 0 | 0 | 0 | 0 | 0 |
| 9 | LTLV | 2 | 2 | 0 | 0 | 0 |
| 10 | LTMD | 1 | 1 | 0 | 0 | 0 |
| 11 | CTLV | 0 | 0 | 0 | 0 | 0 |
| 12 | UBOF | 0 | 0 | 0 | 0 | 0 |

Table 2

| No. | Item | Vivid | Standard | PRO | Mild |
|---|---|---|---|---|---|
| 14 | VM | 3 | 0 | 0 | 1 |
| 15 | VMH | 15 | 0 | 13 | 13 |
| 16 | VMM | 10 | 0 | 8 | 8 |
| 17 | VML | 6 | 0 | 4 | 4 |

Table 3-1

| No. | Item | other | | | | VIDEO1-4 | | | | VIDEO5,6 480I | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild |
| 13 | MIDE | 7 | 5 | 0 | 2 | 12 | 11 | 8 | 9 | 17 | 16 | 13 | 14 |

Table 3-2

| No. | Item | VIDEO5,6 480P | | | | VIDEO5,6 720P | | | | VIDEO5,6 1080I | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild |
| 13 | MIDE | 22 | 21 | 18 | 19 | 32 | 31 | 28 | 29 | 27 | 26 | 23 | 20 |

Table 3-3

| No. | Item | DVI 480I | | | | 480P | | | | 720P | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild |
| 13 | MIDE | 17 | 16 | 13 | 14 | 22 | 21 | 18 | 19 | 32 | 31 | 28 | 29 |

Table 3-4

| No. | Item | DVI 1080I | | | | MS1 | | | | MS2 | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild |
| 13 | MIDE | 27 | 26 | 23 | 20 | 27 | 26 | 23 | 20 | 54 | 54 | 54 | 54 |

Table 3-5

| No. | Item | Twin | | | | VGA |
|---|---|---|---|---|---|---|
| | | Vivid | Standard | PRO | Mild | |
| 13 | MIDE | 57 | 56 | 53 | 54 | 1 |

2170P-4 (KF-60XBR800)

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | SCOL | | | Table 1 | |
| 1 | SHUE | | | Table 1 | |
| 2 | YCON | | | Table 2 | |
| 3 | SPIC | | | Table 1 | |
| 4 | SPIO | | | 7 | |
| 5 | SCLO | | | 7 | |
| 6 | SHUO | | | 7 | |
| 7 | PIC | | | Table 3 | |
| 8 | BRT | | | Table 3 | |
| 9 | RYR | | | Table 4 | |
| 10 | RYB | | | Table 4 | |
| 11 | GYR | | | Table 4 | |
| 12 | GYB | | | Table 4 | |
| 13 | GAMM | | | Table 5 | |
| 14 | GAMS | | | Table 6 | |
| 15 | GAMR | | | Table 6 | |
| 16 | GAMG | | | Table 6 | |
| 17 | GAMB | | | Table 6 | |
| 18 | BLK | | | Table 5 | |
| 19 | DCTR | | | Table 7 | |
| 20 | APED | | | Table 7 | |
| 21 | DSBO | | | Table 7 | |
| 22 | IDSW | | | 0 | |
| 23 | ABLM | | | Table 7 | |
| 24 | ABLT | | | Table 9 | |
| 25 | SPOF | | | 0 | |
| 26 | DPSQ | | | Table 7 | |
| 27 | LRGB | | | 0 | |
| 28 | RROF | | | Table 8 | |
| 29 | RBOF | | | Table 8 | |
| 30 | GROF | | | Table 8 | |
| 31 | GBOF | | | Table 8 | |

Table 1

| No. | Item | other | Video1-4 | VIDEO5,6 | | DVI | | Twin | MS |
|---|---|---|---|---|---|---|---|---|---|
| | | | | 480i | Others | 480I | Others | | |
| 0 | SCOL | 31 | 31 | 29 | 32 | 30 | 30 | 31 | 31 |
| 1 | SHUE | 31 | 31 | 30 | 30 | 30 | 31 | 31 | 31 |
| 3 | SPIC | 7 | 8 | 11 | 10 | 11 | 10 | 2 | 10 |

Table 2

| No. | Item | MS | Others |
|---|---|---|---|
| 2 | YCON | 0 | 0 |

Table 3

| No. | Item | Vivid | Standard | PRO | Mild |
|---|---|---|---|---|---|
| 7 | PIC | 55 | 55 | 55 | 63 |
| 8 | BRT | 31 | 31 | 31 | 31 |

Table 4

| No. | Item | other | Video1-4 | VIDEO5,6 | | | | DVI | | | | DVI | Twin | MS |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | 480i | 480P | 720P | 1080I | 480i | 480P | 720P | 1080I | VGA | | |
| 9 | RYR | 10 | 10 | 10 | 10 | 6 | 6 | 8 | 8 | 6 | 6 | 8 | 8 | 6 |
| 10 | RYB | 13 | 13 | 13 | 13 | 13 | 13 | 13 | 13 | 13 | 13 | 13 | 13 | 13 |
| 11 | GYR | 8 | 11 | 11 | 8 | 8 | 8 | 11 | 8 | 8 | 8 | 8 | 8 | 8 |
| 12 | GYB | 4 | 3 | 3 | 2 | 4 | 4 | 3 | 2 | 4 | 4 | 2 | 4 | 4 |

Table 5-1

| No. | Item | other | | | | VIDEO1-4 | | | | VIDEO5,6 480I | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | Vivid | Standard | PRO | Mild | | Standard | PRO | Mild | Vivid | Standard | PRO | Mild |
| 13 | GAMM | 7 | 6 | 6 | 6 | 2 | 0 | 6 | 0 | 4 | 0 | 4 | 0 |
| 18 | BLK | 11 | 12 | 0 | 12 | 5 | 7 | 0 | 7 | 4 | 6 | 0 | 6 |

Table 5-2

| No. | Item | VIDEO5,6 | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | 480P | | | | 720P | | | | 1080I | | | |
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild |
| 13 | GAMM | 4 | 2 | 4 | 4 | 8 | 2 | 4 | 2 | 8 | 2 | 4 | 2 |
| 18 | BLK | 8 | 9 | 0 | 10 | 3 | 2 | 0 | 2 | 3 | 2 | 0 | 2 |

Table 5-3

| No. | Item | DVI | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | 480I | | | | 480P | | | | 720P | | | |
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild |
| 13 | GAMM | 4 | 0 | 4 | 0 | 4 | 2 | 4 | 4 | 8 | 2 | 4 | 2 |
| 18 | BLK | 4 | 6 | 0 | 6 | 8 | 9 | 0 | 10 | 3 | 2 | 0 | 2 |

Table 5-4

| No. | Item | DVI 1080I | | | | MS | | | | Twin | | | | VGA |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | |
| 13 | GAMM | 8 | 2 | 4 | 2 | 8 | 2 | 4 | 2 | 8 | 4 | 4 | 4 | 0 |
| 18 | BLK | 3 | 2 | 0 | 2 | 3 | 2 | 0 | 2 | 1 | 1 | 0 | 1 | 0 |

Table 6-1

| No. | Item | GAMM | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| | | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
| 14 | GAMS | 7 | 7 | 7 | 7 | 7 | 7 | 7 | 7 |
| 15 | GAMR | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
| 16 | GAMG | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
| 17 | GAMB | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |

Table 6-2

| No. | Item | GAMM | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| | | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 |
| 14 | GAMS | 7 | 7 | 7 | 7 | 7 | 7 | 7 | 7 |
| 15 | GAMR | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 14 |
| 16 | GAMG | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 14 |
| 17 | GAMB | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 14 |

Table 7-1

| No. | Item | BLK | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| | | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
| 19 | DCTR | 0 | 5 | 4 | 8 | 8 | 8 | 5 | 5 |
| 20 | APED | 0 | 1 | 1 | 2 | 1 | 3 | 1 | 2 |
| 21 | DSBO | 7 | 7 | 7 | 7 | 7 | 7 | 7 | 7 |
| 23 | ABLM | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 |
| 26 | DPSQ | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

Table 7-2

| No. | Item | BLK | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| | | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 |
| 19 | DCTR | 8 | 4 | 4 | 8 | 5 | 0 | 0 | 0 |
| 20 | APED | 2 | 1 | 1 | 1 | 1 | 0 | 0 | 0 |
| 21 | DSBO | 7 | 7 | 7 | 7 | 7 | 7 | 7 | 7 |
| 23 | ABLM | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 26 | DPSQ | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

Table 8

| No. | Item | NT/SHIFT | | HD/SHIFT | |
|---|---|---|---|---|---|
| | | Neutral | Warm | Neutral | Warm |
| 28 | RROF | 10 | 15 | 9 | 15 |
| 29 | RBOF | 8 | 9 | 7 | 9 |
| 30 | GROF | 7 | 4 | 7 | 5 |
| 31 | GBOF | 7 | 10 | 7 | 9 |

Table 9

| No. | Item | SINGLE | Others |
|---|---|---|---|
| 24 | ABLT | 0 | 0 |

2170D-1 (KF-60XBR800)

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | VPOS | | | 26 | |
| 1 | VSIZ | | | 19 | |
| 2 | VSZO | | | Table 1 | |
| 3 | VLIN | | | Table 2 | |
| 4 | VSCO | | | Table 2 | |
| 5 | VCEN | | | 31 | |
| 6 | VPIN | | | Table 3 | |
| 7 | MVPN | | | 0 | |
| 8 | NSCO | | | 31 | |
| 9 | HTPZ | | | 15 | |
| 10 | MHTZ | | | 0 | |
| 11 | ZOOM | | | Table 4 | |
| 12 | APSW | | | Table 5 | |
| 13 | ASPT | | | Table 5 | |
| 14 | SCRL | | | Table 5 | |
| 15 | UVLN | | | Table 2 | |
| 16 | LVLN | | | Table 2 | |

Table 1

| No. | Item | HD_FULL/VC 1080I | Others |
|---|---|---|---|
| 2 | VSZO | 2 | 0 |

Table 2

| No. | Item | Wide Zoom | Others |
|---|---|---|---|
| 3 | VLIN | 7 | 7 |
| 4 | VSCO | 10 | 10 |
| 15 | UVLN | 4 | 4 |
| 16 | LVLN | 4 | 4 |

Table 3

| No. | Item | Normal | Others |
|---|---|---|---|
| 6 | VPIN | 15 | 15 |

Table 4

| No. | Item | Wide Zoom | Zoom | Others |
|---|---|---|---|---|
| 11 | ZOOM | 0 | 0 | 0 |

Table 5

| No. | Item | Wide Zoom | Zoom | Full | HD_FULL | VC 1080 | Normal |
|---|---|---|---|---|---|---|---|
| 12 | APSW | 1 | 1 | 1 | 0 | 0 | 1 |
| 13 | ASPT | 24 | 47 | 47 | 47 | 47 | 47 |
| 14 | SCRL | 31 | 31 | 31 | 31 | 31 | 31 |

2170D-2 (KF-60XBR800)

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | HCNT | | | 31 | |
| 1 | HPOS | | | Table 1 | |
| 2 | HSIZ | | | Table 2 | |
| 3 | SLIN | | | Table 2 | |
| 4 | MPIN | | | Table 2 | |
| 5 | PIN | | | Table 2 | |
| 6 | PINO | | | Table 3 | |
| 7 | UCP | | | Table 2 | |
| 8 | LCP | | | Table 2 | |
| 9 | UXCG | | | 1 | |
| 10 | LXCG | | | 1 | |
| 11 | UXCP | | | 2 | |
| 12 | LXCP | | | 2 | |
| 13 | XCPP | | | 0 | |
| 14 | PPHA | | | Table 2 | |
| 15 | VANG | | | 31 | |
| 16 | LANG | | | 31 | |
| 17 | VBOW | | | 31 | |
| 18 | LBOW | | | 31 | |

Table 1

| No. | Item | HD_FULL/VC_1080I | Others |
|---|---|---|---|
| 1 | HPOS | 35 | 27 |

Table 2

| No. | Item | Wide Zoom | Others |
|---|---|---|---|
| 2 | HSIZ | 49 | 40 |
| 3 | SLIN | 10 | 5 |
| 4 | MPIN | 10 | 7 |
| 5 | PIN | 40 | 35 |
| 7 | UCP | 31 | 35 |
| 8 | LCP | 31 | 35 |
| 14 | PPHA | 20 | 20 |

Table 3

| No. | Item | Wide Zoom | Zoom | HD_FULL | FULL | Normal/VC1080I |
|---|---|---|---|---|---|---|
| 6 | PINO | 7 | 7 | 7 | 7 | 7 |

2170D-3 (KF-60XBR800)

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | HBLK | | | 1 | |
| 1 | LBLK | | | Table 1 | |
| 2 | RBLK | | | Table 1 | |
| 3 | VBLK | | | Table 3 | |
| 4 | TBLK | | | Table 2 | |
| 5 | BBLK | | | Table 2 | |
| 6 | AFCM | | | Table 1 | |
| 7 | JUMP | | | Table 4 | |
| 8 | VDJP | | | Table 5 | |
| 9 | VDST | | | Table 1 | |
| 10 | AKBT | | | Table 5 | |

Table 1

| No. | Item | HD_FULL/VC1080I | Others |
|---|---|---|---|
| 1 | LBLK | 57 | 63 |
| 2 | RBLK | 20 | 20 |
| 6 | AFCM | 2 | 3 |
| 9 | VDST | 1 | 0 |

Table 2

| No. | Item | Wide Zoom | Zoom | Full | HD_FULL | VC 1080 | Normal |
|---|---|---|---|---|---|---|---|
| 4 | TBLK | 7 | 7 | 4 | 4 | 12 | 8 |
| 5 | BBLK | 7 | 7 | 8 | 6 | 13 | 13 |

Table 3

| No. | Item | Wide Zoom | Zoom | Full | Normal VC1080I |
|---|---|---|---|---|---|
| 3 | VBLK | 0 | 0 | 1 | 1 |

Table 4

| No. | Item | Normal/VC 1080I | Others |
|---|---|---|---|
| 7 | JUMP | 1 | 1 |

Table 5

| No. | Item | Wide Zoom | Zoom | Full/Normal | HD_Full/ VC1080I |
|---|---|---|---|---|---|
| 8 | VDJP | 1 | 1 | 0 | 1 |
| 10 | AKBT | 15 | 15 | 15 | 10 |

## 2170D-4 (KF-60XBR800)

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | QPAM | | | Table 1 | |
| 1 | QPAV | | | Table 1 | |
| 2 | QPAP | | | Table 1 | |
| 3 | QPDC | | | Table 1 | |
| 4 | QPDV | | | Table 1 | |
| 5 | QPDP | | | Table 1 | |
| 6 | CPY1 | | | 0 | |
| 7 | DF | | | 31 | |
| 8 | DQP | | | 31 | |
| 9 | DHMT | | | 0 | |

Table 1

| No. | Item | Normal/VC 1080I | Others |
|---|---|---|---|
| 0 | QPAM | 17 | 17 |
| 1 | QPAV | 31 | 31 |
| 2 | QPAP | 7 | 7 |
| 3 | QPDC | 20 | 20 |
| 4 | QPDV | 60 | 60 |
| 5 | QPDP | 7 | 5 |



## 2170D-5 (KF-60XBR800)

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | VFRQ | | | 1 | |
| 1 | VON | | | 1 | |
| 2 | EWDC | | | 0 | |
| 3 | MS15 | | | 0 | |
| 4 | HFRQ | | | Table 1 | |
| 5 | HFRX | | | Table 1 | |
| 6 | VMPS | | | Table 1 | |
| 7 | INTR | | | Table 1 | |
| 8 | VLNL | | | Table 1 | |
| 9 | VLNH | | | Table 1 | |
| 10 | AGCS | | | 0 | |

Table 1

| No. | Item | Single 720P/1080I | Others |
|---|---|---|---|
| 4 | HFRQ | 80 | 90 |
| 5 | HFRX | 38 | 41 |
| 6 | VMPS | 0 | 0 |
| 7 | INTR | 0 | 1 |
| 8 | VLNL | 1 | 2 |
| 9 | VLNH | 70 | 62 |

## MID1 COM

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | DHPH | | | Table 1 | |
| 1 | DVPH | | | Table 1 | |
| 2 | DHAR | | | Table 1 | |
| 3 | DVAR | | | Table 1 | |
| 4 | DHPW | | | Table 1 | |
| 5 | DVPW | | | Table 1 | |
| 6 | DYCD | | | Table 2 | |
| 7 | DYSD | | | Table 3 | |
| 8 | MDHP | | | Table 4 | |
| 9 | MDVP | | | Table 5 | |
| 10 | MDHS | | | Table 4 | |
| 11 | MDVS | | | Table 5 | |
| 12 | MLHP | | | Table 6 | |
| 13 | MLVP | | | Table 6 | |
| 14 | SDHP | | | Table 7 | |
| 15 | SDVP | | | Table 7 | |
| 16 | SDHS | | | Table 7 | |
| 17 | SDVS | | | Table 7 | |
| 18 | PDHP | | | Table 8 | |
| 19 | PDVP | | | Table 8 | |
| 20 | PDHS | | | Table 8 | |
| 21 | PDVS | | | Table 8 | |
| 22 | DPSW | | | Table 9 | |
| 23 | MDL0 | | | Table 10 | |
| 24 | BCOL | | | Table 11 | |
| 25 | DYSS | | | Table 12 | |
| 26 | OSDH | | | Table 12 | |
| 27 | OSDV | | | Table 12 | |

Table 1

| No. | Item | 1920 | 1440/1840 |
|---|---|---|---|
| 0 | DHPH | 111 | 119 |
| 1 | DVPH | 21 | 17 |
| 2 | DHAR | 240 | 230 |
| 3 | DVAR | 135 | 120 |
| 4 | DHPW | 55 | 59 |
| 5 | DVPW | 5 | 5 |

Table 2

| No. | Item | Single | | Twin | Freeze | Favorite | INDEX |
|---|---|---|---|---|---|---|---|
| | | 480I | Other | | | | |
| 6 | DYCD | 2 | 0 | 1 | 0 | 0 | 0 |

Table 3

| No. | Item | 1920 | | | | 1840 | | | |
|---|---|---|---|---|---|---|---|---|---|
| | | Table-0 | Table-1 | Table-2 | Table-3 | Table-0 | Table-1 | Table-2 | Table-3 |
| 7 | DYSD | 7 | 4 | 2 | 1 | 7 | 4 | 2 | 1 |

Table 4

| No. | Item | Single | | | | | Favorite | INDEX |
|---|---|---|---|---|---|---|---|---|
| | | 1920 | | | 1840 | | | |
| | | VGA | | Other | | | | |
| | | Side Panel | Other | | Side Panel | Other | Side Panel | Window-SP |
| 8 | MDHP | 156 | 0 | 0 | 137 | 0 | 17 | 0 |
| 10 | MDHS | 162 | 240 | 240 | 163 | 230 | 167 | 168 |

Table 5

| No. | Item | Single | | | FAVORITE | INDEX |
|---|---|---|---|---|---|---|
| | | 480I/480P Other | VGA | Other | VGA | VGA |
| 9 | MDVP | 0 | 0 | 0 | 16 | 0 |
| 11 | MDVS | 120 | 120 | 135 | 111 | 116 |

Table 6

| No. | Item | Twin/Freeze | Favorite | INDEX |
|---|---|---|---|---|
| 12 | MLHP | 15 | 0 | 19 |
| 13 | MLVP | 1 | 0 | 8 |

Table 7

| No. | Item | Favorite |
|---|---|---|
| 14 | SDHP | 174 |
| 15 | SDVP | 8 |
| 16 | SDHS | 104 |
| 17 | SDVS | 70 |

Table 8

| No. | Item | case nothing |
|---|---|---|
| 18 | PDHP | 99 |
| 19 | PDVP | 55 |
| 20 | PDHS | 117 |
| 21 | PDVS | 60 |

Table 9

| No. | Item | Single | | Other |
|---|---|---|---|---|
| | | 1080I | Other | |
| 22 | DPSW | 0 | 0 | ← |

Table 10

| No. | Item | case nothing |
|---|---|---|
| 23 | MDL0 | 12 |

Table 11

| No. | Item | Single | | MS | Other |
|---|---|---|---|---|---|
| | | Side Panel | Other | | |
| 24 | BCOL | 1 | 1 | 1 | 0 |

Table 12

| No. | Item | case nothing |
|---|---|---|
| 25 | DYSS | 1 |
| 26 | OSDH | 39 |
| 27 | OSDV | 16 |

## MID2 DRC

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | DRHP | | | Table 1 | |
| 1 | DRHS | | | Table 1 | |
| 2 | DRVP | | | Table 1 | |
| 3 | DRVS | | | Table 1 | |

Table 1-1

| No. | Item | Single | | | | | | Twin-Left | | | Twin-Right |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | 480I | | YC | | DVI | | 480I | YC | DVI | YC |
| | | Side Panel | Others | Side Panel | Others | Side Panel | Others | | | Others | |
| 0 | DRHP | 153 | 129 | 154 | 130 | 157 | 134 | 135 | 138 | 145 | 151 |
| 1 | DRHS | 164 | 174 | 164 | 174 | 165 | 175 | 168 | 168 | 168 | 168 |
| 2 | DRVP | 37 | 37 | 37 | 37 | 37 | 37 | 55 | 55 | 55 | 55 |
| 3 | DRVS | 120 | 120 | 120 | 120 | 120 | 120 | 111 | 111 | 111 | 111 |

Table 1-2

| No. | Item | Freeze | | | Favorite-Main | | | | | | Favorite-Sub |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | 480I | YC | DVI | 480I | | YC | | DVI | | YC |
| | | | | | DSP-4:3 | DSP-16:9 | DSP-4:3 | DSP-16:9 | DSP-4:3 | DSP-16:9 | |
| 0 | DRHP | 149 | 150 | 156 | 133 | 137 | 136 | 136 | 143 | 131 | 144 |
| 1 | DRHS | 164 | 164 | 164 | 168 | 165 | 168 | 168 | 168 | 165 | 167 |
| 2 | DRVP | 55 | 55 | 55 | 55 | 57 | 55 | 54 | 55 | 37 | 55 |
| 3 | DRVS | 111 | 111 | 111 | 111 | 110 | 111 | 111 | 111 | 120 | 111 |

Table 1-3

| No. | Item | INDEX-Main | | | | | | INDEX-Sub |
|---|---|---|---|---|---|---|---|---|
| | | 480I | | YC | | DVI | | YC |
| | | DSP-4:3 | DSP-16:9 | DSP-4:3 | DSP-16:9 | DSP-4:3 | DSP-16:9 | |
| 0 | DRHP | 135 | 138 | 138 | 138 | 145 | 131 | 144 |
| 1 | DRHS | 168 | 165 | 168 | 168 | 168 | 165 | 167 |
| 2 | DRVP | 46 | 57 | 46 | 55 | 46 | 57 | 55 |
| 3 | DRVS | 116 | 110 | 116 | 111 | 116 | 110 | 111 |

## MID3 VDO

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | VDHP | | | Table 1 | |
| 1 | VDHS | | | Table 1 | |
| 2 | VDVE | | | Table 1 | |
| 3 | VDVS | | | Table 1 | |
| 4 | VDVO | | | Table 2 | |
| 5 | VCPO | | | Table 2 | |
| 6 | VCWD | | | Table 2 | |
| 7 | VYCD | | | Table 2 | |
| 8 | VSTP | | | Table 2 | |
| 9 | VSTT | | | Table 2 | |
| 10 | VHSC | | | Table 2 | |
| 11 | VFRV | | | Table 2 | |

Table 1-1

| No. | Item | Single | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | 1080I | 720P | 480P | | 480I | | VGA | | DVI 1080I | DVI 720P | DVI 480P | |
| | | | | Side Panel | Others | Side Panel | Others | Side Panel | Others | | | Side Panel | Others |
| 0 | VDHP | 107 | 139 | 189 | 157 | 77 | 65 | 185 | 153 | 103 | 145 | 185 | 154 |
| 1 | VDHS | 240 | 160 | 222 | 236 | 164 | 174 | 221 | 235 | 240 | 160 | 222 | 236 |
| 2 | VDVE | 21 | 24 | 37 | 37 | 17 | 17 | 26 | 26 | 19 | 24 | 38 | 37 |
| 3 | VDVS | 135 | 180 | 120 | 120 | 60 | 60 | 125 | 125 | 135 | 180 | 120 | 120 |

Table 1-2

| No. | Item | Single | | Twin-Left | | | | | | | Twin-Right | Freeze | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | DVI 480I | | 1080I | 720P | 480P | VGA | DVI 1080I | DVI 720P | DVI 480P | YC | 1080I | 720P |
| | | Side Panel | Others | | | | | | | | | | |
| 0 | VDHP | 79 | 67 | 124 | 150 | 170 | 163 | 122 | 158 | 170 | 73 | 141 | 163 |
| 1 | VDHS | 165 | 175 | 226 | 151 | 225 | 226 | 226 | 151 | 225 | 169 | 222 | 147 |
| 2 | VDVE | 17 | 17 | 41 | 54 | 57 | 42 | 41 | 54 | 57 | 27 | 43 | 54 |
| 3 | VDVS | 60 | 60 | 124 | 165 | 110 | 116 | 124 | 165 | 110 | 55 | 123 | 165 |

Table 1-3

| No. | Item | Freeze | | | | | | | Favorite-Main | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | 480P | 480I | VGA | DVI 1080I | DVI 720P | DVI 480P | DVI 480I | 1080I | 720P | 480P | |
| | | | | | | | | | | | DSP-4:3 | DSP-16:9 |
| 0 | VDHP | 193 | 74 | 186 | 133 | 167 | 186 | 77 | 116 | 146 | 164 | 161 |
| 1 | VDHS | 219 | 165 | 220 | 222 | 147 | 219 | 165 | 228 | 152 | 228 | 229 |
| 2 | VDVE | 57 | 28 | 42 | 43 | 54 | 57 | 27 | 41 | 54 | 55 | 53 |
| 3 | VDVS | 110 | 55 | 116 | 123 | 165 | 110 | 55 | 124 | 165 | 111 | 111 |

Table 1-4

| No. | Item | Favorite-Main | | | | | | Favorite-Sub | INDEX-Main | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | VGA | | DVI 1080I | DVI 720P | DVI 480P | | YC | 1080I | 720P | 480P | |
| | | DSP-4:3 | DSP-16:9 | | | DSP-4:3 | DSP-16:9 | | | | DSP-4:3 | DSP-16:9 |
| 0 | VDHP | 160 | 198 | 115 | 153 | 160 | 184 | 71 | 124 | 147 | 169 | 168 |
| 1 | VDHS | 227 | 209 | 228 | 152 | 228 | 220 | 167 | 226 | 152 | 227 | 227 |
| 2 | VDVE | 43 | 45 | 41 | 54 | 53 | 57 | 25 | 41 | 54 | 46 | 53 |
| 3 | VDVS | 116 | 110 | 124 | 165 | 111 | 110 | 56 | 124 | 165 | 116 | 111 |

Table 1-5

| No. | Item | INDEX-Main | | | | | | INDEX-Sub |
|---|---|---|---|---|---|---|---|---|
| | | VGA | | DVI 1080I | DVI 720P | DVI 480P | | YC |
| | | DSP-4:3 | DSP-16:9 | | | DSP-4:3 | DSP-16:9 | |
| 0 | VDHP | 165 | 198 | 123 | 155 | 167 | 184 | 76 |
| 1 | VDHS | 226 | 209 | 226 | 152 | 227 | 220 | 162 |
| 2 | VDVE | 35 | 45 | 41 | 54 | 45 | 57 | 25 |
| 3 | VDVS | 120 | 110 | 124 | 165 | 116 | 110 | 56 |

Table 2

| No. | Item | YC | 480I | 1080I | 720P | 480P | VGA |
|---|---|---|---|---|---|---|---|
| 4 | VDVO | 0 | 0 | 0 | 0 | 0 | 0 |
| 5 | VCPO | 42 | 42 | 72 | 88 | 122 | 122 |
| 6 | VCWD | 1 | 1 | 2 | 2 | 2 | 2 |
| 7 | VYCD | 0 | 0 | 0 | 0 | 0 | 0 |
| 8 | VSTP | 62 | 62 | 137 | 186 | 129 | 129 |
| 9 | VSTT | 0 | 0 | 0 | 0 | 0 | 0 |
| 10 | VHSC | 130 | ← | - | - | - | - |
| 11 | VFRV | 0 | 0 | 0 | 0 | 0 | 0 |

MID5 L/E

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | POP | | | Table 1 | |
| 1 | MHLY | | | Table 2 | |
| 2 | MHLC | | | Table 2 | |
| 3 | MVLY | | | Table 2 | |
| 4 | MVLC | | | Table 2 | |
| 5 | MHYR | | | Table 2 | |
| 6 | MHYL | | | Table 2 | |
| 7 | MHYE | | | Table 2 | |
| 8 | MHYO | | | Table 2 | |
| 9 | MHCR | | | Table 2 | |
| 10 | MHCL | | | Table 2 | |
| 11 | MHCE | | | Table 2 | |
| 12 | MHCO | | | Table 2 | |
| 13 | MVYR | | | Table 2 | |
| 14 | MVYL | | | Table 2 | |
| 15 | MVYE | | | Table 2 | |
| 16 | MVCR | | | Table 2 | |
| 17 | MVCL | | | Table 2 | |
| 18 | MVCE | | | Table 2 | |
| 19 | SHLY | | | Table 1 | |
| 20 | SHLC | | | Table 1 | |
| 21 | SVLY | | | Table 1 | |
| 22 | SVLC | | | Table 1 | |
| 23 | SHYR | | | Table 1 | |
| 24 | SHYL | | | Table 1 | |
| 25 | SHYE | | | Table 1 | |
| 26 | SHYO | | | Table 1 | |
| 27 | SHCR | | | Table 1 | |
| 28 | SHCL | | | Table 1 | |
| 29 | SHCE | | | Table 1 | |
| 30 | SHCO | | | Table 1 | |
| 31 | SVYR | | | Table 1 | |
| 32 | SVYL | | | Table 1 | |
| 33 | SVYE | | | Table 1 | |
| 34 | SVCR | | | Table 1 | |
| 35 | SVCL | | | Table 1 | |
| 36 | SVCE | | | Table 1 | |

Table 1

| No. | Item | case nothing |
|---|---|---|
| 0 | POP | — |
| 19 | SHLY | 0 |
| 20 | SHLC | 0 |
| 21 | SVLY | 0 |
| 22 | SVLC | 0 |
| 23 | SHYR | 0 |
| 24 | SHYL | 0 |
| 25 | SHYE | 0 |
| 26 | SHYO | 0 |
| 27 | SHCR | 0 |
| 28 | SHCL | 0 |
| 29 | SHCE | 0 |
| 30 | SHCO | 0 |
| 31 | SVYR | 0 |
| 32 | SVYL | 0 |
| 33 | SVYE | 0 |
| 34 | SVCR | 0 |
| 35 | SVCL | 0 |
| 36 | SVCE | 0 |

RM-Y912

Table 2-1

| No. | Item | POP=0 | POP=1 | POP=2 | POP=3 | POP=4 | POP=5 | POP=6 | POP=7 | POP=8 | POP=9 | POP=10 | POP=11 | POP=12 | POP=13 | POP=14 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| 1 | MHLY | 2 | 0 | 0 | 2 | 1 | 2 | 1 | 2 | 2 | 0 | 1 | 2 | 2 | 0 | 0 |
| 2 | MHLC | 0 | 0 | 1 | 3 | 3 | 0 | 3 | 0 | 1 | 1 | 3 | 1 | 1 | 1 | 1 |
| 3 | MVLY | 1 | 0 | 0 | 0 | 0 | 1 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 4 | MVLC | 0 | 0 | 2 | 0 | 0 | 0 | 0 | 0 | 2 | 2 | 0 | 2 | 2 | 2 | 2 |
| 5 | MHYR | 1 | 0 | 2 | 0 | 2 | 2 | 3 | 2 | 1 | 1 | 0 | 0 | 1 | 1 | 2 |
| 6 | MHYL | 1 | 0 | 1 | 0 | 1 | 1 | 2 | 1 | 1 | 1 | 0 | 1 | 1 | 1 | 1 |
| 7 | MHYE | 4 | 0 | 3 | 0 | 6 | 4 | 7 | 4 | 4 | 7 | 0 | 3 | 7 | 7 | 7 |
| 8 | MHYO | 1 | 0 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| 9 | MHCR | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 10 | MHCL | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 11 | MHCE | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 12 | MHCO | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 13 | MVYR | 0 | 0 | 1 | 0 | 1 | 1 | 2 | 2 | 0 | 1 | 0 | 1 | 1 | 0 | 2 |
| 14 | MVYL | 0 | 0 | 1 | 0 | 1 | 1 | 1 | 1 | 0 | 1 | 0 | 1 | 1 | 0 | 1 |
| 15 | MVYE | 0 | 0 | 5 | 0 | 1 | 7 | 3 | 7 | 0 | 5 | 0 | 5 | 5 | 0 | 5 |
| 16 | MVCR | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 17 | MVCL | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 18 | MVCE | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

Table 2-2

| No. | Item | POP=15 | POP=16 | POP=17 | POP=18 | POP=19 | POP=20 | POP=21 | POP=22 | POP=23 | POP=24 | POP=25 | POP=26 | POP=27 | POP=28 | POP=29 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| 1 | MHLY | 2 | 0 | 0 | 2 | 1 | 0 | 2 | 2 | 0 | 1 | 0 | 0 | 0 | 0 | 0 |
| 2 | MHLC | 3 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 0 | 3 | 2 | 0 | 2 | 2 | 1 |
| 3 | MVLY | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 |
| 4 | MVLC | 0 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 0 | 0 | 0 | 0 | 1 | 1 | 2 |
| 5 | MHYR | 0 | 0 | 1 | 0 | 1 | 0 | 1 | 1 | 1 | 0 | 0 | 1 | 1 | 1 | 1 |
| 6 | MHYL | 0 | 1 | 1 | 1 | 1 | 0 | 1 | 1 | 1 | 0 | 0 | 1 | 2 | 1 | 1 |
| 7 | MHYE | 0 | 7 | 5 | 5 | 3 | 0 | 7 | 7 | 3 | 0 | 0 | 3 | 5 | 4 | 7 |
| 8 | MHYO | 0 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| 9 | MHCR | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 3 | 0 | 0 |
| 10 | MHCL | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 11 | MHCE | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 4 | 0 | 0 |
| 12 | MHCO | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 1 | 1 | 0 | 1 | 0 | 0 |
| 13 | MVYR | 0 | 1 | 1 | 0 | 0 | 0 | 1 | 1 | 0 | 0 | 0 | 1 | 1 | 0 | 0 |
| 14 | MVYL | 0 | 2 | 1 | 0 | 0 | 0 | 1 | 1 | 0 | 0 | 0 | 2 | 2 | 0 | 0 |
| 15 | MVYE | 0 | 7 | 7 | 0 | 0 | 0 | 5 | 7 | 0 | 0 | 0 | 7 | 7 | 0 | 0 |
| 16 | MVCR | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 3 | 0 | 0 |
| 17 | MVCL | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 18 | MVCE | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 4 | 0 | 0 |

Table 2-3

| No. | Item | POP=30 | POP=31 | POP=32 | POP=33 | POP=34 | POP=35 | POP=36 | POP=37 | POP=38 | POP=39 | POP=40 | POP=41 | POP=42 | POP=43 | POP=44 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| 1 | MHLY | 0 | 0 | 0 | 1 | 3 | 1 | 1 | 1 | 1 | 3 | 1 | 1 | 1 | 0 | 3 |
| 2 | MHLC | 0 | 2 | 2 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 0 | 3 |
| 3 | MVLY | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 1 |
| 4 | MVLC | 0 | 1 | 1 | 0 | 1 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 1 |
| 5 | MHYR | 0 | 1 | 1 | 0 | 0 | 1 | 1 | 1 | 1 | 0 | 1 | 1 | 1 | 0 | 0 |
| 6 | MHYL | 0 | 2 | 2 | 0 | 0 | 1 | 2 | 2 | 1 | 0 | 1 | 2 | 2 | 1 | 0 |
| 7 | MHYE | 0 | 5 | 5 | 0 | 0 | 2 | 2 | 7 | 7 | 0 | 3 | 2 | 7 | 2 | 0 |
| 8 | MHYO | 1 | 1 | 1 | 1 | 0 | 1 | 1 | 1 | 1 | 0 | 1 | 1 | 1 | 0 | 0 |
| 9 | MHCR | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 10 | MHCL | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 11 | MHCE | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 12 | MHCO | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 13 | MVYR | 0 | 1 | 1 | 0 | 0 | 1 | 1 | 2 | 0 | 0 | 1 | 1 | 1 | 0 | 0 |
| 14 | MVYL | 0 | 1 | 1 | 0 | 0 | 1 | 1 | 1 | 0 | 0 | 1 | 1 | 1 | 0 | 0 |
| 15 | MVYE | 0 | 5 | 7 | 0 | 0 | 5 | 7 | 5 | 0 | 0 | 4 | 7 | 5 | 0 | 0 |
| 16 | MVCR | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 17 | MVCL | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 18 | MVCE | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

Table 2-4

| No. | Item | POP=45 | POP=46 | POP=47 | POP=48 | POP=49 | POP=50 | POP=51 | POP=52 | POP=53 | POP=54 | POP=55 | POP=56 | POP=57 | POP=58 | POP=59 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| 1 | MHLY | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 2 | MHLC | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 3 | MVLY | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 4 | MVLC | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 5 | MHYR | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 6 | MHYL | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 7 | MHYE | 4 | 7 | 7 | 2 | 2 | 4 | 7 | 7 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 8 | MHYO | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 9 | MHCR | 0 | 1 | 1 | 0 | 0 | 0 | 1 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 10 | MHCL | 0 | 1 | 1 | 0 | 0 | 0 | 1 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 11 | MHCE | 0 | 4 | 4 | 0 | 0 | 0 | 4 | 4 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 12 | MHCO | 0 | 1 | 1 | 0 | 0 | 0 | 1 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 13 | MVYR | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 14 | MVYL | 1 | 1 | 1 | 0 | 0 | 1 | 1 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 15 | MVYE | 4 | 4 | 4 | 0 | 0 | 4 | 4 | 4 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 16 | MVCR | 0 | 1 | 1 | 0 | 0 | 0 | 1 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 17 | MVCL | 0 | 1 | 1 | 0 | 0 | 0 | 1 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 18 | MVCE | 0 | 4 | 4 | 0 | 0 | 0 | 4 | 4 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

Table 2-5

| No. | Item | POP=60 | POP=61 | POP=62 | POP=63 |
|---|---|---|---|---|---|
| 1 | MHLY | 0 | 0 | 0 | 0 |
| 2 | MHLC | 0 | 0 | 0 | 0 |
| 3 | MVLY | 0 | 0 | 0 | 0 |
| 4 | MVLC | 0 | 0 | 0 | 0 |
| 5 | MHYR | 0 | 0 | 0 | 0 |
| 6 | MHYL | 0 | 0 | 0 | 0 |
| 7 | MHYE | 0 | 0 | 0 | 0 |
| 8 | MHYO | 0 | 0 | 0 | 0 |
| 9 | MHCR | 0 | 0 | 0 | 0 |
| 10 | MHCL | 0 | 0 | 0 | 0 |
| 11 | MHCE | 0 | 0 | 0 | 0 |
| 12 | MHCO | 0 | 0 | 0 | 0 |
| 13 | MVYR | 0 | 0 | 0 | 0 |
| 14 | MVYL | 0 | 0 | 0 | 0 |
| 15 | MVYE | 0 | 0 | 0 | 0 |
| 16 | MVCR | 0 | 0 | 0 | 0 |
| 17 | MVCL | 0 | 0 | 0 | 0 |
| 18 | MVCE | 0 | 0 | 0 | 0 |

## MID6 CUT

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | MCUT | | | Table 1 | |
| 1 | MWHS | | | Table 1 | |
| 2 | MWVS | | | Table 1 | |
| 3 | MRHP | | | Table 1 | |
| 4 | MRVP | | | Table 1 | |
| 5 | MRHS | | | Table 1 | |
| 6 | MRVS | | | Table 1 | |

Table 1-1

| No. | Item | 480i NOT Mild(ANLFM=3 or 4) | | | 480i Mild(ANLFM=7) | | | 480p (ANLFM=2) | | | VGA(ANLFM=D) | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | FULL/NORMAL | ZOOM | W-ZOOM | FULL/NORMAL | ZOOM | W-ZOOM | FULL/NORMAL | ZOOM | W-ZOOM | FULL/NORMAL | ZOOM | W-ZOOM |
| 0 | MCUT | 0 | 1 | 1 | 0 | 1 | 1 | 0 | 1 | 1 | 0 | 1 | 1 |
| 1 | MWHS | - | 174 | 174 | - | 87 | 87 | - | 230 | 230 | - | 230 | 230 |
| 2 | MWVS | - | 120 | 120 | - | 60 | 60 | - | 120 | 120 | - | 120 | 120 |
| 3 | MRHP | - | 0 | 0 | - | 0 | 0 | - | 0 | 0 | - | 0 | 0 |
| 4 | MRVP | - | 30 | 11 | - | 30 | 11 | - | 30 | 11 | - | 31 | 12 |
| 5 | MRHS | - | 174 | 174 | - | 87 | 87 | - | 230 | 230 | - | 230 | 230 |
| 6 | MRVS | - | 90 | 109 | - | 90 | 109 | - | 90 | 109 | - | 94 | 113 |

Table 1-2

| No. | Item | DVI 480i NOT Mild(ANLFM=5) | | | DVI 480i Mild(ANLFM=C) | | | DVI 480p (ANLFM=A) | | 480p (ANLFM=A) |
|---|---|---|---|---|---|---|---|---|---|---|
| | | FULL/NORMAL | ZOOM | W-ZOOM | FULL/NORMAL | ZOOM | W-ZOOM | FULL/NORMAL | ZOOM | W-ZOOM |
| 0 | MCUT | 0 | 1 | 1 | 0 | 1 | 1 | 0 | 1 | 1 |
| 1 | MWHS | - | 175 | 175 | - | 87 | 87 | - | 230 | 230 |
| 2 | MWVS | - | 120 | 120 | - | 60 | 60 | - | 120 | 120 |
| 3 | MRHP | - | 0 | 0 | - | 0 | 0 | - | 0 | 0 |
| 4 | MRVP | - | 30 | 11 | - | 15 | 6 | - | 30 | 11 |
| 5 | MRHS | - | 175 | 175 | - | 87 | 87 | - | 230 | 230 |
| 6 | MRVS | - | 90 | 109 | - | 45 | 54 | - | 90 | 109 |

2171

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | MTRX | | | Table 1 | |
| 1 | GAIN | | | Table 2 | |
| 2 | FIXS | | | Table 3 | |
| 3 | CBGN | | | Table 2 | |
| 4 | CRGN | | | Table 2 | |
| 5 | YGN | | | Table 2 | |
| 6 | VTC | | | 0 | |
| 7 | FRGB | | | Table 3 | |
| 7 | HTC | | | Table 4 | |
| 8 | HWID | | | 1 | |
| 9 | HSEP | | | 2 | |
| 10 | HMSK | | | Table 5 | |

Table 1

| No. | Item | FRGB=1 | Video5-6 720P/1080I NORMAL | others |
|---|---|---|---|---|
| 0 | MTRX | 3 | 1 | 0 |

Table 2

| No. | Item | Others | Analog 1080i |
|---|---|---|---|
| 1 | GAIN | 0 | 0 |
| 3 | CBGN | 9 | 7 |
| 4 | CRGN | 9 | 8 |
| 5 | YGN | 9 | 8 |

Table 3

| No. | Item | Video5-6 | DVI | Others |
|---|---|---|---|---|
| 2 | FIXS | 0 | 0 | 0 |
| 7 | FRGB | 0 | 0 | 0 |

Table 4

| No. | Item | Status-tristate=1 | Others(Status-tristate=1) |
|---|---|---|---|
| 7 | HTC | 0 | 1 |

Table 5

| No. | Item | Others | Video5-7 1080i |
|---|---|---|---|
| 10 | HMSK | 1 | 0 |

3506

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | MCON | | | Table 1 | |
| 1 | SCOR | | | Table 1 | |
| 2 | SCOG | | | Table 1 | |
| 3 | SCOB | | | Table 1 | |
| 4 | RGB | | | Table 1 | |

Table 1

| No. | Item | 480I/S VIDEO | OTHERS |
|---|---|---|---|
| 0 | MCON | 64 | 64 |
| 1 | SCOR | 128 | 128 |
| 2 | SCOG | 128 | 128 |
| 3 | SCOB | 128 | 128 |
| 4 | RGB | 0 | 0 |

## AUDIO

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | ASYS | | | 0 | |
| 1 | TRCV | | | 0 | |
| 2 | BACV | | | 2 | |
| 3 | MDCV | | | 0 | |
| 4 | SVHI | | | 5 | |
| 5 | SVLO | | | 0 50XBR | |
| | | | | 1 60XBR | |
| 6 | MIDL | | | 7 | |
| 7 | LOFQ | | | 2 50XBR | |
| | | | | 3 60XBR | |
| 8 | SBAS | | | 8 | |
| 9 | BSFQ | | | 7 | |
| 10 | STRE | | | 5 | |
| 11 | TRFQ | | | 7 | |
| 12 | PSEF | | | 5 | |
| 13 | AGCL | | | 0 | |
| 14 | BBE | | | Table 1 | |
| 15 | BBEP | | | Table 1 | |
| 16 | BBEL | | | Table 1 | |
| 17 | BB2P | | | Table 1 | |
| 18 | BB2L | | | Table 1 | |
| 19 | TRS1 | | | 4 | |
| 20 | TRS2 | | | 5 | |

Table 1

| No. | Item | SURR_OFF | | TRUSURR | SIMULAT |
|---|---|---|---|---|---|
| | | AGC_OFF | AGC_AUTO | | |
| 14 | BBE | 1 | 1 | 1 | 1 |
| 15 | BBEP | 4 | 4 | 4 | 4 |
| 16 | BBEL | 1 | 1 | 1 | 1 |
| 17 | BB2P | 0 | 0 | 0 | 0 |
| 18 | BB2L | 0 | 0 | 0 | 0 |

SNNR

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | MODE | | | Table 1 | |
| 1 | SNNR | | | Table 1 | |
| 2 | WSLT | | | Table 2 | |
| 3 | CPFG | | | Table 3 | |
| 4 | CPFT | | | Table 3 | |
| 5 | CCOR | | | Table 3 | |
| 6 | CHCG | | | Table 3 | |
| 7 | CAPG | | | Table 3 | |
| 8 | 3SHP | | | Table 3 | |
| 9 | NYNR | | | Table 3 | |
| 10 | NCNR | | | Table 3 | |
| 11 | NYMG | | | Table 3 | |
| 12 | NCMG | | | Table 3 | |
| 13 | NYLT | | | Table 3 | |
| 14 | NYNC | | | Table 3 | |
| 15 | NYCO | | | Table 3 | |
| 16 | 7SHP | | | Table 3 | |
| 17 | 7YF1 | | | Table 3 | |
| 18 | 7LTI | | | Table 3 | |
| 19 | 7CTI | | | Table 3 | |
| 20 | 7VML | | | Table 3 | |
| 21 | 7VMC | | | Table 3 | |
| 22 | MIDD | | | Table 3 | |
| 23 | USHS | | | Table 3 | |
| 24 | NLMP | | | Table 3 | |
| 25 | PKNG | | | Table 3 | |
| 26 | CRNG | | | Table 3 | |

Table 1

| No. | Item | case nothing |
|---|---|---|
| 0 | MODE | 0 |
| 1 | SNNR | 0 |

Table 2

| No. | Item | A | B | C | D | E | F | G |
|---|---|---|---|---|---|---|---|---|
| 2 | WSLT | 15 | 31 | 45 | 63 | 85 | 127 | 180 |

Table 3

| No. | Item | SNNR:0 | SNNR:1 | SNNR:2 | SNNR3 | SNNR4 | SNNR:5 | SNNR:6 | SNNR:7 |
|---|---|---|---|---|---|---|---|---|---|
| 3 | CPFG | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 2 |
| 4 | CPFT | 0 | 0 | 1 | 2 | 2 | 3 | 3 | 3 |
| 5 | CCOR | 0 | 1 | 1 | 2 | 2 | 2 | 3 | 3 |
| 6 | CHCG | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 7 | CAPG | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 8 | 3SHP | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 2 |
| 9 | NYNR | 0 | 1 | 1 | 1 | 2 | 2 | 2 | 2 |
| 10 | NCNR | 0 | 1 | 1 | 1 | 2 | 2 | 2 | 2 |
| 11 | NYMG | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 12 | NCMG | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 13 | NYLT | 0 | 1 | 1 | 2 | 3 | 4 | 6 | 8 |
| 14 | NYNC | 0 | 1 | 1 | 1 | 2 | 2 | 2 | 2 |
| 15 | NYCO | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 16 | 7SHP | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 17 | 7YF1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 18 | 7LTI | 0 | 1 | 2 | 3 | 3 | 3 | 3 | 3 |
| 19 | 7CTI | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 20 | 7VML | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 21 | 7VMC | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 22 | MIDD | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 23 | USHS | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
| 24 | NLMP | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
| 25 | PKNG | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 26 | CRNG | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |

3DNR

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | WHCT | | | Table 1 | |
| 1 | NIQM | | | Table 1 | |
| 2 | CLPW | | | Table 1 | |
| 3 | CLPP | | | Table 1 | |
| 4 | YHBW | | | Table 1 | |
| 5 | YBKL | | | Table 1 | |
| 6 | YBKO | | | Table 1 | |
| 7 | MUTE | | | Table 1 | |
| 8 | YHBS | | | Table 1 | |
| 9 | CHBW | | | Table 1 | |
| 10 | CBKO | | | Table 1 | |
| 11 | CHBO | | | Table 1 | |
| 12 | VHBL | | | Table 1 | |
| 13 | UHBL | | | Table 1 | |
| 14 | UVDL | | | Table 1 | |
| 15 | YDL | | | Table 1 | |
| 16 | PVDI | | | Table 1 | |
| 17 | PHDI | | | Table 1 | |
| 18 | HDW | | | Table 1 | |
| 19 | PVDO | | | Table 1 | |
| 20 | PHDO | | | Table 1 | |
| 21 | HST | | | Table 1 | |
| 22 | VDL | | | Table 1 | |
| 23 | VDW | | | Table 1 | |
| 24 | NDET | | | Table 1 | |
| 25 | NVP | | | Table 1 | |
| 26 | NDTS | | | Table 1 | |
| 27 | HROF | | | Table 1 | |
| 28 | NDGW | | | Table 1 | |
| 29 | UOFS | | | Table 1 | |
| 30 | POT | | | Table 1 | |
| 31 | UVF | | | Table 1 | |
| 32 | APC | | | Table 1 | |
| 33 | DAP | | | Table 1 | |
| 34 | YLV | | | Table 2 | |
| 35 | YST | | | Table 1 | |
| 36 | YNT | | | Table 1 | |
| 37 | YPL | | | Table 1 | |
| 38 | YMV | | | Table 1 | |
| 39 | YCR | | | Table 2 | |
| 40 | VOS | | | Table 1 | |
| 41 | YMG | | | Table 2 | |
| 42 | YEG | | | Table 1 | |
| 43 | YEL | | | Table 2 | |
| 44 | YLM | | | Table 2 | |
| 45 | CLV | | | Table 2 | |
| 46 | CNT | | | Table 1 | |
| 47 | CPL | | | Table 1 | |
| 48 | CMG | | | Table 2 | |
| 49 | CCR | | | Table 2 | |
| 50 | CLM | | | Table 2 | |
| 51 | NVSL | | | Table 1 | |
| 52 | NVSH | | | Table 1 | |
| 53 | NHS | | | Table 1 | |
| 54 | NVEL | | | Table 1 | |
| 55 | NVEH | | | Table 1 | |
| 56 | NHE | | | Table 1 | |
| 57 | YNG | | | Table 2 | |
| 58 | COR | | | Table 2 | |
| 59 | LPF | | | Table 2 | |
| 60 | YLT | | | Table 2 | |
| 61 | YNC | | | Table 2 | |
| 62 | YCO | | | Table 2 | |
| 63 | ADTH | | | Table 1 | |

Table 1

| No. | Item | case nothing |
|---|---|---|
| 0 | WHCT | 44 |
| 1 | NIQM | 1 |
| 2 | CLPW | 30 |
| 3 | CLPP | 80 |
| 4 | YHBW | 138 |
| 5 | YBKL | 0 |
| 6 | YBKO | 0 |
| 7 | MUTE | 0 |
| 8 | YHBS | 40 |
| 9 | CHBW | 138 |
| 10 | CBKO | 40 |
| 11 | CHBO | 0 |
| 12 | VHBL | 0 |
| 13 | UHBL | 0 |
| 14 | UVDL | 0 |
| 15 | YDL | 0 |
| 16 | PVDI | 0 |
| 17 | PHDI | 0 |
| 18 | HDW | 16 |
| 19 | PVDO | 0 |
| 20 | PHDO | 0 |
| 21 | HST | 54 |
| 22 | VDL | 0 |
| 23 | VDW | 3 |
| 24 | NDET | 0 |
| 25 | NVP | 2 |
| 26 | NDTS | 3 |
| 27 | HROF | 0 |
| 28 | NDGW | 9 |
| 29 | UOFS | 1 |
| 30 | POT | 0 |
| 31 | UVF | 0 |
| 32 | APC | 1 |
| 33 | DAP | 0 |
| 35 | YST | 0 |
| 36 | YNT | 1 |
| 37 | YPL | 1 |
| 38 | YMV | 0 |
| 40 | VOS | 0 |
| 42 | YEG | 0 |
| 46 | CNT | 1 |
| 47 | CPL | 1 |
| 51 | NVSL | 20 |
| 52 | NVSH | 0 |
| 53 | NHS | 16 |
| 54 | NVEL | 248 |
| 55 | NVEH | 0 |
| 56 | NHE | 120 |
| 63 | ADTH | 0 |

Table 2

| No. | Item | OTHER | | | | VIDEO 5～7(480i) | | | |
|---|---|---|---|---|---|---|---|---|---|
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild |
| 34 | YLV | 8 | 8 | 8 | 8 | 8 | 8 | 8 | 8 |
| 39 | YCR | 3 | 3 | 3 | 3 | 3 | 0 | 0 | 0 |
| 41 | YMG | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 |
| 43 | YEL | 6 | 6 | 6 | 6 | 6 | 6 | 6 | 6 |
| 44 | YLM | 6 | 6 | 6 | 6 | 6 | 6 | 6 | 6 |
| 45 | CLV | 8 | 8 | 8 | 8 | 8 | 8 | 8 | 8 |
| 48 | CMG | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 |
| 49 | CCR | 3 | 3 | 3 | 3 | 3 | 0 | 0 | 0 |
| 50 | CLM | 6 | 6 | 6 | 6 | 6 | 6 | 6 | 6 |
| 57 | YNG | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 |
| 58 | COR | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 59 | LPF | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 60 | YLT | 6 | 6 | 6 | 6 | 6 | 6 | 6 | 6 |
| 61 | YNC | 8 | 8 | 8 | 8 | 8 | 8 | 8 | 8 |
| 62 | YCO | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

## DRCV

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | MFVR | | | Table 1 | |
| 1 | ISEL | | | Table 1 | |
| 2 | ORES | | | Table 2 | |
| 2 | LMLV | | | Table 5 | |
| 3 | ONCT | | | Table 2 | |
| 4 | AINI | | | Table 3 | |
| 5 | BINI | | | Table 3 | |
| 6 | FMAT | | | Table 1 | |
| 7 | FMTH | | | Table 4 | |
| 8 | FSEL | | | Table 1 | |
| 9 | CDLY | | | Table 1 | |
| 10 | LMIT | | | Table 1 | |
| 12 | LMLV | | | Table 1 | |
| 13 | VDLY | | | Table 1 | |
| 14 | VDPR | | | Table 1 | |
| 15 | WPPL | | | Table 1 | |
| 16 | CRCT | | | Table 1 | |
| 17 | NRA | | | Table 6 | |
| 18 | NRB | | | Table 6 | |

Table 1

| No. | Item | case nothing |
|---|---|---|
| 0 | MFVR | 0 |
| 1 | ISEL | 1 |
| 6 | FMAT | 0 |
| 8 | FSEL | 1 |
| 9 | CDLY | 2 |
| 10 | LMIT | 0 |
| 12 | LMLV | 1 |
| 13 | VDLY | 1 |
| 14 | VDPR | 3 |
| 15 | WPPL | 2 |
| 16 | CRCT | 0 |

Table 2-1

| No. | Item | RF | | | | VIDEO 1-4 | | | | VIDEO 5-6 | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild | Vivid | Standard | PRO | Mild |
| 2 | ORES | 128 | 128 | 128 | 128 | 128 | 128 | 128 | 128 | 128 | 128 | 128 | 128 |
| 3 | ONCT | 128 | 128 | 128 | 128 | 128 | 128 | 128 | 128 | 128 | 128 | 128 | 128 |

Table 2-2

| No. | Item | DVI | | | |
|---|---|---|---|---|---|
| | | Vivid | Standard | PRO | Mild |
| 2 | ORES | 128 | 128 | 128 | 128 |
| 3 | ONCT | 128 | 128 | 128 | 128 |

Table 3

| No. | Item | Custom1 | Custom2 | Custom3 |
|---|---|---|---|---|
| 4 | AINI | 0 | 49 | 79 |
| 5 | BINI | 24 | 54 | 89 |

Table 4

| No. | Item | RF | OTHERS |
|---|---|---|---|
| 7 | FMTH | 1 | 1 |

Table 5

| No. | Item | Vivid | Standard | PRO | Mild |
|---|---|---|---|---|---|
| 2 | LMLV | 2 | 2 | 2 | 2 |

Table 6

| No. | Item | SNNR LEVEL | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| | | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
| 17 | NRA | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 18 | NRB | 128 | 128 | 128 | 128 | 128 | 128 | 128 | 128 |

## OP

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | DLY1 | | | Table 1 | |
| 1 | DLY2 | | | Table 1 | |
| 2 | DLY3 | | | Table 1 | |
| 3 | OSDH | | | Table 1 | |
| 4 | HPOF | | | Table 1 | |
| 5 | VPOS | | | Table 1 | |
| 6 | VPOT | | | Table 1 | |
| 7 | HDPT | | | Table 1 | |
| 8 | MSBG | | | Table 1 | |
| 9 | AACK | | | Table 1 | |
| 10 | SLFC | | | Table 1 | |
| 11 | RAMW | | | Table 1 | |

Table 1

| No. | Item | case nothing |
|---|---|---|
| 0 | DLY1 | 4 |
| 1 | DLY2 | 12 |
| 2 | DLY3 | 7 |
| 3 | OSDH | 17 |
| 4 | HPOF | 11 |
| 5 | VPOS | 12 |
| 6 | VPOT | 33 |
| 7 | HDPT | 1 |
| 8 | MSBG | 0 |
| 9 | AACK | 2 |
| 10 | SLFC | 0 |
| 11 | RAMW | 0 |

## ID

| No. | Item | Function | Data range | Data | Remarks |
|---|---|---|---|---|---|
| 0 | ID0 | | | Table 1 | |
| 1 | ID1 | | | Table 1 | |
| 2 | ID2 | | | Table 1 | |
| 3 | ID3 | | | Table 1 | |
| 4 | ID4 | | | Table 1 | |
| 5 | ID5 | | | Table 1 | |
| 6 | ID6 | | | Table 1 | |
| 7 | ID7 | | | Table 1 | |

Table 1

| No. | Item | case nothing |
|---|---|---|
| 0 | ID0 | 89 |
| 1 | ID1 | 255 |
| 2 | ID2 | 239 |
| 3 | ID3 | 107 |
| 4 | ID4 | 75 |
| 5 | ID5 | 243 |
| 6 | ID6 | 126 |
| 7 | ID7 | 27 |

## 3-2. CHASSIS PICTURE QUALITY ADJUSTMENT

### 3-2-1. Sub Color/Sub Hue Adjustment

#### 1. Preparation

1) Before adjustment, set the following adjustment conditions in each mode.

Note: After the adjustment in 3-2-2. Sub Color/Sub Hue Adjustment, restore original data in each mode.

Adjustment conditions

PICTURE MODE: Vivid

| Category | Item | | Data |
|---|---|---|---|
| MCP-ADJ1 | 2 | GDRV | 50 |
| | 3 | GCUT | 40 |
| VID ADJ | 1 | GAM | 0 |
| | 2 | DCTN | 0 |
| | 3 | DPIC | 0 |
| USER STD | 2 | UCOL | 31 |
| | 3 | UHUE | 31 |
| | 9 | UCOF | 31 |
| | 10 | UHOF | 31 |

2) Connect an oscilloscope to the CN702 pin ① (TP744) on the BB board.

#### 2. RF Input Adjustment

1) Enter the RF color bar (75%) signal.
2) Set the adjustment conditions in 1. Preparation, and further set the following data.

Adjustment conditions

| Category | Item | | Data |
|---|---|---|---|
| P-BOOST1 | 0 | BSET | 0 |
| 2103-1 | 22 | ATPD | 0 |
| | 23 | DCTR | 0 |
| 2103-2 | 22 | ATPD | 0 |
| | 23 | DCTR | 0 |

3) Press the TWIN button on the remote commander to display color bar on the left and right two screens.
4) Measure the waveform, and repeat the SCOL and SHUE adjustments so that VB1 = VB4, and VB2 = VB3.

Adjustment positions

| | Category | tem | |
|---|---|---|---|
| Left screen | 2103-1 | 3 | SCOL |
| | | 4 | SHUE |
| Right screen | 2103-2 | 3 | SCOL |
| | | 4 | SHUE |




5) After the adjustment finished, return the data set in 2) to original values, and write the data by pressing the MUTE + ENTER buttons on the remote commander.

#### 3. Video Input Adjustment

1) Enter the Video color bar (100%) signal.
2) Set the adjustment conditions in 1. Preparation, and further set the following data.

Adjustment conditions

| Category | Item | | Data |
|---|---|---|---|
| P-BOOST1 | 0 | BSET | 0 |
| 2103-1 | 22 | ATPD | 0 |
| | 23 | DCTR | 0 |
| 2103-2 | 22 | ATPD | 0 |
| | 23 | DCTR | 0 |

3) Press the TWIN button on the remote commander to display color bar on the left and right two screens.
4) Measure the waveform, and repeat the SCOL and SHUE adjustments so that VB1 = VB4, and VB2 = VB3.

Adjustment positions

| | Category | tem | |
|---|---|---|---|
| Left screen | 2103-1 | 3 | SCOL |
| | | 4 | SHUE |
| Right screen | 2103-2 | 3 | SCOL |
| | | 4 | SHUE |




5) After the adjustment finished, return the data set in 2) to original values, and write the data by pressing the MUTE + ENTER buttons on the remote commander.

#### 4. Component Input Adjustment

1) Enter the Component 480i color bar (100%) signal.
2) Set the adjustment conditions in 1. Preparation, and further set the following data.

Adjustment conditions

| Category | Item | | Data |
|---|---|---|---|
| P-BOOST1 | 0 | BSET | 0 |
| 2103-1 | 22 | ATPD | 0 |
| | 23 | DCTR | 0 |

3) Measure the waveform, and repeat the SCOL and SHUE adjustments so that VB1 = VB4, and VB2 = VB3.

Adjustment position

| Category | Item | |
|---|---|---|
| 2170P-4 | 0 | COL |
| | 1 | HUE |




4) After the adjustment finished, return the data set in 2) to original values, and write the data by pressing the [MUTE] + [ENTER] buttons on the remote commander.
5) Enter the Component 1080i color bar (100%) signal.
6) Set the adjustment conditions in 1. Preparation, and perform adjustment in step 3).
7) After the adjustment finished, return the data set in 6) to original values, and write the data by pressing the [MUTE] + [ENTER] buttons on the remote commander.
8) Enter the Component 480p signal. Set same values as those adjusted in 6) and write the data by pressing the [MUTE] + [ENTER] buttons on the remote commander.
9) Enter the Component 720p signal. Set same values as those adjusted in 6) and write the data by pressing the "[MUTE] + [ENTER] buttons on the remote commander.
10) Enter the Component 1080i signal. Set same values as those adjusted in 6) and write the data by pressing the "[MUTE] + [ENTER] buttons on the remote commander.

### 3-2-2. Hi-Level/Cut-Off Adjustment

1) Enter the Video window signal, and set the PICTURE MODE to "Vivid".
2) Connect an oscilloscope to the CN702 on the BB board.

Measurement positions

| | |
|---|---|
| R | pin ⑤ (TP742) |
| G | pin ③ (TP743) |
| B | pin ① (TP744) |

3) For each output waveform of R, G, and B, repeat respective adjustment items so as to attain H/L = 3.90 V ±1 STEP and C/O = 2.20 V ±1 STEP.

Adjustment position

| Category | Item | |
|---|---|---|
| MCP ADJ1 | 0 | RDRV |
| | 1 | RCUT |
| | 2 | GDRV |
| | 3 | GCUT |
| | 4 | BDRV |
| | 5 | BCUT |




4) After the adjustment finished, write the data by pressing the [MUTE] + [ENTER] buttons on the remote commander.
5) Change over the PICTURE MODE to "Mild", and perform the steps 3) and 4).
6) Enter the Component 480i window signal, and change over the PICTURE MODE to "Vivid".
7) Perform the steps 3) to 5).
8) Enter the Component 1080i window signal, and change over the PICTURE MODE to "Vivid".
9) Perform the steps 3) and 4).
10) Enter the Component 480p signal. Set same values as those adjusted in 9) and write the data by pressing the [MUTE] + [ENTER] buttons on the remote commander.
11) Enter the Component 720p signal. Set same values as those adjusted in 9) and write the data by pressing the [MUTE] + [ENTER] buttons on the remote commander.

### 3-2-3. White Level Adjustment

#### 1. Preparation

1) Before adjustment, set the following adjustment conditions in each mode.

Note: After the adjustment in 3-2-1. White Level Adjustment, restore original data in each mode.

Adjustment conditions

| Category | Item | | Data |
|---|---|---|---|
| P-BOOST1 | 0 | BSET | 0 |
| MCP-ADJ1 | 2 | GDRV | 45 |
| | 3 | GCUT | 30 |
| VID ADJ | 1 | GAM | 0 |
| | 2 | DCTN | 0 |
| | 3 | DPIC | 0 |

2) Connect an oscilloscope to the CN702 pin ③ (TP743) on the BB board.

#### 2. RF Input Adjustment

1) Enter the RF color bar (75%) signal, and set the PICTURE MODE to "Vivid".
2) Set the adjustment conditions in 1. Preparation, and further set the following data.

Adjustment conditions

| Category | Item | | Data |
|---|---|---|---|
| 2103-1 | 22 | ATPD | 0 |
| | 23 | DCTR | 0 |
| 2103-2 | 22 | ATPD | 0 |
| | 23 | DCTR | 0 |

3) Press the TWIN button on the remote commander to display color bar on the left and right two screens.
4) Measure the waveform, and adjust so that a difference between black level and white level is 1.25 Vp-p ±1 STEP.

Adjustment positions

| | Category | tem | |
|---|---|---|---|
| Left screen | 2103-1 | 2 | SCON |
| Right screen | 2103-2 | 2 | SCON |




5) After the adjustment finished, return the data set in 2) to original values, and write the data by pressing the MUTE + ENTER buttons on the remote commander.

#### 3. Video Input Adjustment

1) Enter the 1/2 window signal, and set the PICTURE MODE to "Vivid".
2) Set the adjustment conditions in 1. Preparation, and further set the following data.

Adjustment conditions

| Category | Item | | Data |
|---|---|---|---|
| 2103-1 | 22 | ATPD | 0 |
| | 23 | DCTR | 0 |
| 2103-2 | 22 | ATPD | 0 |
| | 23 | DCTR | 0 |

3) Press the TWIN button on the remote commander to display the STEP signal on the left and right two screens.
4) Measure the waveform, and adjust so that a difference between black level and white level is 1.55 Vp-p ±1 STEP.

Adjustment positions

| | Category | tem | |
|---|---|---|---|
| Left screen | 2103-1 | 2 | SCON |
| Right screen | 2103-2 | 2 | SCON |




5) After the adjustment finished, return the data set in 2) to original values, and write the data by pressing the MUTE + ENTER buttons on the remote commander.

#### 4. Component Input Adjustment

1) Enter the 1/2 window signal, and set the PICTURE MODE to "Vivid".
2) Set the adjustment conditions in 1. Preparation.
3) Measure the waveform, and adjust so that a difference between black level and white level is 1.68 Vp-p ±1 STEP.

Adjustment position

| Category | Item |
|---|---|
| 2103-1 | 0 YLEV |




4) After the adjustment finished, return the data set in 2) to original values, and write the data by pressing the MUTE + ENTER buttons on the remote commander.
5) Change over the PICTURE MODE to "Mild", and perform the steps 2) to 4).

## 3-3. VERTICAL STRIPE ADJUSTMENT

1. Set the following adjustment conditions, and display the test pattern.

Adjustment conditions

| Category | Item | | Data |
|---|---|---|---|
| D-GM TEST | 2 | G-LUT SW | 0 |
| D-GM TPN | 0 | T-PATN SW | 1 |
| | 1 | T-SIG SEL | 0 |
| | 2 | PATN DIR | 1 |
| | 3 | SIG LV DIR | 0 |
| | 5 | B-LV | 15 |
| | 6 | G-LV | 15 |
| | 7 | R-LV | 15 |

2. Set the test pattern to red color, and adjust the EVEN VR so as to minimize vertical stripes (difference in brightness of vertical lines every two dots).



•□Screen Magnify□
□ Should be minimize bright
□ difference every two dots.

| Category | Item | | Data |
|---|---|---|---|
| D-GM TPN | 8 | T-PATN RGB | 1 (R) |
| LCD-DR | 2 | R ODD VR | ADJ* |
| LCD-DR | 3 | R EVEN VR | ADJ |

*: Fundamentally, this item is adjusted with the EVEN VR only, but if the adjustment range is not enough, the ODD VR may also be adjusted.

Test pattern color combination

| DATA= | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|---|---|---|---|---|---|---|---|
| R | ○ | – | ○ | – | ○ | – | ○ |
| G | – | ○ | ○ | – | – | ○ | ○ |
| B | – | – | – | ○ | ○ | ○ | ○ |

3. Adjust the green in the same manner.

| Category | Item | | Data |
|---|---|---|---|
| D-GM TPN | 8 | T-PATN RGB | 2 (G) |
| LCD-DR | 7 | G ODD VR | ADJ* |
| LCD-DR | 8 | G EVEN VR | ADJ |

*: Fundamentally, this item is adjusted with the EVEN VR only, but if the adjustment range is not enough, the ODD VR may also be adjusted.

4. Adjust the blue in the same manner.

| Category | Item | Data |
|---|---|---|
| D-GM TPN | 8 T-PATN RGB | 4 (B) |
| LCD-DR | 12 B ODD VR | ADJ* |
| LCD-DR | 13 B EVEN VR | ADJ |

*: Fundamentally, this item is adjusted with the EVEN VR only, but if the adjustment range is not enough, the ODD VR may also be adjusted.

5. Write the data by pressing the MUTE + ENTER buttons on the remote commander.

## 3-4. SUB BRIGHT ADJUSTMENT

1. Enter the monoscope signal to the VIDEO 5 input, and set the PICTURE MODE to "Vivid" and the WIDE MODE to "Full".
2. Adjust the SUB BRT so that the borderline of 0IRE and 10IRE becomes distinctive.

Adjustment positions

| Category | Item | Standard value |
|---|---|---|
| D-GM IM | 2 SUB CON | 25* |
| D-GM IM | 3 SUB BRT | 20 |

*: If the adjustment is imperfect though the SUB BRT value is 0, lower the SUB CON value and make further adjustment.

Note: If the SUB BRT value exceeds 32, make sure that there is no noisy black of 0IRE.
Though the SUB CON value is generally lowered only, if it is to be raised, take care not to cause the white blurring.

3. If the SUB CON value was changed, check the white balance and repeat adjustment to attain best sub brightness, sub contrast, and white balance.
4. After the adjustment finished, write the data by pressing the MUTE + ENTER buttons on the remote commander.

## 3-5. SCREEN CENTER ADJUSTMENT

1. Enter the RF monoscope signal.
2. Adjust so that the picture is displayed in the center of the screen.

Adjustment position

| Category | Item |
|---|---|
| HV POS AD | 0 H POS ADJ |
| | 1 V POS ADJ |

3. Make sure that a difference in horizontal graduations is below 0.1 frame, and a difference in vertical graduations is below 0.1 frame, and then write the data by pressing the MUTE + ENTER buttons on the remote commander.

## 3-6. FAVORITES ADJUSTMENT

1. Enter the RF signal, and press the FAVORITES button on the remote commander.
2. Adjust so that the "Favorites" displayed on the right side of the screen comes to the center of the display area.

Adjustment position

| Category | Item |
|---|---|
| OSD | 1 HPOF |




3. After the adjustment finished, write the data by pressing the MUTE + ENTER buttons on the remote commander.

# SECTION 4
# DIAGRAMS

## 4-1. BLOCK DIAGRAM (1)



## BLOCK DIAGRAM (2)


TO BB BOARD CN2804 G
H TO BB BOARD CN3203
CHECK CONNECTOR
C1 TO BB BOARD CN5004
C2 TO BB BOARD CN5001
C3 TO BB BOARD CN5002
CN1018 OSD R OSD G OSD B OSD V OSD YSYM OSD H SCP SCLK-E SDAT-E 5V 9V
CN1017 CLK1 DAT1 TH CONT POWER-INT BINT MIDBUSY SUBOSD SUBH SUBV VDOVS VDOHS RST VDOCR VDOCB VDOY DRCV DRCH DRCCR DRCCB DRCY 3.3V 3.3V 9V 5V 5V MS 5V MS 5V
CN1020 SDA0 SDA1 SCL0 SCL1 B INT SCL-E SDA-E
CN1001 SER-C SDAT-E SCLK-E ENB-C SCAN-CS WP-C SDAT-OSD SCLK-OSD WP-LUT SO
CN1002 FLD PLL-EN OSD-BUSY SCL-E SDA-E BLANKING
CN1003 5V 5V 3.3C 3.3C 15V
DATA
SYS
OSD
FAN
MS RST
P-CON
TO U (1/2)
MAIN
CN1019 FSC SUB Y2 SUB C2 SUB Y1 SUB C1 MAIN C MAIN V/Y V56Y V56CB V56CR V7Y V7CB V7CR VDOY VDOCB VDOCR DRCCR DRCCB DRCY VDOHS VDOVS DRCV DRCH SUBV SUBH SUBOSD CLP-MUTE RST YCBCRSWO MILD CONT DRCSUB SYNC SW BLOCK-S BLOCK-M SDA1 SCL1 9V 9V 5V 5V 3.3V 3.3V
CN1025 5V RESET VGA MUTE PR PB Y
DV/IRST DV/VGA DV/MUTE V7PR V7PB V7Y
L TO BC BOARD CN4601
M TO UD BOARD CN7002
CN1004 1 4.5V 2 4.5V 3 4.5V 4 4.5V
I TO G BOARD CN1603
3.3VC IC1005 +3.3V REG
BB3.3V IC1009 +3.3V REG
CN1005 1 5V 2 5V
J TO G BOARD CN1604
5V
CN1007 1 33V 2 17V 4 SUB 7V 5 POWER-CTL
K TO G BOARD CN1605
3.3VC 17V 15V IC1001 +15V REG
STBY 7V
STBY 5V 5 4 IC1010 REG
MS5V IC1901 +5V REG D1904
DSP5V IC1902 +5V REG D1905
CN1006 1 11V 2 11V 3 11V 4 11V
N TO G BOARD CN1613
9V IC1007 +9V REG
BB5V IC1002,1005 SWITCHING REGULATOR
CN1012 HV DET 12 GND 13 POW 6 FAN1 PR 8 FAN2 PR 10 FAN2 POW 9 LAMP CTL 1 LAMP PRT 3 LAMP COV 4
HV DET
FAN PRT
11V
FAN1
Q1006 REG
D1008
D1006
Q1007,1011 SWITCH
FAN1-H
FAN1-L
Q1008, D1012,1013 FAN CONTROL
FAN CTL
STBY 5V
FAN2
Q1004 REG
Q1006,1009 SWITCH
FAN2-H
FAN2-L
LANP CTL
LAMP PRT
LAMP COV
TO LAMP DRIVER L2
T (LAMP DOOR SW)
S8001
CN8001 3 LAMP COV
A (2/2) (AUDIO)

## BLOCK DIAGRAM (3)



## BLOCK DIAGRAM (4)



## BLOCK DIAGRAM (5)



## BLOCK DIAGRAM (6)



## BLOCK DIAGRAM (7)



## BLOCK DIAGRAM (8)









## BLOCK DIAGRAM (9)






**BLOCK DIAGRAM (10)**



## 4-2. FRAME SCHEMATIC DIAGRAM



## 4-3. CIRCUIT BOARDS LOCATION




## 4-4. SCHEMATIC DIAGRAMS AND PRINTED WIRING BOARDS

**Note:**

- The parts marked "#" on schematic diagrams are not mounted.
- All capacitors are in μF unless otherwise noted. (pF: μμF) Capacitors without voltage indication are all 50 V.
- Indication of resistance, which does not have one for rating electrical power, is as follows.

  Pitch: 5 mm
  Rating electrical power 1/4 W (CHIP : 1/10 W)

- All resistors are in ohms.
- : nonflammable resistor.
- : fusible resistor.
- △ : internal component.
- : panel designation, and adjustment for repair.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- : earth-ground.
- : earth-chassis.
- All voltages are in V.
- Readings are taken with a 10 MΩ digital multimeter.
- Readings are taken with a color-bar signal input.
- Voltage variations may be noted due to normal production tolerances.
- ✻ : Can not be measured.
- Circled numbers are waveform references.
- : B + bus.
- : B – bus.
- : Signal path.

•□Divided schematic diagram□

□ Schematic diagrams of A, BB, BC, M and U boards are divided □
□ into several pieces. Information to where the line is to be connected □
□ is printed at the end of each line.□
□ For example, [ **TO A1/3,A2/3_1** ] means the line is connected to □
□ Ref. No. 1 of A (1/3) and A (2/3) schematic diagrams.□

□ **TO A1/3,A2/3_1**□

□□ → Ref. No.□
□□ → Name of divided schematic diagram

**Reference information**

| | | |
|---|---|---|
| RESISTOR | : RN | METAL FILM |
| | : RC | SOLID |
| | : FPRD | NONFLAMMABLE CARBON |
| | : FUSE | NONFLAMMABLE FUSIBLE |
| | : RW | NONFLAMMABLE WIREWOUND |
| | : RS | NONFLAMMABLE METAL OXIDE |
| | : RB | NONFLAMMABLE CEMENT |
| COIL | : LF-8L | MICRO INDUCTOR |
| CAPACITOR | : TA | TANTALUM |
| | : PS | STYROL |
| | : PP | POLYPROPYLENE |
| | : PT | MYLAR |
| | : MPS | METALIZED POLYESTER |
| | : MPP | METALIZED POLYPROPYLENE |
| | : ALB | BIPOLAR |
| | : ALT | HIGH TEMPERATURE |
| | : ALR | HIGH RIPPLE |

**Note: The components identified by shading and mark ⚠ are critical for safety. Replace only with part number specified.**

**Terminal name of semiconductors in silk screen printed circuit (✻)**

| | Device | Printed symbol | Terminal name | Circuit |
|---|---|---|---|---|
| ① | Transistor | T | Collector / Base Emitter | |
| ② | Transistor | — | Collector / Base Emitter | |
| ③ | Diode | | Cathode — Anode | |
| ④ | Diode | T | Cathode / Anode (NC) | |
| ⑤ | Diode | — | Cathode / Anode (NC) | |
| ⑥ | Diode | T | Common / Anode Cathode | |
| ⑦ | Diode | — | Common / Anode Cathode | |
| ⑧ | Diode | T | Common / Anode Anode | |
| ⑨ | Diode | — | Common / Anode Anode | |
| ⑩ | Diode | T | Common / Cathode Cathode | |
| ⑪ | Diode | — | Common / Cathode Cathode | |
| ⑫ | Diode | \| | Anode Cathode / Anode Anode / Cathode Anode | |
| ⑬ | Transistor□ (FET) | \| | Drain Source / Gate | |
| ⑭ | Transistor□ (FET) | ⊢ | Drain Source / Gate | |
| ⑮ | Transistor□ (FET) | \| | □ Source / □ Drain / □ Gate | |
| ⑯ | Transistor | \| | □ Emitter / □ Collector / □ Base | |
| ⑰ | Transistor | ⫫ | C2 B1 E1 / E2 B2 C1 | |
| ⑱ | Transistor | ⫫ | C1 B2 E2 / E1 B1 C2 | |
| ⑲ | Transistor | ▬ | C1 B2 E2 / E1 B1 C2 | |
| ⑳ | Transistor | ▬ | C1 B2 E2 / E1 B1 C2 | |
| ㉑ | Transistor | ▬ | E2 B1 E1 / C2 C1(B2) | |
| ㉒ | Transistor | ▬ | (B2)□ / B1 E1 E2 / C1 C2 | |
| ㉓ | Transistor | ▬ | (B2)□ / E2 E1 B1 / C2 C1 | |
| – | Discrete semiconductot | | | |

(Chip semiconductors that are not actually used are included.)

Ver.1.5

(1) Schematic Diagram of A (1/4) Board



## (2) Schematic Diagram of A (2/4) Board



### (3) Schematic Diagram of A (3/4) Board


CN1025 11P :S-MICRO
CN1020 11P BUS CONNECTOR
CN1019 64P :B TO B TO BC BOARD
CN4601
TO M BOARD CN
CN1015 50P :B TO B
CN1018 40P :B TO B TO BB BOARD
CN2804
TO BB BOARD CN3203
CN1017 50P :B TO B
CN1016 50P :B TO B TO M BOARD CN
Q1016 2PD601AR
R1078 1k 1/10W :CHIP
R1077 47k 1/10W :CHIP
A (3/4)

(4) Schematic Diagram of A (4/4) Board



## (5) Schematic Diagram of BB (1/10) Board



## (6) Schematic Diagram of BB (2/10) Board



## (7) Schematic Diagram of BB (3/10) Board


1 2 3 4 5 6 7 8 9 10 11 12 13 14 15
A B C D E F G H I J
BB (3/10)
IC3408 CXD9509AQ
IC3401 μPC2925T-E1
IC3403 PST9120NL
IC3405
IC3406
IC3407
IC3607
IC5402 MT48LC2M32B2TG 64M-SDRAM
IC3411 TC7W04FU
IC3409 NJM2870F25 2.5V-REG
Q3401 2PD601AR
Q3403
Q3407
Q3409
Q3416 2PD601AR
Q3402 2SK2036 LEVEL-SHIFT
Q3404 2SK2036 LEVEL-SHIFT
Q3405
Q3406
Q3408
Q2819
Q2820
Q2821
D3401 DAN202K
D3402 DAP202K
X3401 16.9395MHz
TO BB 3/10 . BB 9/10 38 VSYNC
TO BB 3/10 . BB 5/10 36 SUBAD_CLVL
RST TO BB 2/10 . BB 3/10 . BB 4/10 . BB 8/10 34
DRC RESET TO BB 1/10 . BB 3/10 4
TO BB 3/10 . BB 9/10 71 DISABLE
TO BB 3/10 . BB 5/10 . BB 9/10 40 SUBAD_OUT
SEL Y/CR/CB TO BB 2/10 . BB 3/10 . BB 5/10 31
TO BB 1/10 . BB 3/10 10 XDRCVS
TO BB 1/10 . BB 3/10 11 XDRCHS
TO BB 1/10 . BB 3/10 24 DRC
DRCDCLK TO BB 1/10 . BB 3/10 25
B 3-4 TO BB 3/10 . BB 4/10 41
SCL_M3 TO BB 3/10 . BB 4/10 . BB 5/10 42
SDA_M3 TO BB 3/10 . BB 4/10 . BB 5/10 43
TO BB 3/10 . BB 4/10 . BB 6/10 . BB 7/10 45 MIO
DSPCLK TO BB 3/10 . BB 4/10 44
MIO VS TO BB 3/10 . BB 4/10 46
SUBAD_DOTCLK
SUBAD_PLLHOLD
SUBAD_EXTCLP
SUBAD_DSYNC
SEL Y OUT
SEL CB OUT
SEL CR OUT
MIO SYNC TO BB 2/10 . BB 3/10 . BB 4/10 32
HD3 TO BB 3/10 . BB 5/10 37
VD3

## (8) Schematic Diagram of BB (4/10) Board



## (9) Schematic Diagram of BB (5/10) Board



## (10) Schematic Diagram of BB (6/10) Board



## (11) Schematic Diagram of BB (7/10) Board


BB (7/10)
IC701 MCP RGB DECODER
IC704 INVERTER
IC706 INVERTER
IC705 BUFFER
IC703 SCP-DET
IC707 SCP-DET
IC2930 LM75CIMX-5
IC2805 74VHC123A
Q714 IK-DET
Q719 IK-DET
Q717 IK-DET
Q716 IK-DET
Q721 BUFFER
Q723 BUFFER
Q725 BUFFER
Q722
CN2804 40P WHT :B TO B TO A CN1018
TO BB 1/10 . BB 2/10 . BB 4/10 . BB 6/10 . BB 7/10 . BB 8/10 . BB 9/10 8(I(C
MID TO BB 3/10 . BB 4/10 . BB 6/10 . BB 7/10 45
TO BB 6/10 . BB 7/10 62 V5
TO BB 6/10 . BB 7/10 61 H5
Y TO BB 6/10 . BB 7/10 55
MID YS
MID CR
MID CB
R TO BB 6/10 . BB 7/10 63
G TO BB 6/10 . BB 7/10 64
B TO BB 6/10 . BB 7/10 65
H OUT TO BB 6/10 . BB 7/10 59
V OUT TO BB 6/10 . BB 7/10 60
5V-1 5V-2
SCP TO BB 6/10 . BB 7/10 53
OSD H TO BB 6/10 . BB 7/10 52
OSD V TO BB 6/10 . BB 7/10 54
OSD TO BB 6/10 . BB 7/10 58
TO BB 6/10 . BB 7/10 57 H DRV
TO BB 6/10 . BB 7/10 56 HP IN
9V
5V
5V H
YSYM
OSD B
OSD G
OSD R

## (12) Schematic Diagram of BB (8/10) Board



## (13) Schematic Diagram of BB (9/10) Board



(14) Schematic Diagram of BB (10/10) Board



## (15) Schematic Diagram of BC (1/5) Board



(16) Schematic Diagram of BC (2/5) Board


BC (2/5)
( Y/C SEP )
IC4801
μPD64083GF-3BA
3D COMB
IC4802
μPC2925T-E1
TO BC 2/5 . BC 3/5 16 3DRST
SIIC TO BC 1/5 . BC 2/5 . BC 3/5 . BC 4/5 . BC 5/5 8
3DV/YIN TO BC 1/5 . BC 2/5 4
3DC IN TO BC 1/5 . BC 2/5 17
TO BC 2/5 . BC 4/5 18 3DYOUT
3DCOUT TO BC 2/5 . BC 4/5 19

## (17) Schematic Diagram of BC (3/5) Board



(18) Schematic Diagrams of BC (4/5) Boards


BC (4/5)
( Y/C SEP )
IC4603
CXA2103AQ
YCT-MAIN
IC4604
TDA9178T
PIC.BOOST
Q4602 2PD601AR BUFF
Q4603 2PD601AR BUFF
Q4604 2PD601AR BUFF
Q4605 2PD601AR BUFF
Q4606 2PD601AR BUFF
Q4607 2PD601AR BUFF
Q4627 2PD601AR INV
Q4628 2PD601AR INV
Q4629 2PD601AR INV
Q4630 2PB709AR BUFF
Q4631 2PD601AR BUFF
Q4632 2PD601AR BUFF
Q4633 2PD601AR INV
Q4634 2PD601AR INV
Q4635 2PD601AR AMP
Q4636 2PB709AR AMP
Q4637 2PD601AR BUFF
Q4638 2PD601AR BUFF
Q4639 2PD601AR BUFF
Q4640 2PD601AR BUFFER
Q4641 2PD601AR BUFFER
Q4642 2PD601AR BUFFER
Q4643 2PB709AR
Q4644 2PB709AR
Q4645 2PB709AR
D4601 MA113 DROP
FL4604 7.2M
FL4605 2.6M
FL4606 2.6M
Y/PB/PR TO BC 1/5 . BC 4/5 2
V7 TO BC 1/5 . BC 4/5 5
SCBCRSW TO BC 1/5 . BC 4/5 24
CR 4-5 TO BC 4/5 . BC 5/5 35
CB 4-5 TO BC 4/5 . BC 5/5 36
Y 4-5 TO BC 4/5 . BC 5/5 37
5V 1-4
TO BC 1/5 . BC 4/5 14 B 1-4
MAINCC0 TO BC 3/5
MCC0IN TO BC 3/5
HTIM TO BC 4/5 . BC 5/5 33
VTIM TO BC 4/5 . BC 5/5 34
TO BC 2/5 . BC 4/5 19 3DCOUT
TO BC 2/5 . BC 4/5 18 3DYOUT
TO BC 1/5 . BC 2/5 . BC 3/5 . BC 4/5 . BC 5/5 8 SIIC

(19) Schematic Diagram of BC (5/5) Board


BC (5/5)
( Y/C SEP )
IC4607 NJM2283 YCT_SEL
IC4605 TC74LVX157FT MAIN/SUB
IC4606 TC74LVX157FT
IC4608 CXA2103AQ YCT-SUB
Q4611 2SA1037AK BUFF
X4603 3.58MHz
TO BC 3/5 . BC 5/5 30 SCCDIN
TO BC 1/5 . BC 5/5 12 SHD SVD
TO BC 3/5 . BC 5/5 29 SUBCCD
TO BC 1/5 . BC 5/5 15 Y
CR 4-5 TO BC 4/5 . BC 5/5 35
TO BC 4/5 . BC 5/5 37 Y 4-5
CB 4-5 TO BC 4/5 . BC 5/5 36
TO BC 4/5 . BC 5/5 34 VTIM
TO BC 1/5 . BC 5/5 25
TO BC 1/5 . BC 5/5 26
TO BC 1/5 . BC 5/5 13
TO BC 1/5 . BC 5/5 11 SELHOUT
TO BC 1/5 . BC 5/5 20 VDOHS
TO BC 1/5 . BC 5/5 7
TO BC 1/5 . BC 5/5 6
TO BC 1/5 . BC 5/5 1
HTIM TO BC 4/5 . BC 5/5 33
SELVOUT TO BC 1/5 . BC 5/5 10
VDOVS TO BC 1/5 . BC 5/5 21
B 1-5 TO BC 1/5 . BC 5/5 3
SIIC TO BC 1/5 . BC 2/5 . BC 3/5 . BC 4/5 . BC 5/5 8
DRCY
DRCCR
DRCCB
SUBY2
SUBC2
SUBY1
SUBC1
SUBY
SFSC
SUBDRC
MILD CONT
SYNCSW
VD HD
5V
3.3V

(20) Schematic Diagram of BF Board



## (21) Schematic Diagram of BM-1C (1/3) Board


BM1C (1/3)
IC101 (4/8) MD2406
IC101 (3/8) MD2406
IC101 (1/8) MD2406
IC102
IC116
IC118
D101 HN1D03FU
D102 HN1D03FU
Q110 DTC114EKA
CN104 60P WHT
TO BMIC 1/3, BMIC 2/3 1 F-RST
F-BSY TO BMIC 1/3, BMIC 2/3 2
VBLK TO BMIC 1/3, BMIC 2/3 3
PXOE TO BMIC 1/3, BMIC 2/3 4
TO BMIC 1/3, BMIC 2/3 5 MS_DIS
TO BMIC 1/3, BMIC 2/3 6 AD_DIS
TO BMIC 1/3, BMIC 2/3 7 SCL_EX
TO BMIC 1/3, BMIC 2/3 8 SDA_EX
TO BMIC 1/3, BMIC 2/3 9 TV_RST
TO BMIC 1/3, BMIC 2/3 10 POWER_INT

## (22) Schematic Diagram of BM-1C (2/3) Board



(23) Schematic Diagram of BM-1C (3/3) Board



## (24) Schematic Diagram of G Board


1 2 3 4 5 6 7 8 9 10 11 12 13 14
A B C D E F G H I J
CN1616 3P :VH
CN1614 3P WHT :S-MICRO
CN1617 3P YEL :S-MICRO TO LFT-SHIELD
CN1607 3P RED :S-MICRO TO HI BOARD CN4303
CN1609 1P TO H3 BOARD CN4504
CN1610 1P TO G-SHIELD
CN1611 1P TO C-SHIELD
TO LAMP BOARD
POWER SUPPLY UNIT
CN1602 3P :VH
CN1603 8P BLK :S-MICRO TO A BOARD
CN1604 4PWHT :VH TO A BOARD
CN1613 9P BLK :S-MICRO TO A BOARD
CN1605 5P WHT :S-MICRO TO A BOARD
CN1606 7P :S-MICRO TO A MOUNT
IC1601 MCZ3001D
IC1602 PC1093J-1-T 5V DET
T1601 PIT1
T1603 PIT1
T1605 CPDIFF
T1606 CPDIFF
RY1601 DLS5D1-O(M) 0.25W TV-8
VD1601 ERZV10D271
CN1608 CPDIFF TO TUNER
CN1601 2P WHT :VH-B
AC IN
F1601 6.3A 125V
FH1601
FH1602
TH1601 M22007
Q1601 2SK2663 CONVERTER
Q1602 2PD601AR PROTECT
Q1603 2PD601AR RELAY DRIVE
Q1604 2PB709AR OVP SW
Q1605 2PD601AR OVP SW
Q1606 IRFIB7N50A CONVERTER
Q1607 IRFIB7N50A CONVERTER
D1601 D2SB60A-F04 STBY RECT.
D1602 D6SB60L MAIN RECT
D1605 ERA22-08 SNUBBER
D1606 RD6.8M-T1B2
D1607 UF4005PKG23 PROT
D1610 D1N20R RECT.
D1612 S2L60F 270V RECT.
D1614 D1NS4 STBY7V RECT
D1619 RD5.6M-T1B2 OVP PROT
D1621 D2S6MTA1 17V RECT.
D1623 RCQ30A04 5V RECT.
D1624 D10SC6M AU-15V RECT.
D1625 D10SC6MR AU-15V RECT.
D1626 D10SC4M-F 4.5V RECT.
D1627 680p 1kV :HR
D1628 680p 1kV :HR
D1629 0.047 800V
D1631 MA111-TX PROT
D1632 0 :CHIP SW
D1633 ERC04-06SE
D1634 ERC04-06SE
D1635 S2L60F 270V RECT.
D1636 S2L60F 270V RECT.
D1638 MA111-TX PROT
D1639 0.1 25V B:CHIP
D1640 1.2 1W RS
D1641 JW(5)
D1642 JW(5)
D1643 JW(5)
D1644 JW(5)
D1645 JW(5)
D1646 JW(5)
D1647 470 :CHIP
D1648 JW(5)
D1649 JW(5)
D1650 JW(5)
D1651 JW(5)
D1652 JW(5)
D1653 JW(5)
D1654 JW(5)
D1655 JW(5)
D1656 JW(5)
D1657 JW(5)
D1658 JW(5)
D1659 JW(5)
D1660 JW(5)
D1661 JW(5)
D1662 JW(5)
D1663 JW(5)
D1664 JW(5)
D1665 JW(5)
D1666 JW(5)
D1667 JW(5)

(25) Schematic Diagram of H1, H2, H3 and T Board



## (26) Schematic Diagram of M (1/4) Board



## (27) Schematic Diagram of M (2/4) Board



## (28) Schematic Diagram of M (3/4) Board


M (3/4)
(MAIN CONTROL)
IC9509 TC7SH02FU-TE85R
IC9510 TC7SH32FU-TE85R
IC9502 MB94918RPF-G-148-BND
MB94P918PF
IC9504 M24C04-MN6T (A)
IC9505 PST9145NL RESET
IC9507 M24C08-MN6T (A)
IC9508 TC7SET08FU
Q9502 DTC114EKA
Q9506 2PB709AR
Q9509 2PB709AR LAMP CTL-4
Q9508 2PD601AR LAMP CTL-3
Q9507 2PD601AR LAMP CTL-2
Q9505 2PD601AR LAMP CTL-1
Q9510 2PD601AR
Q9511 DTA114EKA POW.5W
D9501 1SS355TE
D9502 02CZ5.6-TE85L
CN9501 50P TO A BOARD CN1015
B 3-4 A TO M 3/4.M 4/4 46
B 3-4 B TO M 3/4.M 4/4 47
SI TO M 3/4.M 4/4 48
E-POW WATCH TO M 1/4.M 3/4 34
R OUT TO M 3/4.M 4/4 49
G OUT TO M 3/4.M 4/4 50
B OUT TO M 3/4.M 4/4 51
YS TO M 3/4.M 4/4 52
OSD-H TO M 2/4.M 3/4 40
OSD-V TO M 2/4.M 3/4 41
E MUTE TO M 2/4.M 3/4 45
BINT TO M 1/4.M 3/4 33
CPU-RST TO M 1/4.M 3/4 28
TO M 1/4.M 3/4 30 SDA1
TO M 1/4.M 3/4 29 SCL1
TO M 1/4.M 3/4 19 E-POW CTL
TO M 3/4.M 4/4 53 DAT-R SEL
TO M 1/4.M 3/4 36 STBY-STR-LED
P ON TO M 1/4.M 3/4 37
SIRCS TO M 2/4.M 3/4 39
TIMER-LED TO M 1/4.M 3/4 35
KEY1 TO M 1/4.M 3/4 3
KEY2 TO M 1/4.M 3/4 5
MID-V TO M 2/4.M 3/4 42
MID-H TO M 2/4.M 3/4 43
SP MUTE TO M 2/4.M 3/4 44
SP-DC PROT TO M 1/4.M 3/4 32
BLANKING TO M 1/4.M 3/4 2
POWER-CTL TO M 1/4.M 3/4 18
TP9501
TP9502
TP9503
TP9504
x9501 20MHz
[A0]
[A8]

(29) Schematic Diagram of M (4/4) Board



## (30) Schematic Diagram of U (1/3) Board



(31) Schematic Diagrams of U (2/3) Boards

U (2/3)

(32) Schematic Diagram of U (3/3) Board



## (33) Schematic Diagram of UD (1/2) Board



## (34) Schematic Diagram of UD (2/2) Board



— A BOARD (Component Side) —




**A** [AUDIO OUT, TUNER, POWER SUPPLY]

## • A BOARD SEMICONDUCTOR LOCATION (Component Side)

| IC | |
|---|---|
| IC1001 | I-7 |
| IC1002 | H-9 |
| IC1004 | C-9 |
| IC1005 | J-10 |
| IC1006 | D-8 |
| IC1007 | H-8 |
| IC1009 | I-9 |
| IC1010 | J-8 |
| IC1011 | A-5 |
| IC1012 | A-4 |
| IC1013 | A-4 |
| IC1014 | I-9 |
| IC1015 | H-9 |
| IC1901 | C-9 |
| IC1902 | I-3 |

| TRANSISTOR | | * |
|---|---|---|
| Q1006 | D-8 | ② |
| Q1007 | D-9 | ② |
| Q1009 | D-8 | ② |
| Q1011 | D-9 | ② |
| Q1017 | B-8 | ② |
| Q1018 | B-7 | ② |
| Q1020 | B-7 | ② |
| Q1021 | B-8 | ② |
| Q1025 | C-8 | ② |
| Q1026 | B-6 | ② |
| Q1027 | B-7 | ② |

| DIODE | | * |
|---|---|---|
| D1011 | H-9 | |
| D1012 | D-9 | ③ |
| D1022 | A-5 | ③ |
| D1023 | A-4 | ③ |
| D1025 | C-8 | ③ |
| D1027 | B-7 | ③ |
| D1028 | B-7 | ⑨ |
| D1904 | I-7 | |
| D1905 | I-5 | |

*: Refer to Terminal name of semiconductors in silk screen printed circuit (see page 81)

— A BOARD (Conductor Side) —




**A** AUDIO OUT, TUNER, POWER SUPPLY

## • A BOARD SEMICONDUCTOR LOCATION (Conductor Side)

| IC | | |
|---|---|---|
| IC1001 | I-4 | |
| IC1002 | H-2 | |
| IC1004 | C-2 | |
| IC1005 | J-1 | |
| IC1006 | D-3 | |
| IC1009 | I-2 | |
| IC1014 | B-7 | |
| IC1015 | B-2 | |
| IC1902 | I-8 | |

| TRANSISTOR | | |
|---|---|---|
| | | ✻ |
| Q1003 | D-5 | ① |
| Q1004 | D-5 | ① |
| Q1005 | H-1 | ① |
| Q1008 | D-2 | ① |
| Q1010 | C-6 | ① |
| Q1012 | D-4 | ① |
| Q1013 | C-5 | ① |
| Q1015 | D-5 | ① |
| Q1016 | F-5 | ① |
| Q1019 | B-8 | ① |
| Q1022 | C-8 | ① |
| Q1023 | C-3 | ① |
| Q1024 | C-3 | ① |
| Q1028 | D-6 | ① |
| Q1029 | C-5 | ① |

| DIODE | | |
|---|---|---|
| | | ✻ |
| D1003 | E-2 | ③ |
| D1004 | C-2 | ③ |
| D1006 | D-1 | ③ |
| D1007 | J-1 | ③ |
| D1008 | C-1 | ③ |
| D1011 | H-3 | |
| D1013 | D-2 | ③ |
| D1015 | H-4 | ③ |
| D1020 | I-2 | ③ |
| D1030 | F-4 | ④ |
| D1031 | F-4 | ③ |
| D1904 | I-4 | |
| D1905 | I-8 | |
| D1906 | E-6 | ③ |

✻: Refer to Terminal name of semiconductors in silk screen printed circuit (see page 81)

# BB [DRC, AMDP, MID-X]

**— BB BOARD (Component Side) —**




**・ BB BOARD SEMICONDUCTOR LOCATION (Component Side)**

| IC | |
|---|---|
| IC2801 | C-6 |
| IC2802 | C-1 |
| IC2803 | C-1 |
| IC2805 | B-5 |
| IC2930 | A-6 |
| IC3002 | F-8 |
| IC3003 | G-7 |
| IC3004 | F-8 |
| IC3090 | C-8 |
| IC3302 | F-8 |
| IC3303 | F-6 |
| IC3408 | F-4 |
| IC3409 | E-3 |
| IC3410 | E-5 |
| IC3411 | E-4 |
| IC3601 | F-2 |
| IC3602 | H-2 |
| IC3605 | E-2 |
| IC3606 | F-2 |
| IC3609 | E-2 |
| IC8601 | G-2 |

| TRANSISTOR | | * |
|---|---|---|
| Q2822 | B-6 | ② |
| Q2823 | B-7 | ② |
| Q2949 | B-5 | ② |
| Q2950 | B-5 | ② |
| Q2951 | C-9 | ② |
| Q2952 | C-9 | ② |
| Q2953 | C-9 | ② |
| Q2954 | C-9 | ② |
| Q2959 | C-5 | ② |
| Q2960 | C-5 | ② |
| Q2961 | C-5 | ② |
| Q2962 | C-5 | ② |
| Q2964 | C-4 | ② |
| Q2966 | C-5 | ② |
| Q3306 | H-9 | ② |
| Q3307 | G-9 | ② |
| Q3308 | H-9 | ② |
| Q3309 | G-9 | ② |
| Q3310 | H-8 | ② |
| Q3311 | G-8 | ② |
| Q3410 | D-6 | ② |
| Q3411 | D-9 | ② |
| Q3412 | E-9 | ② |
| Q3413 | E-9 | ② |
| Q3414 | D-6 | ② |
| Q3415 | E-6 | ② |
| Q3601 | H-2 | ② |
| Q8601 | G-2 | ② |
| Q8602 | H-2 | ② |
| Q8603 | H-2 | ② |
| Q8606 | G-1 | ② |
| Q8607 | H-1 | ② |
| Q8608 | H-1 | ② |

| DIODE | | * |
|---|---|---|
| D3001 | G-7 | ③ |
| D3002 | F-8 | ③ |
| D3402 | E-4 | ⑪ |
| D3603 | D-2 | ③ |

**✻: Refer to Terminal name of semiconductors in silk screen printed circuit (see page 81)**

# BB [DRC, AMDP, MID-X]

— BB BOARD (Conductor Side) —




## • BB BOARD SEMICONDUCTOR LOCATION (Conductor Side)

| IC | | |
|---|---|---|
| IC2804 | B-6 | |
| IC3001 | H-4 | |
| IC3089 | B-3 | |
| IC3091 | B-3 | |
| IC3301 | F-4 | |
| IC3306 | F-5 | |
| IC3401 | F-7 | |
| IC3402 | F-8 | |
| IC3403 | E-7 | |
| IC3603 | E-9 | |
| IC3604 | F-9 | |
| IC3608 | G-3 | |

| TRANSISTOR | | * |
|---|---|---|
| Q2805 | B-6 | ② |
| Q2806 | B-6 | ② |
| Q2807 | C-6 | ② |
| Q2808 | B-6 | ② |
| Q2809 | C-6 | ② |
| Q2955 | C-6 | ② |
| Q2956 | C-6 | ② |
| Q2957 | C-6 | ② |
| Q2958 | C-6 | ② |
| Q2963 | B-7 | ② |
| Q2965 | B-7 | ② |
| Q2967 | B-7 | ② |
| Q2968 | D-4 | ② |
| Q2969 | C-5 | ② |
| Q2970 | C-5 | ② |
| Q2971 | C-6 | ② |
| Q2972 | C-6 | ② |
| Q2973 | C-7 | ② |
| Q2974 | C-6 | ② |
| Q2975 | C-6 | ② |
| Q2976 | C-6 | ② |
| Q2978 | C-7 | ② |
| Q2979 | C-7 | ② |
| Q3003 | F-4 | ② |
| Q3008 | G-3 | ② |
| Q3009 | F-2 | ② |
| Q3089 | C-3 | ② |
| Q3090 | C-3 | ② |
| Q3092 | B-4 | ② |
| Q3093 | B-4 | ② |
| Q3302 | F-5 | ② |
| Q3303 | G-6 | ② |
| Q3305 | F-5 | ② |
| Q3401 | H-9 | ② |
| Q3402 | E-8 | ⑮ |
| Q3404 | E-8 | ⑮ |
| Q3416 | E-7 | ② |
| Q3417 | E-3 | ② |
| Q3418 | E-2 | ② |
| Q3419 | E-3 | ② |
| Q3420 | E-2 | ② |
| Q3421 | E-3 | ② |
| Q3422 | E-2 | ② |
| Q3906 | E-4 | ⑮ |
| Q3907 | E-4 | ⑮ |
| Q8604 | F-9 | ② |
| Q8605 | G-9 | ② |
| Q8609 | G-9 | ② |

| DIODE | | * |
|---|---|---|
| D2803 | B-5 | ③ |
| D3089 | C-3 | ⑥ |
| D3090 | C-3 | ⑥ |
| D3309 | E-4 | ⑧ |
| D3310 | E-4 | ⑩ |
| D3401 | E-8 | ⑧ |
| D3403 | B-4 | ② |
| D3404 | C-3 | ② |
| D3601 | E-9 | ⑦ |

*: Refer to Terminal name of semiconductors in silk screen printed circuit (see page 81)

# BC [ VIDEO SELECT ]

— BC BOARD (Component Side) —




• BC BOARD SEMICONDUCTOR LOCATION (Component Side)

| IC | | |
|---|---|---|
| IC4601 | F-1 | |
| IC4602 | G-3 | |
| IC4603 | D-8 | |
| IC4604 | F-6 | |
| IC4605 | G-8 | |
| IC4606 | G-9 | |
| IC4607 | G-9 | |
| IC4608 | B-8 | |
| IC4801 | C-4 | |
| IC4802 | C-6 | |
| IC4803 | C-11 | |
| IC4804 | E-11 | |

| TRANSISTOR | | |
|---|---|---|
| | | ✻ |
| Q4601 | B-2 | ② |
| Q4602 | E-8 | ② |
| Q4603 | E-9 | ② |
| Q4604 | E-9 | ② |
| Q4605 | F-8 | ② |
| Q4606 | E-8 | ② |
| Q4607 | E-9 | ② |
| Q4608 | F-3 | ② |
| Q4609 | F-2 | ② |
| Q4610 | F-3 | ② |
| Q4611 | G-10 | ② |
| Q4612 | F-4 | ② |
| Q4615 | G-2 | ② |
| Q4616 | G-3 | ② |
| Q4620 | F-3 | ② |
| Q4624 | E-3 | ② |
| Q4627 | E-6 | ② |
| Q4628 | E-6 | ② |
| Q4629 | E-7 | ② |
| Q4630 | E-6 | ② |
| Q4631 | E-6 | ② |
| Q4632 | E-6 | ② |
| Q4633 | F-5 | ② |
| Q4634 | G-6 | ② |
| Q4635 | F-6 | ② |
| Q4636 | G-6 | ② |
| Q4637 | G-5 | ② |
| Q4638 | G-6 | ② |
| Q4639 | G-7 | ② |
| Q4640 | G-7 | ② |
| Q4641 | G-6 | ② |
| Q4642 | F-7 | ② |
| Q4643 | G-7 | ② |
| Q4644 | G-5 | ② |
| Q4645 | G-7 | ② |
| Q4802 | C-6 | ② |
| Q4803 | B-4 | ② |
| Q4804 | B-3 | ② |
| Q4807 | B-3 | ② |
| Q4809 | B-3 | ② |
| Q4811 | B-4 | ② |
| Q4812 | B-5 | ② |
| Q4814 | B-5 | ② |
| Q4815 | B-4 | ② |
| Q4816 | B-6 | ② |
| Q4818 | B-3 | ② |
| Q4819 | B-5 | ② |
| Q4821 | E-10 | ② |
| Q4822 | C-9 | ② |

| DIODE | | |
|---|---|---|
| | | ✻ |
| D4801 | C-10 | ⑨ |
| D4802 | E-10 | ⑨ |
| D4803 | B-9 | ⑪ |
| D4804 | C-9 | ⑪ |

✻: Refer to Terminal name of semiconductors in silk screen printed circuit (see page 81)

# BC [VIDEO SELECT]

— BC BOARD (Conductor Side) —




· BC BOARD SEMICONDUCTOR LOCATION (Conductor Side)

| TRANSISTOR | | * |
|---|---|---|
| Q4617 | G-10 | ① |
| Q4618 | G-10 | ① |
| Q4619 | G-9 | ① |
| Q4621 | D-9 | ① |
| Q4622 | F-10 | ① |
| Q4623 | F-10 | ① |
| Q4625 | D-10 | ① |
| Q4626 | G-9 | ① |
| Q4646 | F-10 | ① |
| Q4647 | F-8 | ① |
| Q4801 | D-9 | ① |
| Q4805 | B-8 | ① |
| Q4806 | B-9 | ① |
| Q4808 | B-4 | ① |
| Q4810 | C-7 | ① |
| Q4813 | B-7 | ① |
| Q4817 | B-8 | ① |
| Q4820 | F-10 | ① |
| Q4823 | E-3 | ① |
| Q4824 | B-3 | ① |
| Q4825 | D-3 | ① |
| Q4826 | C-3 | ① |
| Q4827 | C-3 | ① |

| DIODE | | * |
|---|---|---|
| D4601 | F-7 | ③ |
| D4602 | G-4 | ③ |
| D4603 | G-4 | ③ |

*: Refer to Terminal name of semiconductors in silk screen printed circuit (see page 81)

# BF [MEMORY STICK]

— BF BOARD (Component Side) —




— BF BOARD (Conductor Side) —



# BM-1C [RAM]

— BM-1C BOARD (Component Side) —




— BM-1C BOARD (Conductor Side) —



# G ［POWER SUPPLY］

— G BOARD (Component Side) —




## ・ G BOARD SEMICONDUCTOR LOCATION (Component Side)

| IC | |
|---|---|
| IC1601 | D-7 |
| IC1602 | B-6 |
| **PHOTOCOUPLER** | |
| PH1601 | C-6 |
| **TRANSISTOR** | |
| Q1601 | G-5 |
| Q1606 | E-8 |
| Q1607 | F-6 |
| **DIODE** | |
| D1601 | G-6 |
| D1602 | I-8 |
| D1605 | G-5 |
| D1607 | D-7 |
| D1608 | C-3 |
| D1609 | D-6 |
| D1610 | F-5 |
| D1612 | C-3 |
| D1613 | G-3 |
| D1614 | G-4 |
| D1616 | G-3 |
| D1617 | G-3 |
| D1620 | F-3 |
| D1621 | D-2 |
| D1623 | E-3 |
| D1624 | B-5 |
| D1625 | C-5 |
| D1626 | F-2 |
| D1633 | H-9 |
| D1634 | H-8 |
| D1635 | C-3 |
| D1636 | C-3 |

## G [POWER SUPPLY]

— G BOARD (Conductor Side) —




### • G BOARD SEMICONDUCTOR LOCATION (Conductor Side)

| IC | | |
|---|---|---|
| IC1601 | D-7 | |
| IC1602 | B-6 | |
| **PHOTOCOUPLER** | | |
| PH1601 | B-4 | |
| **TRANSISTOR** | | |
| Q1601 | G-5 | |
| Q1602 | F-5 | ① |
| Q1603 | C-9 | ① |
| Q1604 | C-8 | ① |
| Q1605 | C-8 | ① |
| Q1606 | E-3 | |
| Q1607 | F-4 | |
| **DIODE** | | |
| D1601 | G-4 | |
| D1602 | I-3 | |
| D1603 | F-5 | ④ |
| D1604 | G-6 | ③ |
| D1605 | G-5 | |
| D1606 | F-6 | ④ |
| D1607 | D-4 | |
| D1608 | C-6 | |
| D1609 | D-4 | |
| D1610 | F-5 | |
| D1612 | C-7 | |
| D1613 | F-8 | |
| D1614 | G-7 | |
| D1616 | F-8 | |
| D1617 | F-7 | |
| D1618 | C-8 | ③ |
| D1619 | C-8 | ④ |
| D1620 | F-7 | |
| D1621 | D-8 | |
| D1623 | E-7 | |
| D1624 | B-6 | |
| D1625 | C-5 | |
| D1626 | F-8 | |
| D1629 | G-6 | ③ |
| D1630 | G-6 | ③ |
| D1631 | H-4 | ③ |
| D1632 | D-4 | ③ |
| D1633 | H-1 | |
| D1634 | H-2 | |
| D1635 | C-7 | |
| D1636 | C-8 | |
| D1638 | D-4 | ③ |

✻: Refer to Terminal name of semiconductors in silk screen printed circuit (see page 81)

## H1 [VIDEO 2 IN]

**— H1 BOARD (Component Side) —**




**— H1 BOARD (Conductor Side) —**




## T [LAMP DOOR SWITCH]

**— T BOARD (Component Side) —**




**— T BOARD (Conductor Side) —**



# H2 [KEY IN]

— H2 BOARD (Component Side) —




— H2 BOARD (Conductor Side) —



# H3 [ SIRCS, POWER SWITCH ]

**— H3 BOARD (Component Side) —**




**— H3 BOARD (Conductor Side) —**



# M [MAINCONTROL]

— M BOARD (Component Side) —




— M BOARD (Conductor Side) —




## · M BOARD SEMICONDUCTOR LOCATION

| IC | (Component Side) | (Conductor Side) |
|---|---|---|
| IC9001 | E-2 | |
| IC9002 | F-2 | |
| IC9004 | E-3 | |
| IC9005 | G-4 | |
| IC9007 | F-4 | |
| IC9008 | G-2 | |
| IC9009 | E-4 | |
| IC9010 | F-4 | |
| IC9011 | G-4 | |
| IC9012 | F-4 | |
| IC9013 | C-5 | |
| IC9014 | D-5 | |
| IC9015 | H-2 | |
| IC9016 | D-4 | |
| IC9017 | D-5 | |
| IC9502 | C-3 | |
| IC9503 | B-3 | |
| IC9504 | B-4 | |
| IC9505 | C-4 | |
| IC9506 | B-3 | |
| IC9507 | B-4 | |
| IC9508 | B-4 | |
| IC9509 | B-3 | |
| IC9510 | B-3 | |
| IC9514 | B-2 | |
| IC9515 | C-2 | |

| TRANSISTOR | (Component Side) | (Conductor Side) | ✻ |
|---|---|---|---|
| Q9003 | | F-10 | ① |
| Q9004 | | D-7 | ① |
| Q9005 | | F-10 | ① |
| Q9006 | E-6 | | |
| Q9007 | | C-7 | ① |
| Q9008 | | C-7 | ① |
| Q9009 | | C-7 | ① |
| Q9010 | | C-7 | ① |
| Q9011 | | C-7 | ① |
| Q9012 | | E-8 | ① |
| Q9013 | | C-9 | ① |
| Q9014 | | C-7 | ① |
| Q9015 | | C-8 | ① |
| Q9016 | G-4 | | |
| Q9017 | | F-9 | ① |
| Q9018 | | C-9 | ① |
| Q9019 | E-5 | | |
| Q9020 | G-3 | | |
| Q9021 | | E-9 | ① |
| Q9022 | | F-8 | ① |
| Q9023 | | G-8 | ① |
| Q9025 | F-2 | | |
| Q9026 | F-2 | | |
| Q9027 | | G-10 | ① |
| Q9028 | D-2 | | |
| Q9029 | D-2 | | |
| Q9502 | B-2 | | |
| Q9505 | | C-9 | ① |
| Q9506 | C-3 | | |
| Q9507 | D-2 | | |
| Q9508 | D-2 | | |
| Q9509 | D-3 | | |
| Q9510 | B-5 | | |
| Q9511 | B-5 | | |
| Q9516 | B-5 | | |
| Q9517 | B-5 | | |
| Q9518 | | C-7 | ① |
| Q9519 | C-5 | | |
| Q9520 | C-5 | | |
| Q9521 | C-5 | | |
| Q9522 | | C-7 | ① |
| Q9523 | | C-7 | ① |
| Q9524 | | C-7 | ① |
| Q9525 | | C-7 | ① |
| Q9526 | | C-7 | ① |
| Q9527 | | C-7 | ① |

| DIODE | (Component Side) | (Conductor Side) | ✻ |
|---|---|---|---|
| D9001 | G-3 | | ⑨ |
| D9002 | G-3 | | ⑪ |
| D9004 | F-3 | | ⑨ |
| D9005 | G-3 | | ⑪ |
| D9008 | D-4 | | ⑨ |
| D9012 | F-4 | | ③ |
| D9013 | E-5 | | ③ |
| D9014 | H-2 | | ③ |
| D9015 | | H-10 | ③ |
| D9016 | E-5 | | ③ |
| D9017 | E-4 | | ⑨ |
| D9018 | F-4 | | ⑨ |
| D9019 | F-2 | | ③ |
| D9020 | | G-10 | ③ |
| D9021 | | G-10 | ③ |
| D9022 | | E-7 | ③ |
| D9023 | G-2 | | ③ |
| D9024 | G-2 | | ③ |
| D9025 | G-2 | | ③ |
| D9026 | | H-10 | ③ |
| D9027 | | H-10 | ③ |
| D9028 | | G-11 | ③ |
| D9029 | | H-11 | ③ |
| D9030 | E-4 | | ③ |
| D9031 | E-4 | | ③ |
| D9032 | E-8 | | ③ |
| D9033 | E-8 | | ③ |
| D9501 | D-2 | | ③ |
| D9502 | D-2 | | ⑤ |
| D9503 | C-7 | | ③ |

✻: Refer to Terminal name of semiconductors in silk screen printed circuit (see page 81)

# U [INPUT SELECT]

— U BOARD (Component Side) —




## • U BOARD SEMICONDUCTOR LOCATION (Component Side)

| IC | | |
|---|---|---|
| IC2001 | G-2 | |
| IC2002 | F-3 | |
| IC2003 | F-6 | |
| IC2500 | E-10 | |
| IC2502 | E-9 | |
| IC2503 | G-8 | |
| IC2504 | G-10 | |

| TRANSISTOR | | * |
|---|---|---|
| Q2001 | G-3 | ② |
| Q2007 | F-1 | ② |
| Q2008 | F-2 | ② |
| Q2011 | F-5 | ② |
| Q2012 | F-4 | ② |
| Q2013 | G-5 | ② |
| Q2014 | G-4 | ② |
| Q2015 | G-4 | ② |
| Q2016 | F-3 | ② |
| Q2017 | G-3 | ② |
| Q2018 | G-4 | ② |
| Q2019 | G-4 | ② |
| Q2021 | F-3 | ② |
| Q2023 | E-3 | ② |
| Q2025 | E-3 | ② |
| Q2502 | D-10 | ② |
| Q2503 | D-10 | ② |
| Q2504 | E-10 | ② |
| Q2506 | E-7 | ② |

| DIODE | | |
|---|---|---|
| D2015 | F-4 | ③ |
| D2017 | F-4 | ③ |
| D2029 | E-6 | ③ |

*: Refer to Terminal name of semiconductors in silk screen printed circuit (see page 81)

# U [INPUT SELECT]

— U BOARD (Conductor Side) —




· U BOARD SEMICONDUCTOR LOCATION (Conductor Side)

| TRANSISTOR | | |
|---|---|---|
| | | * |
| Q2002 | B-3 | ① |
| Q2003 | A-3 | ① |
| Q2004 | B-3 | ① |
| Q2005 | B-3 | ① |
| Q2006 | A-3 | ① |
| Q2009 | B-1 | ① |
| Q2010 | C-1 | ① |
| Q2020 | D-6 | ① |
| Q2022 | D-6 | ① |
| Q2024 | D-6 | ① |
| Q2500 | D-10 | ① |
| Q2501 | D-10 | ① |
| Q2505 | C-10 | ① |
| Q2507 | D-7 | ① |
| Q2508 | D-7 | ① |

| DIODE | | |
|---|---|---|
| | | * |
| D2001 | F-4 | ③ |
| D2002 | C-2 | ③ |
| D2003 | B-2 | ③ |
| D2004 | F-2 | ③ |
| D2005 | F-2 | ③ |
| D2006 | E-2 | ③ |
| D2007 | D-1 | ③ |
| D2008 | D-1 | ③ |
| D2009 | F-3 | ③ |
| D2010 | F-3 | ③ |
| D2011 | G-3 | ③ |
| D2012 | E-3 | ③ |
| D2013 | C-2 | ③ |
| D2014 | C-2 | ③ |
| D2016 | C-4 | ③ |
| D2018 | E-6 | ③ |
| D2019 | D-6 | ③ |
| D2020 | F-7 | ③ |
| D2027 | C-5 | ③ |
| D2028 | C-4 | ③ |
| D2030 | D-5 | ③ |
| D2031 | F-8 | ③ |
| D2032 | G-7 | ③ |
| D2033 | F-8 | ③ |
| D2034 | F-9 | ③ |
| D2035 | C-7 | ③ |
| D2036 | C-7 | ③ |
| D2500 | D-10 | ③ |

*: Refer to Terminal name of semiconductors in silk screen printed circuit (see page 81)

# UD

[DVI-HDTV VIDEO INPUT]

— UD BOARD (Component Side) —




— UD BOARD (Conductor Side) —




- **U BOARD SEMICONDUCTOR LOCATION (Component Side)**

| IC | | |
|---|---|---|
| IC7001 | H-2 | |
| IC7002 | B-3 | |
| IC7003 | H-3 | |
| IC7004 | F-4 | |
| IC7005 | C-3 | |
| IC7006 | E-3 | |
| IC7007 | E-2 | |
| IC7008 | G-2 | |
| IC7009 | G-2 | |
| **DIODE** | | |
| D7001 | H-2 | ⑨ |
| D7002 | E-10 | ③ |
| D7003 | E-9 | ③ |
| D7004 | H-1 | ③ |
| D7006 | E-2 | ③ |

✻: Refer to Terminal name of semiconductors in silk screen printed circuit (see page 81)

## 4-5. WAVEFORMS

### • BC (1/5) BOARD WAVEFORMS




### • BC (4/5) BOARD WAVEFORMS




### • BC (2/5) BOARD WAVEFORMS




### • BC (3/5) BOARD WAVEFORMS




### • M (1/4) BOARD WAVEFORMS




### • M (3/4) BOARD WAVEFORMS



## 4-6. IC BLOCK DIAGRAMS

- **BB (8/10) BOARD IC3608**
  **TLC2932IPWR**




- **BC (1/5) BOARD IC4601**
  **CXA2171Q**




- **BC (4/5) BOARD IC4603**
- **BC (5/5) BOARD IC4608**
  **CXA2103AQ**




- **U (1/3) BOARD IC2001**
  **CXD2073Q**



• **BC (4/5) BOARD IC4604**
**TDA9178T**



## 4-7 SEMICONDUCTORS

**74VHC123ASJX**

16 pins SOP

**BA05T**



**CXA2069Q**
**CXA2170Q**




TOP VIEW

**CXA2103Q**
**CXA2171Q**
**CXD2309AQ**




48 pins QFP

**CXA3506R**




144 pins QFP

**CXD2073Q**




32 pins QFP

**CXD2097Q**




208 pins QFP

**CXD9509AQ**




240 pins QFP

**CXP964032-001Q**
**M306VSMG-501FP**
**MB94918RPF-G-148-BND**
**MB94918RPF-G-155-BND**
**TC90A90F(BH, DLY)**
**UPD64083GF-3BA**




**DS90LV028ATMX**
**LM75CIMX-5**
**M24C04-MN6T**
**M24C08-MN6T**
**M24C32-WMN6T(A)**
**NJM4558E(TE2)**
**TC7W04FU-TE12R**
**UPC4558G2**




8 pins SOP

**HY57V161610DTC-7TR**




50pins SOJ

**IS41C16256-35K**




40 pins SOP

**M52055FP**
**TLC2932IPWR**
**TLC2933IPWR-12**




14 pins SOP

**MC14052BFEL**
**MC74LVX8053DR2**
**NJM2283V-TE1**
**SN65LVDS31DR**
**TC74LVX157FT (EL)**




16pins SOP

**MCZ3001D**

18 pins DIP

**MT48LC2M32B2TG-7**




86pins SOP

**NJM78L12AUA-TE1**



**NJM79L12UA(TE1)**




**PQ07VZ012ZP**



**PQ09RF21**




**PQ30RV11**
**PQ30RV31**




**PST593C-MMP-4P**




4 pins CHIP

**PST9129NL**
**PST9143NL**
**PST9145NL**
**SN74CBTLV1G125DCKR**
**TC7SET00FU(TE85L)**
**TC7SET08FU(TE85L)**
**TC7SET32FU(TE85L)**
**TC7SH02FU**
**TC7SH08FU(TE85L)**
**TC7SH32FU(TE85R)**
**TC7SZ125FU(TE85R)**
**TC7SZ126FU(TE85R)**




5 pins CHIP

**SBX1971-51P**




**TC94A04F014**




60 pins QFP

**TDA7269A**



**TDA9178T/N1.118**




24 pins SOP

**UPC1093J-1-T**




**2SA1037AK-T146-QR**
**2SA1162-G**
**2SA1226**
**2SA1576A-T106-R**
**2SC2223-F13**
**2SC4081T106R**
**2SD601A-Q-TX**
**DTA114EKA-T146**
**DTC114EK**
**DTC144EKA**




**2SK2036(TE85L)**




**02CZ5.6-TE85L**
**RD15M-T1B2**
**RD5.1M-T1B2**
**RD5.6M-B2**
**RD6.8M-B2**
**RD6.8M-T1B2**




**1SS355TE-17**
**DTZ-TT11-6.8B**
**MA111-TX**
**MA113-(TX)**
**UDZS-TE17-5.6B**
**UDZ-TE-17-10B**
**UDZ-TE-17-3.9B**




**D10SC4M**
**D10SC6M**
**D5S4M**




**D10SC6MR**




**D1NL20U-TR**
**D2S6MTA1**




**D1NS4-TA2**




**D2SB60A**
**D6SB60L**




**DAN202K**
**DAN202U**




**DAP202K**
**DAP202U**




**ERA22-08**
**ERC04-06SE**




**MA153-TX**




**S2L60F**
**UF4005PKG23**




**SLR-325VCT31**




**TLR124**



# SECTION 5
# EXPLODED VIEWS

NOTE:
- Items with no part number and no description are not stocked because they are seldom required for routine service.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

The components identified by shading and mark [ ! ] are critical for safety. Replace only with part number specified.

Les composants identifi□s par un tram□ et une marque [ ! ] sont critiques pour la s□curit□. Ne les remplacer que par une pi□ce portant le num□ro sp□cifi□.

- The mark ⚠ is shown as the letter " ! " in the parts list.

## 5-1. SCREEN MIRROR BLOCK SECTION




| REF. NO. | PART NO. | DESCRIPTION | REMARK |
|---|---|---|---|
| 1 | * A-1603-612-A | SCREEN MIRROR BLOCK ASSY (IRP) | (60XBR800) |
| 1 | * A-1603-626-A | SCREEN MIRROR BLOCK ASSY (IRP) | (50XBR800) |
| 2 | * X-4040-879-1 | COVER (60) ASSY, REAR (60XBR800) | |
| 2 | * X-4040-882-1 | COVER (50) ASSY, REAR (50XBR800) | |
| 3 | 4-054-709-01 | STRIKE (60XBR800) | |
| 3 | 4-083-567-01 | STRIKE (50XBR800) | |
| 4 | * X-4039-925-1 | COVER (R) ASSY, FRONT (60XBR800) | |
| 4 | * X-4040-046-3 | COVER (R) ASSY, FRONT (50XBR800) | |
| 5 | * X-4039-924-1 | COVER (L) ASSY, FRONT (60XBR800) | |
| 5 | * X-4040-045-3 | COVER (L) ASSY, FRONT (50XBR800) | |
| 6 | 4-838-453-00 | SUPPORT (50XBR800) | |
| #1 | 7-685-663-79 | SCREW +BVTP 4X16 TYPE2 IT-3 | |
| #2 | 7-685-648-79 | SCREW +BVTP 3X12 TYPE2 IT-3 | |
| #3 | 7-685-247-19 | SCREW +KTP 3X10 TYPE2 NON-SLIT | (50XBR800) |

## 5-2. CABINET SECTION

The components identified by shading and mark [ ! ] are critical for safety. Replace only with part number specified.

Les composants identifi s par un tram et une marque [ ! ] sont critiques pour la s curit . Ne les remplacer que par une pi ce portant le num ro sp cifi .

Note :
No.108, 115 and 121 are supplied only for the model KF-50XBR800.




| REF. NO. | | PART NO. | DESCRIPTION | REMARK |
|---|---|---|---|---|
| 101 | * | X-4040-877-2 | BRACKET ASSY, H2 (60XBR800) | |
| 101 | * | X-4040-880-2 | DOOR ASSY, CONTROL (50XBR800) | |
| 102 | | 4-045-250-01 | DAMPER | |
| 103 | * | A-1401-407-A | H2 BOARD, COMPLETE | |
| 104 | * | X-4040-878-1 | BRACKET ASSY, H3 (60XBR800) | |
| 104 | * | X-4040-881-3 | BRACKET ASSY, CONTROL (50XBR800) | |
| 105 | | 4-086-268-02 | BUTTON, POWER | |
| 106 | * | 4-086-269-01 | GUIDE, LED | |
| 107 | * | A-1401-408-A | H3 BOARD, COMPLETE | |
| 108 | | X-4041-056-1 | COVER ASSY, FRONT PANEL (50XBR800) | |
| 109 | | 4-091-144-01 | CATCH, PUSH (50XBR800) | |
| 109 | | 4-374-714-01 | CATCH, PUSH (60XBR800) | |
| 110 | * | 4-082-919-02 | PLATE, FRONT | |
| 111 | * | A-1401-410-A | BF BOARD, COMPLETE | |
| 112 | | 4-077-652-01 | CUSHION (A) | |

| REF. NO. | | PART NO. | DESCRIPTION | REMARK |
|---|---|---|---|---|
| 113 | | 4-077-654-01 | CUSHION (C) | |
| 114 | | 4-077-653-01 | CUSHION (B) | |
| 115 | * | 4-082-940-03 | BRACKET, OU (50XBR800) | |
| 116 | * | 3-650-537-00 | WASHER | |
| 117 | * | X-4040-874-3 | DOOR ASSY, LAMP | |
| 118 | | 4-082-951-12 | PEDESTAL (50XBR800) | |
| 118 | * | 4-086-252-11 | PEDESTAL (60F) (60XBR800) | |
| 119 | ! | A-1601-753-A | LAMP BLOCK ASSY (RP) | |
| 120 | * | X-4040-876-1 | BRACKET ASSY, BF | |
| 121 | * | X-4038-931-1 | PLATE ASSY, FOOT (50XBR800) | |
| 121 | | X-4039-771-3 | PLATE (L) ASSY, FOOT (60XBR800) | |
| 121 | | X-4039-772-2 | PLATE (S) ASSY, FOOT (60XBR800) | |
| #1 | | 7-685-663-79 | SCREW +BVTP 4X16 TYPE2 IT-3 | |
| #2 | | 7-685-648-79 | SCREW +BVTP 3X12 TYPE2 IT-3 | |
| #4 | | 7-685-661-14 | SCREW +BVTP 4X12 TYPE2 IT-3 | |

## 5-3. MAIN SECTION




The components identified by shading and mark [ ! ] are critical for safety. Replace only with part number specified.

Les composants identifi□s par un tram□ et une marque [ ! ] sont critiques pour la s□curit□. Ne les remplacer que par une pi□ce portant le num□ro sp□cifi□.

| REF. NO. | | PART NO. | DESCRIPTION | REMARK |
|---|---|---|---|---|
| 151 | | X-4040-875-1 | LID ASSY, H1 | |
| 152 | | 3-703-035-11 | SHAFT, LID | |
| 153 | | X-4039-767-1 | BRACKET ASSY, H1 | |
| 154 | * | A-1401-405-A | H1 BOARD, COMPLETE | |
| 155 | | 4-029-432-01 | SCREW (3X12), (+) BVWHTP | |
| 156 | * | A-1300-695-A | G BOARD, COMPLETE | |
| 157 | * | A-1300-696-A | BB BOARD, COMPLETE | |
| 158 | * | A-1300-697-A | BC BOARD, COMPLETE | |
| 159 | * | A-1300-324-A | UD BOARD, COMPLETE | |
| 160 | * | A-1300-698-A | A BOARD, COMPLETE | |
| 161 | * | A-1300-700-A | U BOARD, COMPLETE | |
| 162 | | 4-089-699-02 | BOARD, TERMINAL | |
| 164 | | 1-771-787-13 | SWITCH, RF ANTENNA | |

| REF. NO. | | PART NO. | DESCRIPTION | REMARK |
|---|---|---|---|---|
| 165 | * | 1-557-056-31 | CABLE, P-P | |
| 166 | * | A-1300-699-A | M BOARD, COMPLETE | |
| 167 | ! | 1-769-837-11 | CORD, POWER (WITH NOISE FILTER) | |
| 168 | * | A-1401-406-A | T BOARD, COMPLETE | |
| 169 | | 4-069-675-01 | CAP, TERMINAL BOARD | |
| 170 | * | 4-034-856-01 | HOLDER, HV CABLE | |
| 171 | | 1-419-661-11 | COIL, CHOKE 4.0MMH | |
| 172 | * | 4-089-698-01 | BRACKET, MAIN | |
| 173 | * | 4-089-700-01 | BRACKET, M | |
| 174 | * | A-1300-650-A | BM1C BOARD, COMPLETE | |
| #1 | | 7-685-663-79 | SCREW +BVTP 4X16 TYPE2 IT-3 | |
| #2 | | 7-685-648-79 | SCREW +BVTP 3X12 TYPE2 IT-3 | |

## 5-4. OPTICAL UNIT SECTION




The components identified by shading and mark [ ! ] are critical for safety. Replace only with part number specified.

Les composants identifi s par un tram et une marque [ ! ] sont critiques pour la s curit . Ne les remplacer que par une pi ce portant le num ro sp cifi .

| REF. NO. | | PART NO. | DESCRIPTION | REMARK |
|---|---|---|---|---|
| 201 | ! * | A-1603-611-A | OPTICS UNIT BLOCK ASSY (IRP) | (60XBR800) |
| 201 | ! * | A-1603-624-A | OPTICS UNIT BLOCK ASSY (IRP) | (50XBR800) |
| 202 | | 1-500-386-11 | FILTER, CLAMP (FERRITE CORE) | |
| 203 | ! | 1-698-696-21 | FAN, DC | |
| 204 | ! | 1-468-510-13 | POWER BLOCK | |
| 205 | | 4-029-432-01 | SCREW (3X12), (+) BVWHTP | |
| 206 | * | 4-078-590-01 | TAPE | |
| 207 | | 4-314-843-02 | SCREW, TAPPINNG, +4X12 | |
| 208 | ! | 1-900-253-70 | CONNECTOR ASSY, SMP-B 2P | |
| 209 | | 1-500-603-11 | CLAMP, FERRITE (50XBR800) | |
| 209 | | 1-543-653-11 | CORE ASSY, BEAD(DIVISION TYPE) (60XBR800) | |
| 210 | | 4-077-706-01 | BRACKET, FAN | |
| #1 | | 7-685-663-79 | SCREW +BVTP 4X16 TYPE2 IT-3 | |
| #2 | | 7-685-648-79 | SCREW +BVTP 3X12 TYPE2 IT-3 | |
| #5 | | 7-685-167-19 | SCREW (WASHER HEAD) (+P 4X35) | |

A

# SECTION 6
# ELECTRICAL PARTS LIST

The components identified by shading and mark [ ! ] are critical for safety. Replace only with part number specified.

Les composants identifi□s par un tram□ et une marque [ ! ] sont critiques pour la s□curit□. Ne les remplacer que par une pi□ce portant le num□ro sp□cifi□.

- The mark ⚠ is shown as the letter " ! " in the parts list.

When indicating parts by reference number, please include the board name.

- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- RESISTORS
  All resistors are in ohms
  F : nonflammable
- CAPACITORS
  PF : μμF
- There are some cases the reference number on one board overlaps on the other board. Therefore, when ordering parts by the reference number, please include the board name.

| REF. NO. | PART NO. | DESCRIPTION | | | | REMARK |
|---|---|---|---|---|---|---|
| | * A-1300-698-A | A BOARD, COMPLETE | | | | |
| | | ********** | | | | |
| | * 4-032-770-81 | HEAT SINK, V-OUT | | | | |
| | 4-382-854-01 | SCREW (M3X8), P, SW (+) | | | | |
| | | <CAPACITOR> | | | | |
| C1004 | 1-104-665-11 | ELECT | 100μF | 20% | 25V | |
| C1005 | 1-126-964-11 | ELECT | 10μF | 20% | 50V | |
| C1006 | 1-162-966-11 | CERAMIC CHIP | 0.0022μF | 10% | 50V | |
| C1008 | 1-126-967-11 | ELECT | 47μF | 20% | 50V | |
| C1009 | 1-162-966-11 | CERAMIC CHIP | 0.0022μF | 10% | 50V | |
| C1010 | 1-162-966-11 | CERAMIC CHIP | 0.0022μF | 10% | 50V | |
| C1011 | 1-104-665-11 | ELECT | 100μF | 20% | 25V | |
| C1013 | 1-126-964-11 | ELECT | 10μF | 20% | 50V | |
| C1014 | 1-104-665-11 | ELECT | 100μF | 20% | 25V | |
| C1016 | 1-126-935-11 | ELECT | 470μF | 20% | 16V | |
| C1019 | 1-126-933-11 | ELECT | 100μF | 20% | 16V | |
| C1020 | 1-104-665-11 | ELECT | 100μF | 20% | 25V | |
| C1022 | 1-104-665-11 | ELECT | 100μF | 20% | 25V | |
| C1023 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V | |
| C1025 | 1-126-964-11 | ELECT | 10μF | 20% | 50V | |
| C1026 | 1-162-927-11 | CERAMIC CHIP | 100pF | 5% | 50V | |
| C1027 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V | |
| C1029 | 1-126-941-11 | ELECT | 470μF | 20% | 25V | |
| C1032 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V | |
| C1033 | 1-104-665-11 | ELECT | 100μF | 20% | 25V | |
| C1034 | 1-115-156-11 | CERAMIC CHIP | 1μF | | 10V | |
| C1035 | 1-126-947-11 | ELECT | 47μF | 20% | 25V | |
| C1037 | 1-162-966-11 | CERAMIC CHIP | 0.0022μF | 10% | 50V | |
| C1039 | 1-126-916-11 | ELECT | 1000μF | 20% | 6.3V | |
| C1040 | 1-126-947-11 | ELECT | 47μF | 20% | 25V | |
| C1041 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V | |
| C1042 | 1-164-344-11 | CERAMIC CHIP | 0.068μF | 10% | 25V | |
| C1043 | 1-162-966-11 | CERAMIC CHIP | 0.0022μF | 10% | 50V | |
| C1044 | 1-126-933-11 | ELECT | 100μF | 20% | 16V | |
| C1045 | 1-165-176-11 | CERAMIC CHIP | 0.047μF | 10% | 16V | |
| C1046 | 1-162-961-11 | CERAMIC CHIP | 330pF | 10% | 50V | |
| C1048 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V | |
| C1050 | 1-126-960-11 | ELECT | 1μF | 20% | 50V | |
| C1051 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V | |
| C1053 | 1-162-966-11 | CERAMIC CHIP | 0.0022μF | 10% | 50V | |
| C1054 | 1-162-966-11 | CERAMIC CHIP | 0.0022μF | 10% | 50V | |
| C1055 | 1-126-933-11 | ELECT | 100μF | 20% | 16V | |
| C1056 | 1-162-966-11 | CERAMIC CHIP | 0.0022μF | 10% | 50V | |
| C1057 | 1-126-933-11 | ELECT | 100μF | 20% | 16V | |
| C1058 | 1-126-933-11 | ELECT | 100μF | 20% | 16V | |
| C1059 | 1-126-767-11 | ELECT | 1000μF | 20% | 16V | |
| C1062 | 1-126-926-11 | ELECT | 1000μF | 20% | 10V | |
| C1063 | 1-126-942-61 | ELECT | 1000μF | 20% | 25V | |
| C1065 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 16V | |
| C1066 | 1-162-966-11 | CERAMIC CHIP | 0.0022μF | 10% | 50V | |
| C1069 | 1-126-935-11 | ELECT | 470μF | 20% | 16V | |
| C1070 | 1-162-927-11 | CERAMIC CHIP | 100pF | 5% | 50V | |
| C1071 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V | |
| C1072 | 1-126-964-11 | ELECT | 10μF | 20% | 50V | |
| C1073 | 1-162-966-11 | CERAMIC CHIP | 0.0022μF | 10% | 50V | |
| C1074 | 1-115-156-11 | CERAMIC CHIP | 1μF | | 10V | |
| C1075 | 1-126-933-11 | ELECT | 100μF | 20% | 16V | |
| C1078 | 1-126-933-11 | ELECT | 100μF | 20% | 16V | |
| C1079 | 1-165-176-11 | CERAMIC CHIP | 0.047μF | 10% | 16V | |
| C1080 | 1-162-961-11 | CERAMIC CHIP | 330pF | 10% | 50V | |
| C1082 | 1-126-926-11 | ELECT | 1000μF | 20% | 10V | |
| C1084 | 1-126-960-11 | ELECT | 1μF | 20% | 50V | |
| C1085 | 1-126-960-11 | ELECT | 1μF | 20% | 50V | |
| C1087 | 1-126-964-11 | ELECT | 10μF | 20% | 50V | |
| C1088 | 1-104-665-11 | ELECT | 100μF | 20% | 25V | |
| C1089 | 1-126-964-11 | ELECT | 10μF | 20% | 50V | |
| C1090 | 1-126-964-11 | ELECT | 10μF | 20% | 50V | |
| C1091 | 1-126-964-11 | ELECT | 10μF | 20% | 50V | |
| C1092 | 1-104-665-11 | ELECT | 100μF | 20% | 25V | |
| C1093 | 1-137-374-11 | MYLAR | 0.047μF | 5% | 50V | |
| C1094 | 1-126-964-11 | ELECT | 10μF | 20% | 50V | |
| C1095 | 1-137-374-11 | MYLAR | 0.047μF | 5% | 50V | |
| C1096 | 1-137-374-11 | MYLAR | 0.047μF | 5% | 50V | |
| C1097 | 1-137-374-11 | MYLAR | 0.047μF | 5% | 50V | |
| C1098 | 1-126-964-11 | ELECT | 10μF | 20% | 50V | |
| C1099 | 1-126-964-11 | ELECT | 10μF | 20% | 50V | |
| C1100 | 1-126-965-91 | ELECT | 22μF | 20% | 50V | |
| C1101 | 1-126-965-91 | ELECT | 22μF | 20% | 50V | |
| C1102 | 1-126-947-11 | ELECT | 47μF | 20% | 16V | |
| C1105 | 1-126-964-11 | ELECT | 10μF | 20% | 50V | |
| C1106 | 1-126-964-11 | ELECT | 10μF | 20% | 50V | |
| C1107 | 1-126-964-11 | ELECT | 10μF | 20% | 50V | |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| C1110 | 1-107-703-11 | ELECT | 220μF | 20% | 25V |
| C1112 | 1-126-960-11 | ELECT | 1μF | 20% | 50V |
| C1113 | 1-136-165-00 | FILM | 0.1μF | 5% | 50V |
| C1114 | 1-136-165-00 | FILM | 0.1μF | 5% | 50V |
| C1115 | 1-126-942-61 | ELECT | 1000μF | 20% | 25V |
| C1116 | 1-136-165-00 | FILM | 0.1μF | 5% | 50V |
| C1117 | 1-107-703-11 | ELECT | 220μF | 20% | 25V |
| C1118 | 1-136-165-00 | FILM | 0.1μF | 5% | 50V |
| C1119 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C1120 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C1121 | 1-128-548-11 | ELECT | 4700μF | 20% | 25V |
| C1122 | 1-128-548-11 | ELECT | 4700μF | 20% | 25V |
| C1123 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C1124 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C1125 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C1126 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C1127 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |
| C1128 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |
| C1129 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |
| C1130 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |
| C1131 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |
| C1132 | 1-127-515-11 | ELECT | 47μF | 20% | 10V |
| C1908 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C1910 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |
| C1911 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C1912 | 1-126-937-11 | ELECT | 4700μF | 20% | 16V |
| C1917 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |
| C1918 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C1919 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |

<CONNECTOR>

| | | | |
|---|---|---|---|
| CN1001 * | 1-764-333-11 | PLUG, CONNECTOR 10P | |
| CN1002 * | 1-564-512-11 | PLUG, CONNECTOR 9P | |
| CN1003 * | 1-564-515-11 | PLUG, CONNECTOR 12P | |
| CN1004 | 1-564-511-11 | PLUG, CONNECTOR 8P | |
| CN1005 * | 1-580-838-11 | PIN, CONNECTOR (PC BOARD) 4P | |
| CN1006 * | 1-564-512-11 | PLUG, CONNECTOR 9P | |
| CN1007 * | 1-564-508-11 | PLUG, CONNECTOR 5P | |
| CN1008 | 1-695-915-11 | TAB (CONTACT) | |
| CN1009 | 1-695-915-11 | TAB (CONTACT) | |
| CN1010 | 1-695-915-11 | TAB (CONTACT) | |
| CN1011 | 1-695-915-11 | TAB (CONTACT) | |
| CN1012 * | 1-564-516-11 | PLUG, CONNECTOR 13P | |
| CN1013 * | 1-564-515-11 | PLUG, CONNECTOR 12P | |
| CN1014 * | 1-564-507-11 | PLUG, CONNECTOR 4P | |
| CN1015 * | 1-793-495-11 | CONNECTOR, BOARD TO BOARD 50P | |
| CN1016 * | 1-793-495-11 | CONNECTOR, BOARD TO BOARD 50P | |
| CN1017 * | 1-793-495-11 | CONNECTOR, BOARD TO BOARD 50P | |
| CN1018 * | 1-793-494-11 | CONNECTOR, BOARD TO BOARD 40P | |
| CN1019 * | 1-793-922-11 | CONNECTOR, DIN (RECEPTACLE)64P | |
| CN1020 | 1-764-812-11 | CONNECTOR, BOARD TO BOARD 11P | |
| CN1021 * | 1-793-922-11 | CONNECTOR, DIN (RECEPTACLE)64P | |
| CN1023 * | 1-564-511-11 | PLUG, CONNECTOR 8P | |
| CN1024 * | 1-564-510-11 | PLUG, CONNECTOR 7P | |
| CN1025 * | 1-764-334-11 | PLUG, CONNECTOR 11P | |

| REF. NO. | PART NO. | DESCRIPTION | REMARK |
|---|---|---|---|
| | | <DIODE> | |
| D1003 | 8-719-404-50 | DIODE MA111-TX | |
| D1004 | 8-719-404-50 | DIODE MA111-TX | |
| D1006 | 8-719-404-50 | DIODE MA111-TX | |
| D1007 | 8-719-404-50 | DIODE MA111-TX | |
| D1008 | 8-719-404-50 | DIODE MA111-TX | |
| D1011 | 8-719-500-70 | DIODE D5S4M | |
| D1012 | 8-719-404-50 | DIODE MA111-TX | |
| D1013 | 8-719-404-50 | DIODE MA111-TX | |
| D1015 | 8-719-404-50 | DIODE MA111-TX | |
| D1016 | 8-719-106-17 | DIODE RD6.8M-T1B2 | |
| D1020 | 8-719-404-50 | DIODE MA111-TX | |
| D1022 | 8-719-404-50 | DIODE MA111-TX | |
| D1023 | 8-719-404-50 | DIODE MA111-TX | |
| D1025 | 8-719-404-50 | DIODE MA111-TX | |
| D1027 | 8-719-404-50 | DIODE MA111-TX | |
| D1028 | 8-719-914-43 | DIODE DAN202K | |
| D1030 | 8-719-105-91 | DIODE RD5.6M-T1B2 | |
| D1031 | 8-719-404-50 | DIODE MA111-TX | |
| D1904 | 8-719-063-73 | DIODE D1NL20U-TR | |
| D1905 | 8-719-063-73 | DIODE D1NL20U-TR | |
| D1906 | 8-719-404-50 | DIODE MA111-TX | |
| | | <IC> | |
| IC1001 | 8-759-098-24 | IC PQ30RV11 | |
| IC1002 | 8-759-640-19 | IC PQ1CG2032FZ | |
| IC1004 | 8-759-098-24 | IC PQ30RV11 | |
| IC1005 | 8-759-284-06 | IC PQ30RV31 | |
| IC1006 | 8-759-098-24 | IC PQ30RV11 | |
| IC1007 | 8-759-198-03 | IC PQ09RF21 | |
| IC1009 | 8-759-284-06 | IC PQ30RV31 | |
| IC1010 | 8-759-663-29 | IC MM1476AF(TP) | |
| IC1011 | 8-759-712-00 | IC NJM79L12UA(TE1) | |
| IC1012 | 8-759-175-30 | IC NJM78L12UA-TE1 | |
| IC1013 | 8-759-100-96 | IC μPC4558G2 | |
| IC1014 | 8-759-590-05 | IC TDA7269A | |
| IC1015 | 8-759-590-05 | IC TDA7269A | |
| IC1901 | 8-759-450-47 | IC BA05T | |
| IC1902 | 8-759-450-47 | IC BA05T | |
| | | <COIL> | |
| L1001 | 1-469-320-21 | INDUCTOR 100μH | |
| L1002 | 1-469-320-21 | INDUCTOR 100μH | |
| L1004 | 1-469-317-21 | INDUCTOR 10μH | |
| L1007 | 1-406-662-11 | INDUCTOR 33μH | |
| L1008 | 1-469-320-21 | INDUCTOR 100μH | |
| L1009 | 1-469-320-21 | INDUCTOR 100μH | |
| L1010 | 1-469-317-21 | INDUCTOR 10μH | |
| L1011 | 1-406-975-21 | INDUCTOR 47μH | |
| L1012 | 1-406-977-21 | INDUCTOR 100μH | |
| | | <TRANSISTOR> | |
| Q1003 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q1004 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| Q1005 | 8-729-422-33 | TRANSISTOR | 2SD601A-Q-TX | | |
| Q1006 | 8-729-900-53 | TRANSISTOR | DTC114EK | | |
| Q1007 | 8-729-900-53 | TRANSISTOR | DTC114EK | | |
| Q1008 | 8-729-900-53 | TRANSISTOR | DTC114EK | | |
| Q1009 | 8-729-900-53 | TRANSISTOR | DTC114EK | | |
| Q1010 | 8-729-422-33 | TRANSISTOR | 2SD601A-Q-TX | | |
| Q1011 | 8-729-900-53 | TRANSISTOR | DTC114EK | | |
| Q1012 | 8-729-216-22 | TRANSISTOR | 2SA1162-G | | |
| Q1013 | 8-729-422-33 | TRANSISTOR | 2SD601A-Q-TX | | |
| Q1015 | 8-729-422-33 | TRANSISTOR | 2SD601A-Q-TX | | |
| Q1016 | 8-729-422-33 | TRANSISTOR | 2SD601A-Q-TX | | |
| Q1017 | 8-729-422-33 | TRANSISTOR | 2SD601A-Q-TX | | |
| Q1018 | 8-729-422-33 | TRANSISTOR | 2SD601A-Q-TX | | |
| Q1019 | 8-729-422-33 | TRANSISTOR | 2SD601A-Q-TX | | |
| Q1020 | 8-729-422-33 | TRANSISTOR | 2SD601A-Q-TX | | |
| Q1021 | 8-729-422-33 | TRANSISTOR | 2SD601A-Q-TX | | |
| Q1022 | 8-729-422-33 | TRANSISTOR | 2SD601A-Q-TX | | |
| Q1023 | 8-729-422-33 | TRANSISTOR | 2SD601A-Q-TX | | |
| Q1024 | 8-729-422-33 | TRANSISTOR | 2SD601A-Q-TX | | |
| Q1025 | 8-729-216-22 | TRANSISTOR | 2SA1162-G | | |
| Q1026 | 8-729-422-33 | TRANSISTOR | 2SD601A-Q-TX | | |
| Q1027 | 8-729-216-22 | TRANSISTOR | 2SA1162-G | | |
| Q1028 | 8-729-422-33 | TRANSISTOR | 2SD601A-Q-TX | | |
| Q1029 | 8-729-216-22 | TRANSISTOR | 2SA1162-G | | |
| | | <RESISTOR> | | | |
| R1001 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R1002 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R1003 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R1005 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R1007 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R1008 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R1009 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R1010 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R1011 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R1012 | 1-216-839-11 | METAL CHIP | 33K | 5% | 1/10W |
| R1013 | 1-218-738-11 | METAL CHIP | 82K | 0.5% | 1/10W |
| R1014 | 1-218-742-11 | METAL CHIP | 120K | 0.5% | 1/10W |
| R1015 | 1-218-718-11 | METAL CHIP | 12K | 0.5% | 1/10W |
| R1016 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R1017 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R1018 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R1019 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |
| R1020 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R1021 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R1022 | 1-216-847-11 | METAL CHIP | 150K | 5% | 1/10W |
| R1023 | 1-216-857-11 | METAL CHIP | 1M | 5% | 1/10W |
| R1025 | 1-216-847-11 | METAL CHIP | 150K | 5% | 1/10W |
| R1026 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R1027 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R1029 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R1030 | 1-218-728-11 | METAL CHIP | 33K | 0.5% | 1/10W |
| R1031 | 1-218-712-11 | METAL CHIP | 6.8K | 0.5% | 1/10W |
| R1032 | 1-216-823-11 | METAL CHIP | 1.5K | 5% | 1/10W |
| R1033 | 1-218-724-11 | METAL CHIP | 22K | 0.5% | 1/10W |
| R1035 | 1-218-726-11 | METAL CHIP | 27K | 0.5% | 1/10W |
| R1036 | 1-218-718-11 | METAL CHIP | 12K | 0.5% | 1/10W |
| R1039 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R1040 | 1-218-718-11 | METAL CHIP | 12K | 0.5% | 1/10W |
| R1041 | 1-218-722-11 | METAL CHIP | 18K | 0.5% | 1/10W |
| R1042 | 1-218-724-11 | METAL CHIP | 22K | 0.5% | 1/10W |
| R1043 | 1-218-742-11 | METAL CHIP | 120K | 0.5% | 1/10W |
| R1045 | 1-218-697-11 | METAL CHIP | 1.6K | 0.5% | 1/10W |
| R1046 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R1047 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R1048 | 1-218-724-11 | METAL CHIP | 22K | 0.5% | 1/10W |
| R1049 | 1-218-685-11 | METAL CHIP | 510 | 0.5% | 1/10W |
| R1051 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R1053 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R1055 | 1-218-720-11 | METAL CHIP | 15K | 0.5% | 1/10W |
| R1056 | 1-218-718-11 | METAL CHIP | 12K | 0.5% | 1/10W |
| R1057 | 1-216-827-11 | METAL CHIP | 3.3K | 5% | 1/10W |
| R1058 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R1059 | 1-216-847-11 | METAL CHIP | 150K | 5% | 1/10W |
| R1060 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R1061 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |
| R1062 | 1-216-839-11 | METAL CHIP | 33K | 5% | 1/10W |
| R1063 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R1064 | 1-216-847-11 | METAL CHIP | 150K | 5% | 1/10W |
| R1065 | 1-216-857-11 | METAL CHIP | 1M | 5% | 1/10W |
| R1066 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R1067 | 1-216-823-11 | METAL CHIP | 1.5K | 5% | 1/10W |
| R1068 | 1-218-722-11 | METAL CHIP | 18K | 0.5% | 1/10W |
| R1069 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R1070 | 1-218-742-11 | METAL CHIP | 120K | 0.5% | 1/10W |
| R1071 | 1-218-718-11 | METAL CHIP | 12K | 0.5% | 1/10W |
| R1072 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R1073 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R1074 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R1075 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R1076 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R1077 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R1078 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R1079 | 1-218-776-11 | RES-CHIP | 1M | 5% | 1/10W |
| R1080 | 1-218-776-11 | RES-CHIP | 1M | 5% | 1/10W |
| R1081 | 1-240-090-21 | RES-CHIP | 39K | 5% | 1/10W |
| R1082 | 1-240-090-21 | RES-CHIP | 39K | 5% | 1/10W |
| R1083 | 1-240-091-21 | RES-CHIP | 47K | 5% | 1/10W |
| R1084 | 1-240-091-21 | RES-CHIP | 47K | 5% | 1/10W |
| R1085 | 1-216-832-11 | METAL CHIP | 8.2K | 5% | 1/10W |
| R1086 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R1087 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R1088 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R1089 | 1-216-832-11 | METAL CHIP | 8.2K | 5% | 1/10W |
| R1090 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R1091 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |
| R1092 | 1-216-813-11 | METAL CHIP | 220 | 5% | 1/10W |
| R1093 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R1094 | 1-216-813-11 | METAL CHIP | 220 | 5% | 1/10W |
| R1095 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R1096 | 1-216-813-11 | METAL CHIP | 220 | 5% | 1/10W |
| R1097 | 1-216-813-11 | METAL CHIP | 220 | 5% | 1/10W |
| R1098 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |

| | | | | | |
|---|---|---|---|---|---|
| R1099 | 1-240-067-21 | RES-CHIP | 470 | 5% | 1/10W |
| R1100 | 1-240-067-21 | RES-CHIP | 470 | 5% | 1/10W |
| R1101 | 1-216-815-11 | METAL CHIP | 330 | 5% | 1/10W |
| R1102 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R1103 | 1-216-815-11 | METAL CHIP | 330 | 5% | 1/10W |
| R1104 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R1105 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R1106 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R1107 | 1-216-071-00 | RES-CHIP | 8.2K | 5% | 1/10W |
| R1108 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R1109 | 1-216-071-00 | RES-CHIP | 8.2K | 5% | 1/10W |
| R1110 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R1111 | 1-216-075-00 | RES-CHIP | 12K | 5% | 1/10W |
| R1112 | 1-240-067-21 | RES-CHIP | 470 | 5% | 1/10W |
| R1113 | 1-216-025-11 | RES-CHIP | 100 | 5% | 1/10W |
| R1114 | 1-218-722-11 | METAL CHIP | 18K | 0.5% | 1/10W |
| R1115 | 1-240-067-21 | RES-CHIP | 470 | 5% | 1/10W |
| R1116 | 1-218-722-11 | METAL CHIP | 18K | 0.5% | 1/10W |
| R1117 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R1118 | 1-216-049-11 | RES-CHIP | 1K | 5% | 1/10W |
| R1119 | 1-240-067-21 | RES-CHIP | 470 | 5% | 1/10W |
| R1120 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R1121 | 1-218-722-11 | METAL CHIP | 18K | 0.5% | 1/10W |
| R1123 | 1-240-067-21 | RES-CHIP | 470 | 5% | 1/10W |
| R1124 | 1-218-722-11 | METAL CHIP | 18K | 0.5% | 1/10W |
| R1125 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R1126 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R1127 | 1-216-830-11 | METAL CHIP | 5.6K | 5% | 1/10W |
| R1128 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R1129 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R1130 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R1131 | 1-218-867-11 | METAL CHIP | 6.8K | 5% | 1/10W |
| R1133 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R1135 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R1136 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R1137 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R1138 | 1-216-357-00 | METAL OXIDE | 4.7 | 5% | 1W |
| R1139 | 1-216-357-00 | METAL OXIDE | 4.7 | 5% | 1W |
| R1140 | 1-216-357-00 | METAL OXIDE | 4.7 | 5% | 1W |
| R1141 | 1-216-357-00 | METAL OXIDE | 4.7 | 5% | 1W |
| R1142 | 1-249-389-11 | CARBON | 4.7 | 5% | 1/4W |
| R1143 | 1-216-849-11 | METAL CHIP | 220K | 5% | 1/10W |
| R1146 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R1147 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R1148 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R1154 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R1156 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R1157 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R1158 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R1159 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R1906 | 1-216-393-00 | METAL OXIDE | 2.2 | 5% | 3W |
| R1907 | 1-216-393-00 | METAL OXIDE | 2.2 | 5% | 3W |

<TUNER>

| | | |
|---|---|---|
| TU1001 | 8-598-594-10 | TUNER, FSS BTF-FA421 |
| TU1002 | 8-598-593-20 | TUNER, FSS BTF-WA421 |

**********

* A-1300-696-A BB BOARD, COMPLETE
**********

<CAPACITOR>

| | | |
|---|---|---|
| | 4-080-345-01 | SHEET (A), RADIATION |
| | 4-382-854-01 | SCREW (M3X8), P, SW (+) |

<CAPACITOR>

| | | | | | |
|---|---|---|---|---|---|
| C2804 | 1-162-923-11 | CERAMIC CHIP | 47pF | 5% | 50V |
| C2806 | 1-125-891-11 | CERAMIC CHIP | 0.47μF | 10% | 10V |
| C2807 | 1-125-837-91 | CERAMIC CHIP | 1μF | 10% | 6.3V |
| C2808 | 1-126-601-11 | ELECT CHIP | 2.2μF | 20% | 50V |
| C2809 | 1-117-681-11 | ELECT CHIP | 100μF | 20% | 16V |
| C2810 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2811 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C2812 | 1-125-891-11 | CERAMIC CHIP | 0.47μF | 10% | 10V |
| C2813 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2814 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2815 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2816 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2817 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2821 | 1-117-681-11 | ELECT CHIP | 100μF | 20% | 16V |
| C2822 | 1-117-681-11 | ELECT CHIP | 100μF | 20% | 16V |
| C2823 | 1-117-681-11 | ELECT CHIP | 100μF | 20% | 16V |
| C2824 | 1-117-681-11 | ELECT CHIP | 100μF | 20% | 16V |
| C2826 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C2827 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C2829 | 1-162-968-11 | CERAMIC CHIP | 0.0047μF | 10% | 50V |
| C2831 | 1-117-681-11 | ELECT CHIP | 100μF | 20% | 16V |
| C2833 | 1-127-715-91 | CERAMIC CHIP | 0.22μF | 10% | 16V |
| C2834 | 1-125-891-11 | CERAMIC CHIP | 0.47μF | 10% | 10V |
| C2835 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C2836 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C2837 | 1-117-681-11 | ELECT CHIP | 100μF | 20% | 16V |
| C2840 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2841 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2844 | 1-117-681-11 | ELECT CHIP | 100μF | 20% | 16V |
| C2846 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2850 | 1-117-681-11 | ELECT CHIP | 100μF | 20% | 16V |
| C2851 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C2852 | 1-126-204-11 | ELECT CHIP | 47μF | 20% | 16V |
| C2853 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2854 | 1-124-779-00 | ELECT CHIP | 10μF | 20% | 16V |
| C2855 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2856 | 1-126-204-11 | ELECT CHIP | 47μF | 20% | 16V |
| C2857 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2858 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2859 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C2861 | 1-164-388-91 | CERAMIC CHIP | 270pF | 5% | 50V |
| C2863 | 1-164-388-91 | CERAMIC CHIP | 270pF | 5% | 50V |

**BB**

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| C2931 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2932 | 1-124-779-00 | ELECT CHIP | 10μF | 20% | 16V |
| C2951 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C2952 | 1-126-204-11 | ELECT CHIP | 47μF | 20% | 16V |
| C2953 | 1-162-925-11 | CERAMIC CHIP | 68pF | 5% | 50V |
| C2954 | 1-162-922-11 | CERAMIC CHIP | 39pF | 5% | 50V |
| C2955 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C2956 | 1-165-176-11 | CERAMIC CHIP | 0.047μF | 10% | 16V |
| C2957 | 1-162-968-11 | CERAMIC CHIP | 0.0047μF | 10% | 50V |
| C2958 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2959 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2960 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2964 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C2965 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C2966 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C2967 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C2968 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C2969 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C2970 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C2972 | 1-117-681-11 | ELECT CHIP | 100μF | 20% | 16V |
| C2973 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C2974 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C2975 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C3004 | 1-126-206-11 | ELECT CHIP | 100μF | 20% | 6.3V |
| C3005 | 1-126-204-11 | ELECT CHIP | 47μF | 20% | 16V |
| C3006 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C3008 | 1-126-204-11 | ELECT CHIP | 47μF | 20% | 16V |
| C3009 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C3011 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3012 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3013 | 1-128-391-11 | ELECT CHIP | 330μF | 20% | 6.3V |
| C3014 | 1-128-391-11 | ELECT CHIP | 330μF | 20% | 6.3V |
| C3015 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3016 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3017 | 1-125-837-91 | CERAMIC CHIP | 1μF | 10% | 6.3V |
| C3018 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3019 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3020 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C3021 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3023 | 1-125-837-91 | CERAMIC CHIP | 1μF | 10% | 6.3V |
| C3024 | 1-125-837-91 | CERAMIC CHIP | 1μF | 10% | 6.3V |
| C3025 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3026 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3027 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3028 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3029 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3030 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3031 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3032 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3033 | 1-109-982-11 | CERAMIC CHIP | 1μF | 10% | 10V |
| C3034 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C3035 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C3036 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C3037 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C3038 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C3039 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3040 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C3041 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3042 | 1-128-391-11 | ELECT CHIP | 330μF | 20% | 6.3V |
| C3044 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3046 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C3047 | 1-126-204-11 | ELECT CHIP | 47μF | 20% | 16V |
| C3048 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C3049 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C3089 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C3090 | 1-126-204-11 | ELECT CHIP | 47μF | 20% | 16V |
| C3095 | 1-128-391-11 | ELECT CHIP | 330μF | 20% | 6.3V |
| C3096 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C3097 | 1-128-391-11 | ELECT CHIP | 330μF | 20% | 6.3V |
| C3098 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C3101 | 1-162-925-11 | CERAMIC CHIP | 68pF | 5% | 50V |
| C3102 | 1-162-925-11 | CERAMIC CHIP | 68pF | 5% | 50V |
| C3103 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C3301 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3302 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3303 | 1-126-206-11 | ELECT CHIP | 100μF | 20% | 6.3V |
| C3304 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3305 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3307 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3308 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3309 | 1-126-206-11 | ELECT CHIP | 100μF | 20% | 6.3V |
| C3313 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3314 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3315 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3316 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3317 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3318 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3319 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3325 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3326 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3329 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C3333 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3334 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C3335 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3337 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C3341 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3343 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3349 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3350 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3351 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3357 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3358 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3359 | 1-126-204-11 | ELECT CHIP | 47μF | 20% | 16V |
| C3360 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3363 | 1-126-204-11 | ELECT CHIP | 47μF | 20% | 16V |
| C3364 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3365 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3366 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3367 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3368 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3369 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3370 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3371 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |

**BB**

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| C3372 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3374 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3375 | 1-127-760-11 | CERAMIC CHIP | 4.7μF | 10% | 6.3V |
| C3376 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3377 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C3378 | 1-126-204-11 | ELECT CHIP | 47μF | 20% | 16V |
| C3379 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3401 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3403 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3404 | 1-126-206-11 | ELECT CHIP | 100μF | 20% | 6.3V |
| C3405 | 1-126-206-11 | ELECT CHIP | 100μF | 20% | 6.3V |
| C3406 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C3407 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C3408 | 1-126-206-11 | ELECT CHIP | 100μF | 20% | 6.3V |
| C3409 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3410 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3411 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3412 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3413 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3414 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3417 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3418 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C3424 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3426 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3428 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C3431 | 1-126-204-11 | ELECT CHIP | 47μF | 20% | 16V |
| C3435 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3436 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C3439 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3440 | 1-162-916-11 | CERAMIC CHIP | 12pF | 5% | 50V |
| C3441 | 1-162-916-11 | CERAMIC CHIP | 12pF | 5% | 50V |
| C3444 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3446 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C3449 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C3450 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3452 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3460 | 1-162-923-11 | CERAMIC CHIP | 47pF | 5% | 50V |
| C3462 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3463 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3464 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3465 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3466 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3467 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3468 | 1-126-206-11 | ELECT CHIP | 100μF | 20% | 6.3V |
| C3469 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3470 | 1-126-206-11 | ELECT CHIP | 100μF | 20% | 6.3V |
| C3473 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3475 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3476 | 1-124-779-00 | ELECT CHIP | 10μF | 20% | 16V |
| C3477 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3478 | 1-126-204-11 | ELECT CHIP | 47μF | 20% | 16V |
| C3479 | 1-124-779-00 | ELECT CHIP | 10μF | 20% | 16V |
| C3480 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3481 | 1-117-681-11 | ELECT CHIP | 100μF | 20% | 16V |
| C3482 | 1-117-681-11 | ELECT CHIP | 100μF | 20% | 16V |
| C3483 | 1-117-681-11 | ELECT CHIP | 100μF | 20% | 16V |
| C3484 | 1-125-837-91 | CERAMIC CHIP | 1μF | 10% | 6.3V |
| C3485 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3486 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3487 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3488 | 1-124-779-00 | ELECT CHIP | 10μF | 20% | 16V |
| C3489 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3494 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3495 | 1-124-779-00 | ELECT CHIP | 10μF | 20% | 16V |
| C3496 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3499 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C3601 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3602 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3604 | 1-124-779-00 | ELECT CHIP | 10μF | 20% | 16V |
| C3605 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C3606 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3607 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C3608 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3610 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3611 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3613 | 1-126-206-11 | ELECT CHIP | 100μF | 20% | 6.3V |
| C3614 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3615 | 1-124-779-00 | ELECT CHIP | 10μF | 20% | 16V |
| C3617 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C3618 | 1-127-760-11 | CERAMIC CHIP | 4.7μF | 10% | 6.3V |
| C3619 | 1-126-206-11 | ELECT CHIP | 100μF | 20% | 6.3V |
| C3620 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C3622 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3623 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3624 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3626 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3627 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3628 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C3629 | 1-124-779-00 | ELECT CHIP | 10μF | 20% | 16V |
| C3630 | 1-124-779-00 | ELECT CHIP | 10μF | 20% | 16V |
| C3906 | 1-126-204-11 | ELECT CHIP | 47μF | 20% | 16V |
| C3912 | 1-126-206-11 | ELECT CHIP | 100μF | 20% | 6.3V |
| C8601 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C8602 | 1-127-692-11 | CERAMIC CHIP | 10μF | 10% | 6.3V |
| C8603 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C8604 | 1-127-692-11 | CERAMIC CHIP | 10μF | 10% | 6.3V |
| C8605 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C8606 | 1-127-692-11 | CERAMIC CHIP | 10μF | 10% | 6.3V |
| C8607 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C8608 | 1-128-934-91 | CERAMIC CHIP | 0.33μF | 20% | 10V |
| C8609 | 1-162-967-11 | CERAMIC CHIP | 0.0033μF | 10% | 50V |
| C8610 | 1-162-927-11 | CERAMIC CHIP | 100pF | 5% | 50V |
| C8611 | 1-162-927-11 | CERAMIC CHIP | 100pF | 5% | 50V |
| C8612 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C8613 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C8615 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C8617 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C8621 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C8622 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C8623 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C8624 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C8625 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C8630 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C8631 | 1-125-837-91 | CERAMIC CHIP | 1μF | 10% | 6.3V |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| C8632 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C8633 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C8634 | 1-125-837-91 | CERAMIC CHIP | 1μF | 10% | 6.3V |
| C8635 | 1-125-837-91 | CERAMIC CHIP | 1μF | 10% | 6.3V |
| C8636 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C8637 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C8638 | 1-128-994-21 | ELECT CHIP | 47μF | 20% | 10V |
| C8639 | 1-135-599-11 | ELECT CHIP | 39μF | 20% | 16V |
| C8640 | 1-117-370-11 | CERAMIC CHIP | 10μF | | 10V |
| C8641 | 1-117-370-11 | CERAMIC CHIP | 10μF | | 10V |
| C8642 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C8643 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C8644 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C8645 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C8646 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C8647 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C8648 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C8649 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C8650 | 1-126-204-11 | ELECT CHIP | 47μF | 20% | 16V |
| C8651 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C8652 | 1-128-994-21 | ELECT CHIP | 47μF | 20% | 10V |
| C8653 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C8654 | 1-126-206-11 | ELECT CHIP | 100μF | 20% | 6.3V |
| C8655 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C8656 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C8657 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |

<CONNECTOR>

| | | | |
|---|---|---|---|
| CN2804 | 1-815-871-11 | CONNECTOR, BOARD TO BOARD 40P | |
| CN2805 * | 1-764-643-21 | PIN, CONNECTOR (SMD) 11P | |
| CN3203 | 1-815-870-11 | CONNECTOR, BOARD TO BOARD 50P | |
| CN3601 * | 1-816-070-21 | CONNECTOR, BOARD TO BOARD 60P | |
| CN3602 * | 1-793-141-21 | PIN, CONNECTOR (PC BOARD) 15P | |
| CN3603 * | 1-815-177-12 | PIN, CONNECTOR(WITH | SHIELD)22P |

<DIODE>

| | | | |
|---|---|---|---|
| D2803 | 8-719-404-50 | DIODE | MA111-TX |
| D3001 | 8-719-404-50 | DIODE | MA111-TX |
| D3002 | 8-719-083-58 | DIODE | UDZSTE-173.9B |
| D3089 | 8-719-800-76 | DIODE | MA153-TX |
| D3090 | 8-719-800-76 | DIODE | MA153-TX |
| D3309 | 8-719-914-43 | DIODE | DAN202K |
| D3310 | 8-719-914-44 | DIODE | DAP202K |
| D3401 | 8-719-914-43 | DIODE | DAN202K |
| D3402 | 8-719-914-44 | DIODE | DAP202K |
| D3403 | 8-719-978-33 | DIODE | DTZ-TT11-6.8B |
| D3404 | 8-719-404-50 | DIODE | MA111-TX |
| D3601 | 8-719-800-76 | DIODE | MA153-TX |
| D3603 | 8-719-083-58 | DIODE | UDZSTE-173.9B |

<FERRITE BEAD>

| | | | |
|---|---|---|---|
| FB3001 | 1-500-451-11 | FERRITE | 0μH |
| FB3002 | 1-216-864-11 | SHORT CHIP | 0 |
| FB3301 | 1-414-235-22 | FERRITE | 0μH |
| FB3302 | 1-414-235-22 | FERRITE | 0μH |
| FB3303 | 1-216-809-11 | METAL CHIP | 100 5% 1/10W |
| FB3304 | 1-469-110-21 | FERRITE | 0μH |
| FB3401 | 1-414-235-22 | FERRITE | 0μH |
| FB3402 | 1-414-235-22 | FERRITE | 0μH |
| FB3403 | 1-216-864-11 | SHORT CHIP | 0 |
| FB3601 | 1-414-228-11 | FERRITE | 0μH |
| FB3602 | 1-414-228-11 | FERRITE | 0μH |
| FB3603 | 1-216-864-11 | SHORT CHIP | 0 |
| FB3604 | 1-216-864-11 | SHORT CHIP | 0 |
| FB3605 | 1-216-864-11 | SHORT CHIP | 0 |
| FB3606 | 1-216-864-11 | SHORT CHIP | 0 |
| FB3607 | 1-216-864-11 | SHORT CHIP | 0 |
| FB3608 | 1-469-568-21 | FERRITE | 0μH |
| FB3609 | 1-414-921-11 | FERRITE | 0μH |
| FB3610 | 1-414-921-11 | FERRITE | 0μH |
| FB3611 | 1-414-921-11 | FERRITE | 0μH |
| FB3612 | 1-414-921-11 | FERRITE | 0μH |

<FILTER>

| | | | |
|---|---|---|---|
| FL2951 | 1-234-113-21 | FILTER, LOW PASS | |
| FL2952 | 1-234-113-21 | FILTER, LOW PASS | |
| FL2953 | 1-234-113-21 | FILTER, LOW PASS | |
| FL3001 | 1-234-177-21 | FERRITE | 0μH |
| FL3002 | 1-234-177-21 | FERRITE | 0μH |
| FL3301 | 1-234-558-21 | FILTER, LOW PASS | |
| FL3302 | 1-234-557-21 | FILTER, LOW PASS | |
| FL3303 | 1-234-557-21 | FILTER, LOW PASS | |
| FL3401 | 1-781-923-11 | FILTER, LOW PASS (SMD) | |
| FL3602 | 1-234-494-21 | FILTER, EMI | REMOVAL (SMD) |
| FL8601 | 1-234-559-21 | FILTER, LOW PASS | |
| FL8602 | 1-234-559-21 | FILTER, LOW PASS | |
| FL8603 | 1-234-560-21 | FILTER, LOW PASS | |

<IC>

| | | | |
|---|---|---|---|
| IC2801 | 8-752-102-68 | IC | CXA2170Q |
| IC2802 | 8-759-547-54 | IC | TC7SET00FU(TE85R) |
| IC2803 | 8-759-547-54 | IC | TC7SET00FU(TE85R) |
| IC2804 | 8-759-831-53 | IC | MC74LVX8053DR2 |
| IC2805 | 8-759-272-74 | IC | 74VHC123ASJX |
| IC2930 | 8-759-442-07 | IC | LM75CIMX-5 |
| IC3001 | 6-700-188-01 | IC | IS41C16256-35K |
| IC3002 | 8-759-641-26 | IC | NJM2391DL1-33(TE1) |
| IC3003 | 6-701-892-01 | IC | TC90A90F(BH,DRY) |
| IC3004 | 8-759-642-22 | IC | μPC29M05T-E2 |
| IC3089 | 8-759-682-41 | IC | M24C32-WMN6T(A) |
| IC3090 | 6-802-467-01 | IC | MB94918RpF-G-155-BND |
| IC3091 | 8-759-352-91 | IC | PST9143NL |
| IC3301 | 8-759-663-74 | IC | HY57V161610DTC-7TR |
| IC3301 | 8-759-832-53 | IC | W981616AH-7-EL10 |
| IC3302 | 6-700-398-01 | IC | μPC2918T-E1 |
| IC3302 | 8-759-832-05 | IC | BA18BC0FP-E2 |
| IC3303 | 8-752-417-57 | IC | CXD2097Q |
| IC3303 | 8-752-419-58 | IC | CXD2097AQ |
| IC3306 | 8-759-669-78 | IC | TLC2933IPWR-12 |

| REF. NO. | PART NO. | DESCRIPTION | REMARK |
|---|---|---|---|
| IC3401 | 6-700-394-01 | IC BA25BC0FP-E2 | |
| IC3402 | 8-759-677-37 | IC MT48LC2M32B2TG-7 | |
| IC3402 | 8-759-677-39 | IC MB81F643242B-D | |
| IC3403 | 8-759-460-29 | IC PST9120NL | |
| IC3408 | 8-759-672-57 | IC CXD9509AQ | |
| IC3409 | 8-759-833-72 | IC NJM2870F25-TE2 | |
| IC3410 | 8-752-409-20 | IC CXD2309AQ | |
| IC3411 | 8-759-082-57 | IC TC7W04FU(TE12R) | |
| IC3601 | 8-759-592-50 | IC TC7SZ126FU(TE85R) | |
| IC3602 | 8-759-592-49 | IC TC7SZ125FU(TE85R) | |
| IC3603 | 8-759-639-85 | IC SN65LVDS31DR | |
| IC3604 | 6-701-762-11 | IC DS90LV028ATMX | |
| IC3605 | 8-759-698-08 | IC SN74CBTLV1G125DCKR | |
| IC3606 | 8-759-641-26 | IC NJM2391DL1-33(TE1) | |
| IC3608 | 8-759-669-75 | IC TLC2932IPWR | |
| IC3609 | 8-759-828-44 | IC NJM2870F33(TE2) | |
| IC8601 | 8-752-093-03 | IC CXA3506R | |
| | | <COIL> | |
| L2803 | 1-469-555-21 | INDUCTOR 10μH | |
| L2804 | 1-469-555-21 | INDUCTOR 10μH | |
| L2805 | 1-469-555-21 | INDUCTOR 10μH | |
| L2807 | 1-469-555-21 | INDUCTOR 10μH | |
| L2811 | 1-469-557-21 | INDUCTOR 22μH | |
| L2930 | 1-469-555-21 | INDUCTOR 10μH | |
| L2951 | 1-469-555-21 | INDUCTOR 10μH | |
| L2952 | 1-410-993-42 | INDUCTOR 1μH | |
| L2953 | 1-410-993-42 | INDUCTOR 1μH | |
| L2955 | 1-469-555-21 | INDUCTOR 10μH | |
| L3001 | 1-216-295-91 | SHORT CHIP 0 | |
| L3002 | 1-412-026-11 | INDUCTOR 1μH | |
| L3004 | 1-412-026-11 | INDUCTOR 1μH | |
| L3005 | 1-412-026-11 | INDUCTOR 1μH | |
| L3007 | 1-469-555-21 | INDUCTOR 10μH | |
| L3009 | 1-469-555-21 | INDUCTOR 10μH | |
| L3010 | 1-469-555-21 | INDUCTOR 10μH | |
| L3011 | 1-469-555-21 | INDUCTOR 10μH | |
| L3089 | 1-414-233-22 | FERRITE 0μH | |
| L3102 | 1-469-552-21 | INDUCTOR 3.3μH | |
| L3304 | 1-469-555-21 | INDUCTOR 10μH | |
| L3310 | 1-469-561-21 | INDUCTOR 100μH | |
| L3311 | 1-469-561-21 | INDUCTOR 100μH | |
| L3402 | 1-412-052-21 | INDUCTOR 1μH | |
| L3405 | 1-469-555-21 | INDUCTOR 10μH | |
| L3406 | 1-469-555-21 | INDUCTOR 10μH | |
| L3407 | 1-469-555-21 | INDUCTOR 10μH | |
| L3411 | 1-412-058-11 | INDUCTOR 10μH | |
| L3412 | 1-469-555-21 | INDUCTOR 10μH | |
| L3413 | 1-469-555-21 | INDUCTOR 10μH | |
| L3414 | 1-469-555-21 | INDUCTOR 10μH | |
| L3416 | 1-469-555-21 | INDUCTOR 10μH | |
| L3601 | 1-419-370-21 | INDUCTOR 0μH | |
| L3602 | 1-419-370-21 | INDUCTOR 0μH | |
| L3603 | 1-419-370-21 | INDUCTOR 0μH | |
| L3604 | 1-419-370-21 | INDUCTOR 0μH | |
| L3605 | 1-419-370-21 | INDUCTOR 0μH | |

| REF. NO. | PART NO. | DESCRIPTION | REMARK |
|---|---|---|---|
| L3903 | 1-412-052-21 | INDUCTOR 1μH | |
| L8601 | 1-469-555-21 | INDUCTOR 10μH | |
| L8602 | 1-469-553-21 | INDUCTOR 4.7μH | |
| L8603 | 1-469-555-21 | INDUCTOR 10μH | |
| L8604 | 1-469-555-21 | INDUCTOR 10μH | |
| | | <TRANSISTOR> | |
| Q2805 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q2806 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2807 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2808 | 8-729-900-53 | TRANSISTOR DTC114EK | |
| Q2809 | 8-729-900-53 | TRANSISTOR DTC114EK | |
| Q2822 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2823 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2949 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2950 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2951 | 8-729-102-07 | TRANSISTOR 2SC2223-F13 | |
| Q2952 | 8-729-122-63 | TRANSISTOR 2SA1226 | |
| Q2953 | 8-729-900-53 | TRANSISTOR DTC114EK | |
| Q2954 | 8-729-900-53 | TRANSISTOR DTC114EK | |
| Q2955 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q2956 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q2957 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q2958 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q2959 | 8-729-122-63 | TRANSISTOR 2SA1226 | |
| Q2960 | 8-729-122-63 | TRANSISTOR 2SA1226 | |
| Q2961 | 8-729-122-63 | TRANSISTOR 2SA1226 | |
| Q2962 | 8-729-102-07 | TRANSISTOR 2SC2223-F13 | |
| Q2963 | 8-729-122-63 | TRANSISTOR 2SA1226 | |
| Q2964 | 8-729-102-07 | TRANSISTOR 2SC2223-F13 | |
| Q2965 | 8-729-122-63 | TRANSISTOR 2SA1226 | |
| Q2966 | 8-729-102-07 | TRANSISTOR 2SC2223-F13 | |
| Q2967 | 8-729-122-63 | TRANSISTOR 2SA1226 | |
| Q2968 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2969 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2970 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2971 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2972 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2973 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2974 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2975 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2976 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2978 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q2979 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q3003 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q3008 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q3009 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q3089 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q3090 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q3092 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q3093 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q3302 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q3303 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q3305 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q3306 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q3307 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| Q3308 | 8-729-216-22 | TRANSISTOR | 2SA1162-G | | |
| Q3309 | 8-729-422-33 | TRANSISTOR | 2SD601A-Q-TX | | |
| Q3310 | 8-729-216-22 | TRANSISTOR | 2SA1162-G | | |
| Q3311 | 8-729-422-33 | TRANSISTOR | 2SD601A-Q-TX | | |
| Q3401 | 8-729-422-33 | TRANSISTOR | 2SD601A-Q-TX | | |
| Q3402 | 8-729-028-28 | TRANSISTOR | 2SK2036(TE85L) | | |
| Q3404 | 8-729-028-28 | TRANSISTOR | 2SK2036(TE85L) | | |
| Q3410 | 8-729-122-63 | TRANSISTOR | 2SA1226 | | |
| Q3411 | 8-729-122-63 | TRANSISTOR | 2SA1226 | | |
| Q3412 | 8-729-122-63 | TRANSISTOR | 2SA1226 | | |
| Q3413 | 8-729-122-63 | TRANSISTOR | 2SA1226 | | |
| Q3414 | 8-729-122-63 | TRANSISTOR | 2SA1226 | | |
| Q3415 | 8-729-122-63 | TRANSISTOR | 2SA1226 | | |
| Q3416 | 8-729-422-33 | TRANSISTOR | 2SD601A-Q-TX | | |
| Q3417 | 8-729-900-53 | TRANSISTOR | DTC114EK | | |
| Q3418 | 8-729-900-53 | TRANSISTOR | DTC114EK | | |
| Q3419 | 8-729-900-53 | TRANSISTOR | DTC114EK | | |
| Q3420 | 8-729-900-53 | TRANSISTOR | DTC114EK | | |
| Q3421 | 8-729-900-53 | TRANSISTOR | DTC114EK | | |
| Q3422 | 8-729-900-53 | TRANSISTOR | DTC114EK | | |
| Q3601 | 8-729-422-33 | TRANSISTOR | 2SD601A-Q-TX | | |
| Q3906 | 8-729-028-28 | TRANSISTOR | 2SK2036(TE85L) | | |
| Q3907 | 8-729-028-28 | TRANSISTOR | 2SK2036(TE85L) | | |
| Q8601 | 8-729-102-07 | TRANSISTOR | 2SC2223-F13 | | |
| Q8602 | 8-729-102-07 | TRANSISTOR | 2SC2223-F13 | | |
| Q8603 | 8-729-102-07 | TRANSISTOR | 2SC2223-F13 | | |
| Q8604 | 8-729-216-22 | TRANSISTOR | 2SA1162-G | | |
| Q8605 | 8-729-216-22 | TRANSISTOR | 2SA1162-G | | |
| Q8606 | 8-729-122-63 | TRANSISTOR | 2SA1226 | | |
| Q8607 | 8-729-122-63 | TRANSISTOR | 2SA1226 | | |
| Q8608 | 8-729-122-63 | TRANSISTOR | 2SA1226 | | |
| Q8609 | 8-729-216-22 | TRANSISTOR | 2SA1162-G | | |
| | | <RESISTOR> | | | |
| R2801 | 1-218-867-11 | METAL CHIP | 6.8K | 5% | 1/10W |
| R2803 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R2804 | 1-218-716-11 | METAL CHIP | 10K | 0.5% | 1/10W |
| R2805 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2806 | 1-216-863-11 | METAL CHIP | 3.3M | 5% | 1/10W |
| R2807 | 1-218-716-11 | METAL CHIP | 10K | 0.5% | 1/10W |
| R2808 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2811 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2812 | 1-218-708-11 | METAL CHIP | 4.7K | 0.5% | 1/10W |
| R2817 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R2819 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R2820 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2821 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2824 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2826 | 1-218-716-11 | METAL CHIP | 10K | 0.5% | 1/10W |
| R2827 | 1-216-830-11 | METAL CHIP | 5.6K | 5% | 1/10W |
| R2828 | 1-216-832-11 | METAL CHIP | 8.2K | 5% | 1/10W |
| R2829 | 1-216-824-11 | METAL CHIP | 1.8K | 5% | 1/10W |
| R2830 | 1-216-818-11 | METAL CHIP | 560 | 5% | 1/10W |
| R2831 | 1-216-826-11 | METAL CHIP | 2.7K | 5% | 1/10W |
| R2832 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2833 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2835 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2852 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R2857 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R2858 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R2859 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R2860 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2863 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2865 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2866 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2868 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R2869 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2870 | 1-216-822-11 | METAL CHIP | 1.2K | 5% | 1/10W |
| R2871 | 1-216-822-11 | METAL CHIP | 1.2K | 5% | 1/10W |
| R2872 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R2873 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2874 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2875 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2876 | 1-216-806-11 | METAL CHIP | 56 | 5% | 1/10W |
| R2877 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2878 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2879 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2882 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R2883 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R2884 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2886 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2887 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2889 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R2890 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2891 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R2892 | 1-218-728-11 | METAL CHIP | 33K | 0.5% | 1/10W |
| R2893 | 1-218-714-11 | METAL CHIP | 8.2K | 0.5% | 1/10W |
| R2894 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R2895 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R2896 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R2897 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2898 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2899 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2900 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R2901 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R2902 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R2907 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2908 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2913 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2914 | 1-218-716-11 | METAL CHIP | 10K | 0.5% | 1/10W |
| R2915 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R2916 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R2917 | 1-218-700-11 | METAL CHIP | 2.2K | 0.5% | 1/10W |
| R2918 | 1-216-815-11 | METAL CHIP | 330 | 5% | 1/10W |
| R2919 | 1-216-815-11 | METAL CHIP | 330 | 5% | 1/10W |
| R2920 | 1-216-815-11 | METAL CHIP | 330 | 5% | 1/10W |
| R2921 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2925 | 1-218-690-11 | METAL CHIP | 820 | 0.5% | 1/10W |
| R2926 | 1-218-690-11 | METAL CHIP | 820 | 0.5% | 1/10W |
| R2927 | 1-218-690-11 | METAL CHIP | 820 | 0.5% | 1/10W |
| R2928 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2930 | 1-216-864-11 | SHORT CHIP | 0 | | |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| R2931 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2932 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2935 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R2936 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R2937 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R2938 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R2939 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R2940 | 1-218-704-11 | METAL CHIP | 3.3K | 0.5% | 1/10W |
| R2941 | 1-218-710-11 | METAL CHIP | 5.6K | 0.5% | 1/10W |
| R2942 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R2943 | 1-216-849-11 | METAL CHIP | 220K | 5% | 1/10W |
| R2944 | 1-216-849-11 | METAL CHIP | 220K | 5% | 1/10W |
| R2945 | 1-218-704-11 | METAL CHIP | 3.3K | 0.5% | 1/10W |
| R2946 | 1-218-710-11 | METAL CHIP | 5.6K | 0.5% | 1/10W |
| R2947 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R2948 | 1-216-849-11 | METAL CHIP | 220K | 5% | 1/10W |
| R2949 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2950 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R2951 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2953 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2955 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2957 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2958 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R2959 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2960 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2961 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2962 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2966 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2968 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2970 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2971 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2972 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R2973 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R2974 | 1-218-678-11 | METAL CHIP | 270 | 0.5% | 1/10W |
| R2975 | 1-218-690-11 | METAL CHIP | 820 | 0.5% | 1/10W |
| R2976 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2977 | 1-218-700-11 | METAL CHIP | 2.2K | 0.5% | 1/10W |
| R2978 | 1-216-820-11 | METAL CHIP | 820 | 5% | 1/10W |
| R2979 | 1-216-820-11 | METAL CHIP | 820 | 5% | 1/10W |
| R2980 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2981 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R2982 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R2983 | 1-218-678-11 | METAL CHIP | 270 | 0.5% | 1/10W |
| R2984 | 1-218-690-11 | METAL CHIP | 820 | 0.5% | 1/10W |
| R2985 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2986 | 1-218-700-11 | METAL CHIP | 2.2K | 0.5% | 1/10W |
| R2987 | 1-216-820-11 | METAL CHIP | 820 | 5% | 1/10W |
| R2988 | 1-216-820-11 | METAL CHIP | 820 | 5% | 1/10W |
| R2989 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2990 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R2991 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R2992 | 1-218-678-11 | METAL CHIP | 270 | 0.5% | 1/10W |
| R2993 | 1-218-690-11 | METAL CHIP | 820 | 0.5% | 1/10W |
| R2994 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2995 | 1-218-700-11 | METAL CHIP | 2.2K | 0.5% | 1/10W |
| R2996 | 1-216-820-11 | METAL CHIP | 820 | 5% | 1/10W |
| R2997 | 1-216-820-11 | METAL CHIP | 820 | 5% | 1/10W |
| R2998 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2999 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3001 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R3002 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3005 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3013 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3014 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R3015 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R3017 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R3020 | 1-216-827-11 | METAL CHIP | 3.3K | 5% | 1/10W |
| R3021 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3022 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3023 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R3025 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R3026 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R3029 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R3030 | 1-216-827-11 | METAL CHIP | 3.3K | 5% | 1/10W |
| R3031 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3032 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R3033 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R3034 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R3045 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3047 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3049 | 1-216-859-11 | METAL CHIP | 1.5M | 5% | 1/10W |
| R3050 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R3051 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3063 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3064 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3066 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3068 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R3069 | 1-216-820-11 | METAL CHIP | 820 | 5% | 1/10W |
| R3070 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3071 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R3072 | 1-216-855-11 | METAL CHIP | 680K | 5% | 1/10W |
| R3073 | 1-216-855-11 | METAL CHIP | 680K | 5% | 1/10W |
| R3074 | 1-218-704-11 | METAL CHIP | 3.3K | 0.5% | 1/10W |
| R3075 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R3076 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3077 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R3078 | 1-216-815-11 | METAL CHIP | 330 | 5% | 1/10W |
| R3079 | 1-216-815-11 | METAL CHIP | 330 | 5% | 1/10W |
| R3089 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3091 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R3092 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R3093 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3095 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R3096 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R3097 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R3098 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R3099 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R3102 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3103 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3104 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3105 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3107 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3108 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R3110 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| R3111 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3116 | 1-216-797-11 | METAL CHIP | 10 | 5% | 1/10W |
| R3117 | 1-216-797-11 | METAL CHIP | 10 | 5% | 1/10W |
| R3121 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3122 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3123 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R3125 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3126 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3150 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3302 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R3303 | 1-218-710-11 | METAL CHIP | 5.6K | 0.5% | 1/10W |
| R3304 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3325 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3335 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R3341 | 1-216-813-11 | METAL CHIP | 220 | 5% | 1/10W |
| R3342 | 1-218-705-11 | METAL CHIP | 3.6K | 0.5% | 1/10W |
| R3343 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3344 | 1-216-853-11 | METAL CHIP | 470K | 5% | 1/10W |
| R3345 | 1-218-704-11 | METAL CHIP | 3.3K | 0.5% | 1/10W |
| R3346 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3347 | 1-216-815-11 | METAL CHIP | 330 | 5% | 1/10W |
| R3348 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3349 | 1-216-819-11 | METAL CHIP | 680 | 5% | 1/10W |
| R3350 | 1-216-814-11 | METAL CHIP | 270 | 5% | 1/10W |
| R3351 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R3352 | 1-216-853-11 | METAL CHIP | 470K | 5% | 1/10W |
| R3353 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |
| R3354 | 1-216-813-11 | METAL CHIP | 220 | 5% | 1/10W |
| R3355 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R3357 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R3358 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R3359 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R3360 | 1-216-827-11 | METAL CHIP | 3.3K | 5% | 1/10W |
| R3365 | 1-216-827-11 | METAL CHIP | 3.3K | 5% | 1/10W |
| R3367 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R3368 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3370 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R3371 | 1-218-686-11 | METAL CHIP | 560 | 0.5% | 1/10W |
| R3372 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R3373 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R3374 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3375 | 1-218-686-11 | METAL CHIP | 560 | 0.5% | 1/10W |
| R3376 | 1-218-710-11 | METAL CHIP | 5.6K | 0.5% | 1/10W |
| R3377 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R3378 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R3379 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3380 | 1-218-686-11 | METAL CHIP | 560 | 0.5% | 1/10W |
| R3381 | 1-218-710-11 | METAL CHIP | 5.6K | 0.5% | 1/10W |
| R3383 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R3395 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3396 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3400 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3401 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3406 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R3407 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3409 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3410 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| R3411 | 1-216-797-11 | METAL CHIP | 10 | 5% | 1/10W |
| R3421 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3422 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3425 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3428 | 1-469-094-21 | FERRITE | 0μH | | |
| R3442 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R3445 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3451 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3452 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3453 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3454 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R3456 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3457 | 1-216-813-11 | METAL CHIP | 220 | 5% | 1/10W |
| R3460 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R3461 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R3466 | 1-216-813-11 | METAL CHIP | 220 | 5% | 1/10W |
| R3470 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R3475 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R3480 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3489 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3490 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3494 | 1-216-813-11 | METAL CHIP | 220 | 5% | 1/10W |
| R3497 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R3498 | 1-216-818-11 | METAL CHIP | 560 | 5% | 1/10W |
| R3533 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3534 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3535 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3536 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R3537 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R3538 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3539 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3540 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3541 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3542 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3575 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3601 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3602 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3603 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3604 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3605 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3606 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3607 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3608 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3609 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3610 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R3611 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R3612 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R3613 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R3614 | 1-216-827-11 | METAL CHIP | 3.3K | 5% | 1/10W |
| R3615 | 1-218-867-11 | METAL CHIP | 6.8K | 5% | 1/10W |
| R3616 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3617 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R3800 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3801 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3811 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3812 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| R3813 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3818 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3819 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3820 | 1-218-680-11 | METAL CHIP | 330 | 0.5% | 1/10W |
| R3821 | 1-218-680-11 | METAL CHIP | 330 | 0.5% | 1/10W |
| R3822 | 1-218-680-11 | METAL CHIP | 330 | 0.5% | 1/10W |
| R3823 | 1-216-826-11 | METAL CHIP | 2.7K | 5% | 1/10W |
| R3824 | 1-216-826-11 | METAL CHIP | 2.7K | 5% | 1/10W |
| R3825 | 1-216-826-11 | METAL CHIP | 2.7K | 5% | 1/10W |
| R3826 | 1-218-693-11 | METAL CHIP | 1.1K | 0.5% | 1/10W |
| R3827 | 1-218-700-11 | METAL CHIP | 2.2K | 0.5% | 1/10W |
| R3828 | 1-218-682-11 | METAL CHIP | 390 | 0.5% | 1/10W |
| R3829 | 1-218-682-11 | METAL CHIP | 390 | 0.5% | 1/10W |
| R3830 | 1-218-682-11 | METAL CHIP | 390 | 0.5% | 1/10W |
| R3831 | 1-218-693-11 | METAL CHIP | 1.1K | 0.5% | 1/10W |
| R3832 | 1-218-700-11 | METAL CHIP | 2.2K | 0.5% | 1/10W |
| R3833 | 1-218-693-11 | METAL CHIP | 1.1K | 0.5% | 1/10W |
| R3840 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R3843 | 1-218-700-11 | METAL CHIP | 2.2K | 0.5% | 1/10W |
| R3846 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R3847 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R3848 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R3849 | 1-218-675-11 | METAL CHIP | 200 | 0.5% | 1/10W |
| R3850 | 1-218-675-11 | METAL CHIP | 200 | 0.5% | 1/10W |
| R3851 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3852 | 1-218-675-11 | METAL CHIP | 200 | 0.5% | 1/10W |
| R3854 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R3857 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3858 | 1-218-704-11 | METAL CHIP | 3.3K | 0.5% | 1/10W |
| R3862 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R3863 | 1-218-700-11 | METAL CHIP | 2.2K | 0.5% | 1/10W |
| R3864 | 1-216-827-11 | METAL CHIP | 3.3K | 5% | 1/10W |
| R3865 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R3866 | 1-414-234-22 | FERRITE | 0μH | | |
| R3867 | 1-414-234-22 | FERRITE | 0μH | | |
| R3868 | 1-414-234-22 | FERRITE | 0μH | | |
| R3881 | 1-216-807-11 | METAL CHIP | 68 | 5% | 1/10W |
| R3882 | 1-216-807-11 | METAL CHIP | 68 | 5% | 1/10W |
| R3883 | 1-216-807-11 | METAL CHIP | 68 | 5% | 1/10W |
| R3911 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R3917 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R3928 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R3933 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R3956 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R3957 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R3958 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R3973 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R3974 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R8606 | 1-216-819-11 | METAL CHIP | 680 | 5% | 1/10W |
| R8607 | 1-216-819-11 | METAL CHIP | 680 | 5% | 1/10W |
| R8608 | 1-216-819-11 | METAL CHIP | 680 | 5% | 1/10W |
| R8609 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R8610 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R8611 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R8612 | 1-216-820-11 | METAL CHIP | 820 | 5% | 1/10W |
| R8613 | 1-216-820-11 | METAL CHIP | 820 | 5% | 1/10W |
| R8614 | 1-216-820-11 | METAL CHIP | 820 | 5% | 1/10W |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| R8615 | 1-218-668-11 | METAL CHIP | 100 | 0.5% | 1/10W |
| R8616 | 1-218-668-11 | METAL CHIP | 100 | 0.5% | 1/10W |
| R8617 | 1-218-668-11 | METAL CHIP | 100 | 0.5% | 1/10W |
| R8618 | 1-218-679-11 | METAL CHIP | 300 | 0.5% | 1/10W |
| R8619 | 1-218-679-11 | METAL CHIP | 300 | 0.5% | 1/10W |
| R8620 | 1-218-675-11 | METAL CHIP | 200 | 0.5% | 1/10W |
| R8621 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R8622 | 1-218-679-11 | METAL CHIP | 300 | 0.5% | 1/10W |
| R8623 | 1-218-679-11 | METAL CHIP | 300 | 0.5% | 1/10W |
| R8624 | 1-218-675-11 | METAL CHIP | 200 | 0.5% | 1/10W |
| R8625 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R8626 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R8627 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R8628 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R8629 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R8630 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R8631 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R8632 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R8636 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R8637 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R8638 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R8639 | 1-218-704-11 | METAL CHIP | 3.3K | 0.5% | 1/10W |
| R8641 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R8642 | 1-218-703-11 | METAL CHIP | 3K | 0.5% | 1/10W |
| R8643 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R8645 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R8646 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R8647 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R8648 | 1-216-830-11 | METAL CHIP | 5.6K | 5% | 1/10W |
| R8650 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R8651 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R8652 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R8653 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R8654 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R8655 | 1-216-864-11 | SHORT CHIP | 0 | | |

<NETWORK RESISTOR>

| | | |
|---|---|---|
| RB3005 | 1-239-409-11 | RES, CHIP NETWORK 47 (3216) |
| RB3006 | 1-239-409-11 | RES, CHIP NETWORK 47 (3216) |
| RB3007 | 1-239-409-11 | RES, CHIP NETWORK 47 (3216) |
| RB3008 | 1-239-409-11 | RES, CHIP NETWORK 47 (3216) |
| RB3009 | 1-239-409-11 | RES, CHIP NETWORK 47 (3216) |
| RB3010 | 1-239-409-11 | RES, CHIP NETWORK 47 (3216) |
| RB3011 | 1-239-409-11 | RES, CHIP NETWORK 47 (3216) |
| RB3012 | 1-239-409-11 | RES, CHIP NETWORK 47 (3216) |
| RB3013 | 1-239-409-11 | RES, CHIP NETWORK 47 (3216) |
| RB3014 | 1-239-409-11 | RES, CHIP NETWORK 47 (3216) |
| RB3015 | 1-239-409-11 | RES, CHIP NETWORK 47 (3216) |
| RB3100 | 1-233-574-11 | RES, CHIP NETWORK 10 |
| RB3101 | 1-233-574-11 | RES, CHIP NETWORK 10 |
| RB3102 | 1-233-574-11 | RES, CHIP NETWORK 10 |
| RB3103 | 1-233-574-11 | RES, CHIP NETWORK 10 |
| RB3304 | 1-233-576-11 | RES, CHIP NETWORK 100 |
| RB3305 | 1-233-576-11 | RES, CHIP NETWORK 100 |
| RB3306 | 1-233-576-11 | RES, CHIP NETWORK 100 |
| RB3307 | 1-233-576-11 | RES, CHIP NETWORK 100 |

| REF. NO. | PART NO. | DESCRIPTION | REMARK |
|---|---|---|---|
| RB3401 | 1-234-524-21 | RES, CHIP NETWORK 33 | |
| RB3402 | 1-234-524-21 | RES, CHIP NETWORK 33 | |
| RB3403 | 1-234-524-21 | RES, CHIP NETWORK 33 | |
| RB3404 | 1-234-524-21 | RES, CHIP NETWORK 33 | |
| RB3405 | 1-234-524-21 | RES, CHIP NETWORK 33 | |
| RB3406 | 1-234-524-21 | RES, CHIP NETWORK 33 | |
| RB3407 | 1-239-409-11 | RES, CHIP NETWORK 47 (3216) | |
| RB3408 | 1-239-409-11 | RES, CHIP NETWORK 47 (3216) | |
| RB3409 | 1-239-409-11 | RES, CHIP NETWORK 47 (3216) | |
| RB3410 | 1-239-409-11 | RES, CHIP NETWORK 47 (3216) | |
| RB3411 | 1-239-409-11 | RES, CHIP NETWORK 47 (3216) | |
| RB3412 | 1-239-409-11 | RES, CHIP NETWORK 47 (3216) | |
| RB3421 | 1-233-576-11 | RES, CHIP NETWORK 100 | |
| RB3422 | 1-233-576-11 | RES, CHIP NETWORK 100 | |
| RB3423 | 1-233-576-11 | RES, CHIP NETWORK 100 | |
| RB3424 | 1-233-576-11 | RES, CHIP NETWORK 100 | |
| RB3425 | 1-233-576-11 | RES, CHIP NETWORK 100 | |
| RB3426 | 1-233-576-11 | RES, CHIP NETWORK 100 | |
| RB3427 | 1-233-576-11 | RES, CHIP NETWORK 100 | |
| RB3428 | 1-233-576-11 | RES, CHIP NETWORK 100 | |
| RB3436 | 1-234-523-21 | RES, CHIP NETWORK 0 | (3216) |
| RB3437 | 1-234-523-21 | RES, CHIP NETWORK 0 | (3216) |
| RB3438 | 1-234-523-21 | RES, CHIP NETWORK 0 | (3216) |
| RB3439 | 1-234-523-21 | RES, CHIP NETWORK 0 | (3216) |
| | | <CRYSTAL> | |
| X2801 | 1-760-895-21 | VIBRATOR, CERAMIC 2.7MHz | |
| X3089 | 1-781-945-21 | VIBRATOR, CERAMIC 20MHz | |
| X3401 | 1-781-887-21 | VIBRATOR, CRYSTAL 18.543956MHz | |

**********

* A-1300-697-A BC BOARD, COMPLETE
**********

<CAPACITOR>

| | | | | | |
|---|---|---|---|---|---|
| C4601 | 1-126-964-11 | ELECT | 10µF | 20% | 50V |
| C4602 | 1-126-964-11 | ELECT | 10µF | 20% | 50V |
| C4603 | 1-126-964-11 | ELECT | 10µF | 20% | 50V |
| C4604 | 1-126-964-11 | ELECT | 10µF | 20% | 50V |
| C4605 | 1-126-964-11 | ELECT | 10µF | 20% | 50V |
| C4606 | 1-126-964-11 | ELECT | 10µF | 20% | 50V |
| C4607 | 1-125-891-11 | CERAMIC CHIP | 0.47µF | 10% | 10V |
| C4608 | 1-125-891-11 | CERAMIC CHIP | 0.47µF | 10% | 10V |
| C4609 | 1-125-891-11 | CERAMIC CHIP | 0.47µF | 10% | 10V |
| C4610 | 1-216-864-11 | SHORT CHIP | 0 | | |
| C4611 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4612 | 1-216-864-11 | SHORT CHIP | 0 | | |
| C4613 | 1-125-891-11 | CERAMIC CHIP | 0.47µF | 10% | 10V |
| C4614 | 1-125-891-11 | CERAMIC CHIP | 0.47µF | 10% | 10V |
| C4615 | 1-125-891-11 | CERAMIC CHIP | 0.47µF | 10% | 10V |
| C4616 | 1-125-891-11 | CERAMIC CHIP | 0.47µF | 10% | 10V |
| C4617 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4618 | 1-125-891-11 | CERAMIC CHIP | 0.47µF | 10% | 10V |
| C4619 | 1-125-891-11 | CERAMIC CHIP | 0.47µF | 10% | 10V |
| C4620 | 1-125-891-11 | CERAMIC CHIP | 0.47µF | 10% | 10V |
| C4621 | 1-126-935-11 | ELECT | 470µF | 20% | 10V |
| C4622 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4623 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4624 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4625 | 1-126-933-11 | ELECT | 100µF | 20% | 16V |
| C4626 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4627 | 1-107-826-11 | CERAMIC CHIP | 0.1µF | 10% | 16V |
| C4628 | 1-162-916-11 | CERAMIC CHIP | 12pF | 5% | 50V |
| C4629 | 1-107-826-11 | CERAMIC CHIP | 0.1µF | 10% | 16V |
| C4630 | 1-107-826-11 | CERAMIC CHIP | 0.1µF | 10% | 16V |
| C4631 | 1-125-891-11 | CERAMIC CHIP | 0.47µF | 10% | 10V |
| C4632 | 1-164-315-11 | CERAMIC CHIP | 470pF | 5% | 50V |
| C4633 | 1-107-826-11 | CERAMIC CHIP | 0.1µF | 10% | 16V |
| C4634 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4635 | 1-125-837-91 | CERAMIC CHIP | 1µF | 10% | 6.3V |
| C4636 | 1-162-970-11 | CERAMIC CHIP | 0.01µF | 10% | 25V |
| C4637 | 1-126-935-11 | ELECT | 470µF | 20% | 10V |
| C4638 | 1-107-826-11 | CERAMIC CHIP | 0.1µF | 10% | 16V |
| C4639 | 1-107-826-11 | CERAMIC CHIP | 0.1µF | 10% | 16V |
| C4640 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4641 | 1-126-963-11 | ELECT | 4.7µF | 20% | 50V |
| C4642 | 1-107-826-11 | CERAMIC CHIP | 0.1µF | 10% | 16V |
| C4643 | 1-107-826-11 | CERAMIC CHIP | 0.1µF | 10% | 16V |
| C4644 | 1-107-826-11 | CERAMIC CHIP | 0.1µF | 10% | 16V |
| C4645 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4646 | 1-162-970-11 | CERAMIC CHIP | 0.01µF | 10% | 25V |
| C4647 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4648 | 1-126-935-11 | ELECT | 470µF | 20% | 10V |
| C4649 | 1-125-891-11 | CERAMIC CHIP | 0.47µF | 10% | 10V |
| C4650 | 1-107-826-11 | CERAMIC CHIP | 0.1µF | 10% | 16V |
| C4651 | 1-107-826-11 | CERAMIC CHIP | 0.1µF | 10% | 16V |
| C4652 | 1-126-963-11 | ELECT | 4.7µF | 20% | 50V |
| C4653 | 1-107-826-11 | CERAMIC CHIP | 0.1µF | 10% | 16V |
| C4654 | 1-162-970-11 | CERAMIC CHIP | 0.01µF | 10% | 25V |
| C4655 | 1-125-891-11 | CERAMIC CHIP | 0.47µF | 10% | 10V |
| C4656 | 1-125-891-11 | CERAMIC CHIP | 0.47µF | 10% | 10V |
| C4657 | 1-162-927-11 | CERAMIC CHIP | 100pF | 5% | 50V |
| C4659 | 1-126-947-11 | ELECT | 47µF | 20% | 16V |
| C4660 | 1-126-947-11 | ELECT | 47µF | 20% | 16V |
| C4664 | 1-126-933-11 | ELECT | 100µF | 20% | 16V |
| C4665 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4666 | 1-126-964-11 | ELECT | 10µF | 20% | 50V |
| C4667 | 1-126-964-11 | ELECT | 10µF | 20% | 50V |
| C4668 | 1-126-964-11 | ELECT | 10µF | 20% | 50V |
| C4669 | 1-126-964-11 | ELECT | 10µF | 20% | 50V |
| C4671 | 1-126-964-11 | ELECT | 10µF | 20% | 50V |
| C4672 | 1-126-964-11 | ELECT | 10µF | 20% | 50V |
| C4673 | 1-107-826-11 | CERAMIC CHIP | 0.1µF | 10% | 16V |
| C4674 | 1-126-933-11 | ELECT | 100µF | 20% | 16V |
| C4675 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4676 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4677 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4678 | 1-126-947-11 | ELECT | 47µF | 20% | 16V |
| C4679 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| C4680 | 1-126-947-11 | ELECT | 47µF | 20% | 25V |
| C4681 | 1-107-826-11 | CERAMIC CHIP | 0.1µF | 10% | 16V |
| C4682 | 1-126-947-11 | ELECT | 47µF | 20% | 16V |
| C4683 | 1-126-947-11 | ELECT | 47µF | 20% | 16V |
| C4684 | 1-162-916-11 | CERAMIC CHIP | 12pF | 5% | 50V |
| C4685 | 1-164-315-11 | CERAMIC CHIP | 470pF | 5% | 50V |
| C4686 | 1-107-826-11 | CERAMIC CHIP | 0.1µF | 10% | 16V |
| C4687 | 1-125-891-11 | CERAMIC CHIP | 0.47µF | 10% | 10V |
| C4688 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4691 | 1-126-935-11 | ELECT | 470µF | 20% | 10V |
| C4692 | 1-107-826-11 | CERAMIC CHIP | 0.1µF | 10% | 16V |
| C4693 | 1-126-963-11 | ELECT | 4.7µF | 20% | 50V |
| C4694 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4695 | 1-162-970-11 | CERAMIC CHIP | 0.01µF | 10% | 25V |
| C4696 | 1-125-891-11 | CERAMIC CHIP | 0.47µF | 10% | 10V |
| C4697 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4698 | 1-126-935-11 | ELECT | 470µF | 20% | 10V |
| C4699 | 1-107-826-11 | CERAMIC CHIP | 0.1µF | 10% | 16V |
| C4700 | 1-162-970-11 | CERAMIC CHIP | 0.01µF | 10% | 25V |
| C4701 | 1-107-826-11 | CERAMIC CHIP | 0.1µF | 10% | 16V |
| C4702 | 1-126-963-11 | ELECT | 4.7µF | 20% | 50V |
| C4703 | 1-107-826-11 | CERAMIC CHIP | 0.1µF | 10% | 16V |
| C4704 | 1-125-891-11 | CERAMIC CHIP | 0.47µF | 10% | 10V |
| C4705 | 1-162-970-11 | CERAMIC CHIP | 0.01µF | 10% | 25V |
| C4706 | 1-125-891-11 | CERAMIC CHIP | 0.47µF | 10% | 10V |
| C4708 | 1-162-927-11 | CERAMIC CHIP | 100pF | 5% | 50V |
| C4710 | 1-126-933-11 | ELECT | 100µF | 20% | 16V |
| C4711 | 1-126-933-11 | ELECT | 100µF | 20% | 16V |
| C4712 | 1-125-891-11 | CERAMIC CHIP | 0.47µF | 10% | 10V |
| C4713 | 1-125-891-11 | CERAMIC CHIP | 0.47µF | 10% | 10V |
| C4801 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4802 | 1-162-975-11 | CERAMIC CHIP | 24pF | 5% | 50V |
| C4803 | 1-162-975-11 | CERAMIC CHIP | 24pF | 5% | 50V |
| C4804 | 1-164-392-11 | CERAMIC CHIP | 390pF | 5% | 50V |
| C4805 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4806 | 1-126-947-11 | ELECT | 47µF | 20% | 25V |
| C4807 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4808 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4809 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4810 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4812 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4813 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4814 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4815 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4816 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4817 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4818 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4819 | 1-126-947-11 | ELECT | 47µF | 20% | 25V |
| C4820 | 1-126-933-11 | ELECT | 100µF | 20% | 16V |
| C4821 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4822 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4823 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4824 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4825 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4826 | 1-126-933-11 | ELECT | 100µF | 20% | 16V |
| C4827 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4828 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4829 | 1-125-837-91 | CERAMIC CHIP | 1µF | 10% | 6.3V |
| C4830 | 1-162-917-11 | CERAMIC CHIP | 15pF | 5% | 50V |
| C4831 | 1-162-917-11 | CERAMIC CHIP | 15pF | 5% | 50V |
| C4832 | 1-115-156-11 | CERAMIC CHIP | 1µF | | 10V |
| C4833 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4834 | 1-126-933-11 | ELECT | 100µF | 20% | 16V |
| C4835 | 1-162-917-11 | CERAMIC CHIP | 15pF | 5% | 50V |
| C4836 | 1-162-915-11 | CERAMIC CHIP | 10pF | 0.50pF | 50V |
| C4837 | 1-162-923-11 | CERAMIC CHIP | 47pF | 5% | 50V |
| C4838 | 1-125-837-91 | CERAMIC CHIP | 1µF | 10% | 6.3V |
| C4839 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4840 | 1-162-913-11 | CERAMIC CHIP | 8pF | 0.50pF | 50V |
| C4841 | 1-126-933-11 | ELECT | 100µF | 20% | 16V |
| C4843 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4844 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4846 | 1-162-921-11 | CERAMIC CHIP | 33pF | 5% | 50V |
| C4847 | 1-162-917-11 | CERAMIC CHIP | 15pF | 5% | 50V |
| C4848 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4849 | 1-162-919-11 | CERAMIC CHIP | 22pF | 5% | 50V |
| C4850 | 1-126-933-11 | ELECT | 100µF | 20% | 16V |
| C4851 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4852 | 1-126-933-11 | ELECT | 100µF | 20% | 16V |
| C4853 | 1-107-826-11 | CERAMIC CHIP | 0.1µF | 10% | 16V |
| C4854 | 1-126-934-11 | ELECT | 220µF | 20% | 16V |
| C4855 | 1-126-934-11 | ELECT | 220µF | 20% | 16V |
| C4856 | 1-107-826-11 | CERAMIC CHIP | 0.1µF | 10% | 16V |
| C4857 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4858 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4859 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4860 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4861 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4862 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4863 | 1-126-933-11 | ELECT | 100µF | 20% | 16V |
| C4864 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4865 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4866 | 1-126-933-11 | ELECT | 100µF | 20% | 16V |
| C4867 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4868 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4869 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4870 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4871 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4872 | 1-125-891-11 | CERAMIC CHIP | 0.47µF | 10% | 10V |
| C4873 | 1-107-826-11 | CERAMIC CHIP | 0.1µF | 10% | 16V |
| C4874 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4875 | 1-107-826-11 | CERAMIC CHIP | 0.1µF | 10% | 16V |
| C4876 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4877 | 1-125-891-11 | CERAMIC CHIP | 0.47µF | 10% | 10V |
| C4878 | 1-107-826-11 | CERAMIC CHIP | 0.1µF | 10% | 16V |
| C4879 | 1-164-230-11 | CERAMIC CHIP | 220pF | 5% | 50V |
| C4880 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4881 | 1-107-826-11 | CERAMIC CHIP | 0.1µF | 10% | 16V |
| C4882 | 1-164-230-11 | CERAMIC CHIP | 220pF | 5% | 50V |
| C4883 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4884 | 1-126-933-11 | ELECT | 100µF | 20% | 16V |

| REF. NO. | PART NO. | DESCRIPTION | REMARK |
|---|---|---|---|
| | | <CONNECTOR> | |
| CN4601 * | 1-793-923-11 | CONNECTOR, IN (PLUG) 64P | |
| | | <DIODE> | |
| D4601 | 8-719-041-97 | DIODE MA113-(TX) | |
| D4602 | 8-719-041-97 | DIODE MA113-(TX) | |
| D4603 | 8-719-041-97 | DIODE MA113-(TX) | |
| D4801 | 8-719-914-43 | DIODE DAN202K | |
| D4802 | 8-719-914-43 | DIODE DAN202K | |
| D4803 | 8-719-914-44 | DIODE DAP202K | |
| D4804 | 8-719-914-44 | DIODE DAP202K | |
| | | <FERRITE BEAD> | |
| FB4801 | 1-414-229-11 | FERRITE 0μH | |
| FB4802 | 1-414-229-11 | FERRITE 0μH | |
| | | <FILTER> | |
| FL4601 | 1-234-557-21 | FILTER, LOW PASS | |
| FL4602 | 1-234-557-21 | FILTER, LOW PASS | |
| FL4603 | 1-234-558-21 | FILTER, LOW PASS | |
| FL4604 | 1-234-558-21 | FILTER, LOW PASS | |
| FL4605 | 1-234-557-21 | FILTER, LOW PASS | |
| FL4606 | 1-234-557-21 | FILTER, LOW PASS | |
| FL4801 | 1-239-848-21 | FILTER, LOW PASS | |
| FL4802 | 1-239-848-21 | FILTER, LOW PASS | |
| FL4803 | 1-239-848-21 | FILTER, LOW PASS | |
| FL4804 | 1-239-848-21 | FILTER, LOW PASS | |
| | | <IC> | |
| IC4601 | 8-752-103-44 | IC CXA2171Q | |
| IC4602 | 8-759-831-53 | IC MC74LVX8053DR2 | |
| IC4603 | 8-752-102-21 | IC CXA2103AQ | |
| IC4604 | 8-759-572-04 | IC TDA9178T/N1.118 | |
| IC4605 | 6-700-205-01 | IC TC74LVX157FT(EL) | |
| IC4606 | 6-700-205-01 | IC TC74LVX157FT(EL) | |
| IC4607 | 8-759-448-68 | IC NJM2283V-TE1 | |
| IC4608 | 8-752-102-21 | IC CXA2103AQ | |
| IC4801 | 6-700-960-01 | IC μPD64083GF-3BA | |
| IC4802 | 6-700-399-01 | IC μPC2925T-E1 | |
| IC4803 | 8-752-930-68 | IC CXP964032-001Q | |
| IC4804 | 8-752-930-68 | IC CXP964032-001Q | |
| | | <COIL> | |
| L4601 | 1-469-555-21 | INDUCTOR 10μH | |
| L4602 | 1-469-555-21 | INDUCTOR 10μH | |
| L4603 | 1-469-555-21 | INDUCTOR 10μH | |
| L4604 | 1-469-555-21 | INDUCTOR 10μH | |
| L4605 | 1-469-555-21 | INDUCTOR 10μH | |
| L4606 | 1-469-555-21 | INDUCTOR 10μH | |
| L4607 | 1-469-555-21 | INDUCTOR 10μH | |
| L4608 | 1-216-864-11 | SHORT CHIP 0 | |
| L4609 | 1-216-864-11 | SHORT CHIP 0 | |
| L4610 | 1-469-555-21 | INDUCTOR 10μH | |
| L4611 | 1-469-555-21 | INDUCTOR 10μH | |
| L4612 | 1-469-555-21 | INDUCTOR 10μH | |
| L4613 | 1-469-555-21 | INDUCTOR 10μH | |
| L4801 | 1-469-553-21 | INDUCTOR 4.7μH | |
| L4802 | 1-469-555-21 | INDUCTOR 10μH | |
| L4803 | 1-469-555-21 | INDUCTOR 10μH | |
| L4804 | 1-469-555-21 | INDUCTOR 10μH | |
| L4805 | 1-469-555-21 | INDUCTOR 10μH | |
| L4806 | 1-412-005-11 | INDUCTOR 8.2μH | |
| L4807 | 1-469-555-21 | INDUCTOR 10μH | |
| L4808 | 1-469-555-21 | INDUCTOR 10μH | |
| L4809 | 1-469-555-21 | INDUCTOR 10μH | |
| L4810 | 1-469-555-21 | INDUCTOR 10μH | |
| L4811 | 1-469-555-21 | INDUCTOR 10μH | |
| L4812 | 1-469-555-21 | INDUCTOR 10μH | |
| | | <TRANSISTOR> | |
| Q4601 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q4602 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q4603 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q4604 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q4605 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q4606 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q4607 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q4608 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q4609 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q4610 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q4611 | 8-729-026-49 | TRANSISTOR 2SA1037AK-T146-QR | |
| Q4612 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q4615 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q4616 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q4617 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q4618 | 8-729-122-63 | TRANSISTOR 2SA1226 | |
| Q4619 | 8-729-122-63 | TRANSISTOR 2SA1226 | |
| Q4620 | 8-729-122-63 | TRANSISTOR 2SA1226 | |
| Q4621 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q4622 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q4623 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q4624 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q4625 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q4626 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q4627 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q4628 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q4629 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q4630 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q4631 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q4632 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q4633 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q4634 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q4635 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q4636 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q4637 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q4638 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q4639 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q4640 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| Q4641 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| Q4642 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| Q4643 | 8-729-216-22 | TRANSISTOR 2SA1162-G | | | |
| Q4644 | 8-729-216-22 | TRANSISTOR 2SA1162-G | | | |
| Q4645 | 8-729-216-22 | TRANSISTOR 2SA1162-G | | | |
| Q4646 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| Q4647 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| Q4801 | 8-729-216-22 | TRANSISTOR 2SA1162-G | | | |
| Q4802 | 8-729-216-22 | TRANSISTOR 2SA1162-G | | | |
| Q4803 | 8-729-216-22 | TRANSISTOR 2SA1162-G | | | |
| Q4804 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| Q4805 | 8-729-216-22 | TRANSISTOR 2SA1162-G | | | |
| Q4806 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| Q4807 | 8-729-216-22 | TRANSISTOR 2SA1162-G | | | |
| Q4808 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| Q4809 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| Q4810 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| Q4811 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| Q4812 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| Q4813 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| Q4814 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| Q4815 | 8-729-216-22 | TRANSISTOR 2SA1162-G | | | |
| Q4816 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| Q4817 | 8-729-216-22 | TRANSISTOR 2SA1162-G | | | |
| Q4818 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| Q4819 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| Q4820 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| Q4821 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| Q4822 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| Q4823 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| Q4824 | 8-729-216-22 | TRANSISTOR 2SA1162-G | | | |
| Q4825 | 8-729-216-22 | TRANSISTOR 2SA1162-G | | | |
| Q4826 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| Q4827 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| | | <RESISTOR> | | | |
| R4601 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4602 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R4603 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |
| R4604 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |
| R4605 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |
| R4606 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |
| R4607 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R4608 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R4609 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |
| R4610 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |
| R4611 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |
| R4612 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |
| R4613 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R4614 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R4615 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |
| R4616 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |
| R4617 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |
| R4618 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |
| R4619 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R4620 | 1-216-808-11 | METAL CHIP | 82 | 5% | 1/10W |
| R4621 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R4622 | 1-216-814-11 | METAL CHIP | 270 | 5% | 1/10W |
| R4623 | 1-216-814-11 | METAL CHIP | 270 | 5% | 1/10W |
| R4624 | 1-216-814-11 | METAL CHIP | 270 | 5% | 1/10W |
| R4625 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R4626 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R4627 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R4628 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R4629 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R4630 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R4631 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R4632 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R4633 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R4634 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R4635 | 1-216-850-11 | METAL CHIP | 270K | 5% | 1/10W |
| R4636 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R4637 | 1-218-716-11 | METAL CHIP | 10K | 0.5% | 1/10W |
| R4638 | 1-216-835-11 | METAL CHIP | 15K | 5% | 1/10W |
| R4639 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R4640 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R4642 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R4643 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R4644 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R4645 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R4646 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R4647 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R4648 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R4649 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R4651 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R4653 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R4654 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R4655 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4656 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4657 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4658 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R4659 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R4660 | 1-216-828-11 | METAL CHIP | 3.9K | 5% | 1/10W |
| R4661 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R4662 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R4663 | 1-218-672-11 | METAL CHIP | 150 | 0.5% | 1/10W |
| R4664 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R4665 | 1-218-672-11 | METAL CHIP | 150 | 0.5% | 1/10W |
| R4666 | 1-218-672-11 | METAL CHIP | 150 | 0.5% | 1/10W |
| R4667 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4668 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R4669 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R4670 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4671 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4672 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4673 | 1-218-710-11 | METAL CHIP | 5.6K | 0.5% | 1/10W |
| R4674 | 1-218-710-11 | METAL CHIP | 5.6K | 0.5% | 1/10W |
| R4675 | 1-218-710-11 | METAL CHIP | 5.6K | 0.5% | 1/10W |
| R4676 | 1-218-686-11 | METAL CHIP | 560 | 0.5% | 1/10W |
| R4677 | 1-218-686-11 | METAL CHIP | 560 | 0.5% | 1/10W |
| R4678 | 1-218-686-11 | METAL CHIP | 560 | 0.5% | 1/10W |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| R4679 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R4680 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R4681 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R4682 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R4683 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R4684 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R4685 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R4686 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4687 | 1-216-838-11 | METAL CHIP | 27K | 5% | 1/10W |
| R4688 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R4689 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4690 | 1-216-838-11 | METAL CHIP | 27K | 5% | 1/10W |
| R4691 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4692 | 1-218-692-11 | METAL CHIP | 1K | 0.5% | 1/10W |
| R4693 | 1-218-696-11 | METAL CHIP | 1.5K | 0.5% | 1/10W |
| R4694 | 1-218-689-11 | METAL CHIP | 750 | 0.5% | 1/10W |
| R4695 | 1-218-690-11 | METAL CHIP | 820 | 0.5% | 1/10W |
| R4696 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R4697 | 1-218-688-11 | METAL CHIP | 680 | 0.5% | 1/10W |
| R4698 | 1-218-732-11 | METAL CHIP | 47K | 0.5% | 1/10W |
| R4699 | 1-218-724-11 | METAL CHIP | 22K | 0.5% | 1/10W |
| R4700 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R4701 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R4702 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R4703 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R4704 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4705 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4706 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4707 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4708 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4709 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4710 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4711 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4712 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4713 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R4714 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4715 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4716 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4717 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4718 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4719 | 1-218-696-11 | METAL CHIP | 1.5K | 0.5% | 1/10W |
| R4724 | 1-218-695-11 | METAL CHIP | 1.3K | 0.5% | 1/10W |
| R4725 | 1-218-688-11 | METAL CHIP | 680 | 0.5% | 1/10W |
| R4726 | 1-218-694-11 | METAL CHIP | 1.2K | 0.5% | 1/10W |
| R4727 | 1-218-690-11 | METAL CHIP | 820 | 0.5% | 1/10W |
| R4728 | 1-218-680-11 | METAL CHIP | 330 | 0.5% | 1/10W |
| R4729 | 1-218-686-11 | METAL CHIP | 560 | 0.5% | 1/10W |
| R4730 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R4731 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R4732 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R4733 | 1-218-670-11 | METAL CHIP | 120 | 0.5% | 1/10W |
| R4734 | 1-218-728-11 | METAL CHIP | 33K | 0.5% | 1/10W |
| R4735 | 1-218-720-11 | METAL CHIP | 15K | 0.5% | 1/10W |
| R4737 | 1-216-842-11 | METAL CHIP | 56K | 5% | 1/10W |
| R4738 | 1-216-838-11 | METAL CHIP | 27K | 5% | 1/10W |
| R4739 | 1-216-842-11 | METAL CHIP | 56K | 5% | 1/10W |
| R4740 | 1-216-838-11 | METAL CHIP | 27K | 5% | 1/10W |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| R4741 | 1-216-813-11 | METAL CHIP | 220 | 5% | 1/10W |
| R4742 | 1-216-835-11 | METAL CHIP | 15K | 5% | 1/10W |
| R4743 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R4744 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R4745 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R4746 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R4747 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R4748 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4749 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4750 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4751 | 1-216-828-11 | METAL CHIP | 3.9K | 5% | 1/10W |
| R4752 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R4753 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R4754 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R4755 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R4756 | 1-218-841-11 | METAL CHIP | 560 | 0.5% | 1/10W |
| R4757 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R4758 | 1-218-841-11 | METAL CHIP | 560 | 0.5% | 1/10W |
| R4759 | 1-218-841-11 | METAL CHIP | 560 | 0.5% | 1/10W |
| R4760 | 1-218-675-11 | METAL CHIP | 200 | 0.5% | 1/10W |
| R4761 | 1-218-710-11 | METAL CHIP | 5.6K | 0.5% | 1/10W |
| R4762 | 1-218-675-11 | METAL CHIP | 200 | 0.5% | 1/10W |
| R4763 | 1-218-710-11 | METAL CHIP | 5.6K | 0.5% | 1/10W |
| R4764 | 1-218-710-11 | METAL CHIP | 5.6K | 0.5% | 1/10W |
| R4765 | 1-218-668-11 | METAL CHIP | 100 | 0.5% | 1/10W |
| R4766 | 1-218-668-11 | METAL CHIP | 100 | 0.5% | 1/10W |
| R4767 | 1-218-668-11 | METAL CHIP | 100 | 0.5% | 1/10W |
| R4768 | 1-218-675-11 | METAL CHIP | 200 | 0.5% | 1/10W |
| R4769 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R4770 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |
| R4771 | 1-218-716-11 | METAL CHIP | 10K | 0.5% | 1/10W |
| R4772 | 1-218-732-11 | METAL CHIP | 47K | 0.5% | 1/10W |
| R4773 | 1-218-732-11 | METAL CHIP | 47K | 0.5% | 1/10W |
| R4774 | 1-218-740-11 | METAL CHIP | 100K | 0.5% | 1/10W |
| R4775 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R4776 | 1-218-672-11 | METAL CHIP | 150 | 0.5% | 1/10W |
| R4777 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R4801 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R4802 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R4803 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R4804 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R4806 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R4807 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R4808 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R4809 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R4810 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R4811 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R4812 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4813 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4814 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R4815 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R4816 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R4817 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R4818 | 1-216-818-11 | METAL CHIP | 560 | 5% | 1/10W |
| R4819 | 1-216-818-11 | METAL CHIP | 560 | 5% | 1/10W |
| R4820 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R4821 | 1-216-830-11 | METAL CHIP | 5.6K | 5% | 1/10W |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| R4822 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R4823 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R4824 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4825 | 1-216-830-11 | METAL CHIP | 5.6K | 5% | 1/10W |
| R4826 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R4827 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R4828 | 1-216-815-11 | METAL CHIP | 330 | 5% | 1/10W |
| R4829 | 1-216-830-11 | METAL CHIP | 5.6K | 5% | 1/10W |
| R4830 | 1-216-818-11 | METAL CHIP | 560 | 5% | 1/10W |
| R4831 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R4832 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R4833 | 1-216-849-11 | METAL CHIP | 220K | 5% | 1/10W |
| R4834 | 1-216-816-11 | METAL CHIP | 390 | 5% | 1/10W |
| R4835 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R4836 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R4837 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R4838 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R4839 | 1-216-819-11 | METAL CHIP | 680 | 5% | 1/10W |
| R4840 | 1-216-813-11 | METAL CHIP | 220 | 5% | 1/10W |
| R4841 | 1-216-819-11 | METAL CHIP | 680 | 5% | 1/10W |
| R4842 | 1-216-820-11 | METAL CHIP | 820 | 5% | 1/10W |
| R4843 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R4844 | 1-218-680-11 | METAL CHIP | 330 | 0.5% | 1/10W |
| R4845 | 1-218-684-11 | METAL CHIP | 470 | 0.5% | 1/10W |
| R4846 | 1-216-839-11 | METAL CHIP | 33K | 5% | 1/10W |
| R4847 | 1-216-834-11 | METAL CHIP | 12K | 5% | 1/10W |
| R4848 | 1-216-822-11 | METAL CHIP | 1.2K | 5% | 1/10W |
| R4849 | 1-216-820-11 | METAL CHIP | 820 | 5% | 1/10W |
| R4850 | 1-216-839-11 | METAL CHIP | 33K | 5% | 1/10W |
| R4851 | 1-216-834-11 | METAL CHIP | 12K | 5% | 1/10W |
| R4852 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R4853 | 1-216-830-11 | METAL CHIP | 5.6K | 5% | 1/10W |
| R4854 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R4855 | 1-216-813-11 | METAL CHIP | 220 | 5% | 1/10W |
| R4856 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R4858 | 1-216-818-11 | METAL CHIP | 560 | 5% | 1/10W |
| R4859 | 1-218-688-11 | METAL CHIP | 680 | 0.5% | 1/10W |
| R4860 | 1-218-688-11 | METAL CHIP | 680 | 0.5% | 1/10W |
| R4861 | 1-218-699-11 | METAL CHIP | 2K | 0.5% | 1/10W |
| R4862 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R4863 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4864 | 1-218-692-11 | METAL CHIP | 1K | 0.5% | 1/10W |
| R4865 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R4866 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R4867 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R4868 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R4869 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R4870 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R4871 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R4872 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R4873 | 1-216-857-11 | METAL CHIP | 1M | 5% | 1/10W |
| R4874 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R4875 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R4876 | 1-216-811-11 | METAL CHIP | 150 | 5% | 1/10W |
| R4877 | 1-216-811-11 | METAL CHIP | 150 | 5% | 1/10W |
| R4878 | 1-216-811-11 | METAL CHIP | 150 | 5% | 1/10W |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| R4879 | 1-218-706-11 | METAL CHIP | 3.9K | 0.5% | 1/10W |
| R4880 | 1-216-857-11 | METAL CHIP | 1M | 5% | 1/10W |
| R4881 | 1-216-811-11 | METAL CHIP | 150 | 5% | 1/10W |
| R4882 | 1-216-811-11 | METAL CHIP | 150 | 5% | 1/10W |
| R4883 | 1-216-811-11 | METAL CHIP | 150 | 5% | 1/10W |
| R4884 | 1-218-706-11 | METAL CHIP | 3.9K | 0.5% | 1/10W |
| R4885 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R4886 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R4887 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R4888 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R4889 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R4890 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R4891 | 1-218-692-11 | METAL CHIP | 1K | 0.5% | 1/10W |
| R4892 | 1-216-827-11 | METAL CHIP | 3.3K | 5% | 1/10W |
| R4893 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R4894 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R4895 | 1-218-692-11 | METAL CHIP | 1K | 0.5% | 1/10W |
| R4896 | 1-216-827-11 | METAL CHIP | 3.3K | 5% | 1/10W |
| R4897 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R4898 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R4899 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R4900 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R4901 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R4902 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R4903 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R4904 | 1-216-824-11 | METAL CHIP | 1.8K | 5% | 1/10W |
| R4905 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R4906 | 1-216-824-11 | METAL CHIP | 1.8K | 5% | 1/10W |
| R4907 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R4908 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R4909 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R4910 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R4911 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R4912 | 1-216-820-11 | METAL CHIP | 820 | 5% | 1/10W |
| R4913 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R4914 | 1-216-820-11 | METAL CHIP | 820 | 5% | 1/10W |
| R4915 | 1-216-820-11 | METAL CHIP | 820 | 5% | 1/10W |
| R4916 | 1-216-864-11 | SHORT CHIP | 0 | | |

<CRYSTAL>

| | | |
|---|---|---|
| X4601 | 1-567-505-11 | OSCILLATOR, CRYSTAL 3.58MHz |
| X4602 | 1-781-282-11 | VIBRATOR, CERAMIC 4MHz |
| X4603 | 1-567-505-11 | OSCILLATOR, CRYSTAL 3.58MHz |
| X4801 | 1-767-606-11 | VIBRATOR, CRYSTAL 20MHz |
| X4802 | 1-795-565-21 | VIBRATOR, CERAMIC 10MHz |
| X4803 | 1-795-565-21 | VIBRATOR, CERAMIC 10MHz |

**********

# BF BM1C

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| * | A-1401-410-A | BF BOARD, COMPLETE ********** | | | |
| * | 4-374-906-01 | HOLDER (TV/V), LED | | | |
| | | <CAPACITOR> | | | |
| C7205 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C7206 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C7208 | 1-126-964-11 | ELECT | 10μF | 20% | 50V |
| C7209 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C7210 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C7212 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C7213 | 1-126-965-91 | ELECT | 22μF | 20% | 50V |
| C7214 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C7215 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C7216 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C7217 | 1-126-965-91 | ELECT | 22μF | 20% | 50V |
| C7219 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C7220 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| | | <CONNECTOR> | | | |
| CN7201 * | 1-816-402-12 | CONNECTOR, MEMORY STICK (MEMORY STICK) | | | |
| CN7202 * | 1-816-124-11 | PIN, CONNECTOR (FOR PWB) 18P | | | |
| CN7204 | 1-695-915-11 | TAB (CONTACT) | | | |
| | | <DIODE> | | | |
| D7201 | 8-719-800-76 | DIODE MA153-TX | | | |
| D7202 | 8-719-800-76 | DIODE MA153-TX | | | |
| D7203 | 8-719-800-76 | DIODE MA153-TX | | | |
| D7204 | 8-719-800-76 | DIODE MA153-TX | | | |
| D7205 | 8-719-800-76 | DIODE MA153-TX | | | |
| D7206 | 8-719-800-76 | DIODE MA153-TX | | | |
| D7207 | 8-719-800-76 | DIODE MA153-TX | | | |
| D7208 | 8-719-800-76 | DIODE MA153-TX | | | |
| D7209 | 8-719-069-94 | DIODE TLR124 | | | |
| D7210 | 8-719-056-77 | DIODE UDZ-TE-17-3.9B | | | |
| D7211 | 8-719-056-77 | DIODE UDZ-TE-17-3.9B | | | |
| D7212 | 8-719-800-76 | DIODE MA153-TX | | | |
| D7213 | 8-719-800-76 | DIODE MA153-TX | | | |
| D7214 | 8-719-800-76 | DIODE MA153-TX | | | |
| D7215 | 8-719-800-76 | DIODE MA153-TX | | | |
| D7216 | 8-719-800-76 | DIODE MA153-TX | | | |
| D7217 | 8-719-800-76 | DIODE MA153-TX | | | |
| | | <FERRITE BEAD> | | | |
| FB7201 | 1-414-921-11 | FERRITE | 0μH | | |
| FB7202 | 1-414-921-11 | FERRITE | 0μH | | |
| FB7203 | 1-414-921-11 | FERRITE | 0μH | | |
| FB7204 | 1-414-921-11 | FERRITE | 0μH | | |
| | | <IC> | | | |
| IC7201 | 8-759-639-86 | IC SN65LVDS32DR | | | |
| IC7202 | 6-701-763-11 | IC DS90LV017ATMX | | | |
| IC7203 | 8-759-698-08 | IC SN74CBTLV1G125DCKR | | | |
| | | <COIL> | | | |
| L7201 | 1-419-370-21 | INDUCTOR | 0μH | | |
| L7202 | 1-419-370-21 | INDUCTOR | 0μH | | |
| L7203 | 1-419-370-21 | INDUCTOR | 0μH | | |
| L7204 | 1-419-370-21 | INDUCTOR | 0μH | | |
| L7205 | 1-419-370-21 | INDUCTOR | 0μH | | |
| | | <TRANSISTOR> | | | |
| Q7201 | 8-729-216-22 | TRANSISTOR 2SA1162-G | | | |
| Q7202 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| Q7203 | 8-729-216-22 | TRANSISTOR 2SA1162-G | | | |
| | | <RESISTOR> | | | |
| R7201 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R7202 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R7204 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R7205 | 1-218-692-11 | METAL CHIP | 1K | 0.5% | 1/10W |
| R7206 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R7207 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R7208 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R7209 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R7210 | 1-216-803-11 | METAL CHIP | 33 | 5% | 1/10W |
| R7221 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R7222 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R7224 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R7225 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R7226 | 1-218-716-11 | METAL CHIP | 10K | 0.5% | 1/10W |
| R7228 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R7231 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R7232 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R7233 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |

**********

| | | | | | |
|---|---|---|---|---|---|
| * | A-1300-650-A | BM1C BOARD, COMPLETE ********** | | | |
| | | <CAPACITOR> | | | |
| C103 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C105 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C106 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C107 | 1-126-390-11 | ELECT CHIP | 22μF | 20% | 6.3V |
| C108 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C110 | 1-126-394-11 | ELECT CHIP | 10μF | 20% | 16V |
| C112 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C118 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C123 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C124 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C125 | 1-125-891-11 | CERAMIC CHIP | 0.47μF | 10% | 10V |
| C126 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| C127 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C128 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C129 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C130 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C131 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C132 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C133 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C134 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C135 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C136 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C137 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C138 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C139 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C141 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C142 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C143 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C144 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C145 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C146 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C147 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C148 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C151 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C154 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C162 | 1-126-394-11 | ELECT CHIP | 10μF | 20% | 16V |
| C163 | 1-126-394-11 | ELECT CHIP | 10μF | 20% | 16V |
| C164 | 1-126-390-11 | ELECT CHIP | 22μF | 20% | 6.3V |
| C165 | 1-124-779-00 | ELECT CHIP | 10μF | 20% | 16V |
| C166 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| | | <CONNECTOR> | | | |
| CN104 | * 1-816-933-21 | CONNECTOR,BOARDTOBOARD 60P | | | |
| | | <DIODE> | | | |
| D101 | 8-719-024-77 | DIODE HN1D03FU-TE85R | | | |
| D102 | 8-719-024-77 | DIODE HN1D03FU-TE85R | | | |
| D201 | 8-719-024-77 | DIODE HN1D03FU-TE85R | | | |
| | | <FERRITE BEAD> | | | |
| FB101 | 1-414-921-11 | FERRITE | 0μH | | |
| FB102 | 1-414-921-11 | FERRITE | 0μH | | |
| FB103 | 1-414-921-11 | FERRITE | 0μH | | |
| FB104 | 1-414-921-11 | FERRITE | 0μH | | |
| FB106 | 1-500-451-11 | FERRITE | 0μH | | |
| FB109 | 1-414-921-11 | FERRITE | 0μH | | |
| FB110 | 1-414-921-11 | FERRITE | 0μH | | |
| FB111 | 1-414-921-11 | FERRITE | 0μH | | |
| FB120 | 1-414-921-11 | FERRITE | 0μH | | |
| FB121 | 1-414-921-11 | FERRITE | 0μH | | |
| FB122 | 1-414-921-11 | FERRITE | 0μH | | |
| FB123 | 1-414-921-11 | FERRITE | 0μH | | |
| FB124 | 1-414-921-11 | FERRITE | 0μH | | |
| FB137 | 1-414-921-11 | FERRITE | 0μH | | |
| FB141 | 1-414-921-11 | FERRITE | 0μH | | |
| FB143 | 1-414-921-11 | FERRITE | 0μH | | |
| FB149 | 1-414-921-11 | FERRITE | 0μH | | |
| | | <IC> | | | |
| IC101 | 6-702-978-01 | IC MD2406 | | | |
| IC102 | 6-802-277-11 | IC SST39VF800A70E-11300-T | | | |
| IC104 | 8-759-460-72 | IC BA033FP-E2 | | | |
| IC106 | 8-759-661-55 | IC 24LC21AT/SN | | | |
| IC107 | 8-759-331-27 | IC MM1096AFF | | | |
| IC108 | 6-702-511-01 | IC MT48LC8M16A2TG-75-Y95W | | | |
| IC111 | 8-759-832-05 | IC BA18BC0FP-E2 | | | |
| IC121 | 8-752-932-19 | IC CXP86608-001R | | | |
| | | <COIL> | | | |
| L106 | 1-469-555-21 | INDUCTOR | 10μH | | |
| L107 | 1-469-561-21 | INDUCTOR | 100μH | | |
| | | <TRANSISTOR> | | | |
| Q101 | 8-729-013-28 | TRANSISTOR HN1B01FU-TE85R | | | |
| Q103 | 8-729-905-35 | TRANSISTOR 2SC4081T106R | | | |
| Q105 | 8-729-427-72 | TRANSISTOR HN1C01FU-TE85R | | | |
| Q110 | 8-729-900-53 | TRANSISTOR DTC114EK | | | |
| Q116 | 8-729-900-53 | TRANSISTOR DTC114EK | | | |
| Q201 | 8-729-026-53 | TRANSISTOR 2SA1576A-T106-QR | | | |
| Q202 | 8-729-028-28 | TRANSISTOR 2SK2036(TE85L) | | | |
| Q203 | 8-729-028-28 | TRANSISTOR 2SK2036(TE85L) | | | |
| | | <RESISTOR> | | | |
| R101 | 1-216-797-11 | METAL CHIP | 10 | 5% | 1/10W |
| R102 | 1-216-797-11 | METAL CHIP | 10 | 5% | 1/10W |
| R103 | 1-216-797-11 | METAL CHIP | 10 | 5% | 1/10W |
| R105 | 1-216-797-11 | METAL CHIP | 10 | 5% | 1/10W |
| R110 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R111 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R112 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R113 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R120 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R121 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R124 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R125 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R127 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R128 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R129 | 1-218-712-11 | METAL CHIP | 6.8K | 0.5% | 1/10W |
| R136 | 1-216-797-11 | METAL CHIP | 10 | 5% | 1/10W |
| R137 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R143 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R144 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R145 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R148 | 1-216-839-11 | METAL CHIP | 33K | 5% | 1/10W |
| R149 | 1-216-839-11 | METAL CHIP | 33K | 5% | 1/10W |
| R150 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R152 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R155 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R158 | 1-216-864-11 | SHORT CHIP | 0 | | |

The components identified by shading and mark [ ! ] are critical for safety. Replace only with part number specified.

Les composants identifi□s par un tram□ et une marque [ ! ] sont critiques pour la s□curit□. Ne les remplacer que par une pi□ce portant le num□ro sp□cifi□.

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| R161 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R164 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R186 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R189 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R190 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R201 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R202 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R203 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R205 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R206 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R208 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R209 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R213 | 1-218-830-11 | METAL CHIP | 200 | 0.5% | 1/10W |
| R217 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R218 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R219 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R221 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R222 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R226 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R230 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R232 | 1-218-709-11 | METAL CHIP | 5.1K | 0.5% | 1/10W |
| R238 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R239 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R240 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R283 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R287 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R288 | 1-216-797-11 | METAL CHIP | 10 | 5% | 1/10W |
| R290 | 1-216-797-11 | METAL CHIP | 10 | 5% | 1/10W |
| | | <NETWORK RESISTOR> | | | |
| RB101 | 1-234-381-21 | RES, NETWORK 100KX4 | (1005) | | |
| RB102 | 1-234-381-21 | RES, NETWORK 100KX4 | (1005) | | |
| RB103 | 1-234-381-21 | RES, NETWORK 100KX4 | (1005) | | |
| RB104 | 1-234-381-21 | RES, NETWORK 100KX4 | (1005) | | |
| RB105 | 1-234-372-21 | RES, NETWORK 100X4 | (1005) | | |
| RB106 | 1-234-378-21 | RES, NETWORK 10KX4 | (1005) | | |
| RB107 | 1-234-370-21 | RES, NETWORK 22X4 | (1005) | | |
| RB108 | 1-234-370-21 | RES, NETWORK 22X4 | (1005) | | |
| RB109 | 1-234-370-21 | RES, NETWORK 22X4 | (1005) | | |
| RB110 | 1-234-370-21 | RES, NETWORK 22X4 | (1005) | | |
| RB111 | 1-234-370-21 | RES, NETWORK 22X4 | (1005) | | |
| RB112 | 1-234-370-21 | RES, NETWORK 22X4 | (1005) | | |
| RB113 | 1-234-378-21 | RES, NETWORK 10KX4 | (1005) | | |
| RB114 | 1-234-378-21 | RES, NETWORK 10KX4 | (1005) | | |
| RB115 | 1-234-378-21 | RES, NETWORK 10KX4 | (1005) | | |
| RB121 | 1-234-371-21 | RES, NETWORK 47X4 | (1005) | | |
| RB122 | 1-234-371-21 | RES, NETWORK 47X4 | (1005) | | |
| RB123 | 1-234-371-21 | RES, NETWORK 47X4 | (1005) | | |
| RB124 | 1-234-371-21 | RES, NETWORK 47X4 | (1005) | | |
| RB131 | 1-234-378-21 | RES, NETWORK 10KX4 | (1005) | | |
| RB132 | 1-234-378-21 | RES, NETWORK 10KX4 | (1005) | | |
| RB133 | 1-234-378-21 | RES, NETWORK 10KX4 | (1005) | | |
| RB134 | 1-234-378-21 | RES, NETWORK 10KX4 | (1005) | | |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| | | <CRYSTAL> | | | |
| X101 | 1-795-725-21 | CRYSTAL OSCILLATOR (SMD) 49.090908MHz | | | |
| X102 | 1-795-313-21 | VIBRATOR, CERAMIC | | | |
| ********** | | | | | |
| * | A-1300-695-A | G BOARD, COMPLETE | | | |
| | | ********** | | | |
| | 1-533-223-11 | FUSE HOLDER 0A 0V | | | |
| * | 4-374-846-11 | COVER, CAPACITOR, CAP TYPE | | | |
| | 4-382-854-01 | SCREW (M3X8), P, SW (+) | | | |
| | | <CAPACITOR> | | | |
| C1602 | 1-163-005-91 | CERAMIC CHIP | 470pF | 10% | 50V |
| C1603 | 1-107-679-91 | ELECT | 10μF | 20% | 450V |
| ! C1604 | 1-161-830-00 | CERAMIC | 0.0047μF | 99% | 500V |
| ! C1605 | 1-161-830-00 | CERAMIC | 0.0047μF | 99% | 500V |
| C1606 | 1-163-809-11 | CERAMIC CHIP | 0.047μF | 10% | 25V |
| ! C1607 | 1-161-830-00 | CERAMIC | 0.0047μF | 99% | 500V |
| ! C1608 | 1-161-830-00 | CERAMIC | 0.0047μF | 99% | 500V |
| C1609 | 1-163-021-91 | CERAMIC CHIP | 0.01μF | 10% | 50V |
| C1610 | 1-163-009-91 | CERAMIC CHIP | 0.001μF | 10% | 50V |
| C1611 | 1-137-750-11 | ELECT | 1500μF | 20% | 250V |
| C1612 | 1-137-750-11 | ELECT | 1500μF | 20% | 250V |
| C1613 | 1-126-964-11 | ELECT | 10μF | 20% | 50V |
| C1614 | 1-126-967-11 | ELECT | 47μF | 20% | 50V |
| C1615 | 1-126-948-11 | ELECT | 100μF | 20% | 35V |
| C1616 | 1-137-605-11 | MYLAR | 0.01μF | 10% | 250V |
| C1617 | 1-126-965-91 | ELECT | 22μF | 20% | 50V |
| C1618 | 1-136-165-00 | FILM | 0.1μF | 5% | 50V |
| C1620 | 1-126-960-11 | ELECT | 1μF | 20% | 50V |
| C1621 | 1-126-940-11 | ELECT | 330μF | 20% | 25V |
| C1622 | 1-126-961-11 | ELECT | 2.2μF | 20% | 50V |
| C1623 | 1-136-479-11 | FILM | 0.001μF | 2% | 50V |
| C1624 | 1-126-962-11 | ELECT | 3.3μF | 20% | 50V |
| C1625 | 1-164-004-11 | CERAMIC CHIP | 0.1μF | 10% | 25V |
| C1627 | 1-125-969-91 | CERAMIC | 680pF | 10% | 1KV |
| C1628 | 1-125-969-91 | CERAMIC | 680pF | 10% | 1KV |
| C1629 | 1-165-953-11 | FILM | 47000pF | 3% | 800V |
| C1630 | 1-126-939-11 | ELECT | 10000μF | 20% | 16V |
| C1631 | 1-126-942-61 | ELECT | 1000μF | 20% | 25V |
| C1632 | 1-126-964-11 | ELECT | 10μF | 20% | 50V |
| C1633 | 1-126-947-11 | ELECT | 47μF | 20% | 25V |
| C1634 | 1-128-548-11 | ELECT | 4700μF | 20% | 25V |
| C1635 | 1-128-548-11 | ELECT | 4700μF | 20% | 25V |
| C1636 | 1-163-021-91 | CERAMIC CHIP | 0.01μF | 10% | 50V |
| C1637 | 1-126-929-11 | ELECT | 4700μF | 20% | 10V |
| C1638 | 1-128-546-11 | ELECT | 10000μF | 20% | 10V |
| C1639 | 1-164-004-11 | CERAMIC CHIP | 0.1μF | 10% | 25V |
| C1640 | 1-126-947-11 | ELECT | 47μF | 20% | 25V |
| C1641 | 1-126-947-11 | ELECT | 47μF | 20% | 25V |
| C1642 | 1-126-964-11 | ELECT | 10μF | 20% | 50V |
| C1643 | 1-126-947-11 | ELECT | 47μF | 20% | 25V |
| C1644 | 1-126-947-11 | ELECT | 47μF | 20% | 25V |

The components identified by shading and mark [ ! ] are critical for safety. Replace only with part number specified.

Les composants identifi□s par un tram□ et une marque [ ! ] sont critiques pour la s□curit□. Ne les remplacer que par une pi□ce portant le num□ro sp□cifi□.

| REF. NO. | | PART NO. | DESCRIPTION | | | | REMARK |
|---|---|---|---|---|---|---|---|
| C1645 | | 1-126-947-11 | ELECT | 47µF | 20% | 25V | |
| C1646 | | 1-163-021-91 | CERAMIC CHIP | 0.01µF | 10% | 50V | |
| C1647 | | 1-163-021-91 | CERAMIC CHIP | 0.01µF | 10% | 50V | |
| C1648 | | 1-163-021-91 | CERAMIC CHIP | 0.01µF | 10% | 50V | |
| C1649 | | 1-163-021-91 | CERAMIC CHIP | 0.01µF | 10% | 50V | |
| C1650 | | 1-163-021-91 | CERAMIC CHIP | 0.01µF | 10% | 50V | |
| C1651 | | 1-163-021-91 | CERAMIC CHIP | 0.01µF | 10% | 50V | |
| C1652 | | 1-126-964-11 | ELECT | 10µF | 20% | 50V | |
| C1653 | | 1-126-967-11 | ELECT | 47µF | 20% | 50V | |
| C1654 | | 1-126-947-11 | ELECT | 47µF | 20% | 25V | |
| C1655 | | 1-163-009-91 | CERAMIC CHIP | 0.001µF | 10% | 50V | |
| C1656 | | 1-163-009-91 | CERAMIC CHIP | 0.001µF | 10% | 50V | |
| C1657 | | 1-163-009-91 | CERAMIC CHIP | 0.001µF | 10% | 50V | |
| C1658 | | 1-163-009-91 | CERAMIC CHIP | 0.001µF | 10% | 50V | |
| C1659 | | 1-137-194-81 | FILM | 0.47µF | 5% | 50V | |
| C1660 | ! | 1-104-708-11 | MYLAR | 0.47µF | 20% | 250V | |
| C1661 | ! | 1-119-888-51 | CERAMIC | 2200pF | 20% | 250V | |
| C1662 | ! | 1-119-888-51 | CERAMIC | 2200pF | 20% | 250V | |
| C1664 | ! | 1-107-533-11 | MYLAR | 1µF | 20% | 250V | |
| C1666 | | 1-109-843-11 | CERAMIC | 33pF | 5% | 2KV | |
| C1667 | | 1-109-843-11 | CERAMIC | 33pF | 5% | 2KV | |
| C1668 | | 1-109-843-11 | CERAMIC | 33pF | 5% | 2KV | |
| C1669 | | 1-109-843-11 | CERAMIC | 33pF | 5% | 2KV | |
| C1670 | | 1-125-497-11 | ELECT(BLOCK) | 100µF | 20% | 400V | |
| C1671 | | 1-125-497-11 | ELECT(BLOCK) | 100µF | 20% | 400V | |
| C1672 | | 1-161-830-00 | CERAMIC | 0.0047µF | 500V | | |

<CONNECTOR>

| | | | | |
|---|---|---|---|---|
| CN1601 | * | 1-580-843-11 | PIN, CONNECTOR (POWER) | |
| CN1602 | * | 1-691-960-21 | PIN, CONNECTOR (PC BOARD) 3P | |
| CN1603 | * | 1-564-511-61 | PLUG, CONNECTOR 8P | |
| CN1604 | * | 1-580-838-11 | PIN, CONNECTOR (PC BOARD) 4P | |
| CN1605 | * | 1-564-508-11 | PLUG, CONNECTOR 5P | |
| CN1606 | * | 1-564-510-11 | PLUG, CONNECTOR 7P | |
| CN1607 | * | 1-564-506-11 | PLUG, CONNECTOR 3P | |
| CN1608 | | 1-695-915-11 | TAB (CONTACT) | |
| CN1609 | | 1-695-915-11 | TAB (CONTACT) | |
| CN1610 | | 1-695-915-11 | TAB (CONTACT) | |
| CN1611 | | 1-695-915-11 | TAB (CONTACT) | |
| CN1613 | * | 1-564-512-11 | PLUG, CONNECTOR 9P | |
| CN1614 | * | 1-564-506-11 | PLUG, CONNECTOR 3P | |
| CN1616 | * | 1-691-960-11 | PIN, CONNECTOR (PC BOARD) 3P | |
| CN1617 | * | 1-564-506-11 | PLUG, CONNECTOR 3P | |

<DIODE>

| | | | | |
|---|---|---|---|---|
| D1601 | ! | 8-719-077-76 | DIODE | D2SB60A-F04 |
| D1602 | ! | 8-719-022-99 | DIODE | D6SB60L |
| D1603 | | 8-719-106-89 | DIODE | RD15M-T1B2 |
| D1604 | | 8-719-404-50 | DIODE | MA111-TX |
| D1605 | | 8-719-948-45 | DIODE | ERA22-08 |
| D1606 | | 8-719-106-17 | DIODE | RD6.8M-B2 |
| D1607 | | 8-719-979-64 | DIODE | µF4005PKG23 |
| D1608 | | 8-719-060-90 | DIODE | S2L60F |
| D1609 | | 8-719-063-73 | DIODE | D1NL20U-TR |
| D1610 | | 8-719-510-48 | DIODE | D1N20R |
| D1612 | | 8-719-060-90 | DIODE | S2L60F |
| D1613 | | 8-719-510-02 | DIODE | D1NS4-TA2 |
| D1614 | | 8-719-510-02 | DIODE | D1NS4-TA2 |
| D1616 | | 8-719-510-02 | DIODE | D1NS4-TA2 |
| D1617 | | 8-719-510-02 | DIODE | D1NS4-TA2 |
| D1618 | | 8-719-404-50 | DIODE | MA111-TX |
| D1619 | | 8-719-105-91 | DIODE | RD5.6M-B2 |
| D1620 | | 8-719-055-40 | DIODE | FCQ30A04 |
| D1621 | | 8-719-018-84 | DIODE | D2S6MTA1 |
| D1623 | | 8-719-055-40 | DIODE | FCQ30A04 |
| D1624 | | 8-719-510-09 | DIODE | D10SC6M |
| D1625 | | 8-719-988-31 | DIODE | D10SC6MR |
| D1626 | | 8-719-510-12 | DIODE | D10SC4M |
| D1629 | | 8-719-404-50 | DIODE | MA111-TX |
| D1630 | | 8-719-404-50 | DIODE | MA111-TX |
| D1631 | | 8-719-404-50 | DIODE | MA111-TX |
| D1632 | | 1-216-295-91 | SHORT CHIP | 0 |
| D1633 | | 8-719-068-00 | DIODE | ERC04-06SE |
| D1634 | | 8-719-068-00 | DIODE | ERC04-06SE |
| D1635 | | 8-719-060-90 | DIODE | S2L60F |
| D1636 | | 8-719-060-90 | DIODE | S2L60F |
| D1638 | | 8-719-404-50 | DIODE | MA111-TX |

<FUSE>

| | | | | |
|---|---|---|---|---|
| F1601 | ! | 1-576-193-11 | FUSE 6.3A 125V 6.3 | |

<FERRITE BEAD>

| | | | | |
|---|---|---|---|---|
| FB1601 | | 1-410-397-21 | FERRITE | 1.1µH |
| FB1602 | | 1-410-397-21 | FERRITE | 1.1µH |
| FB1603 | | 1-410-397-21 | FERRITE | 1.1µH |
| FB1604 | | 1-410-397-21 | FERRITE | 1.1µH |
| FB1605 | | 1-410-397-21 | FERRITE | 1.1µH |
| FB1606 | | 1-410-397-21 | FERRITE | 1.1µH |

<IC>

| | | | | |
|---|---|---|---|---|
| IC1601 | | 8-759-670-30 | IC | MCZ3001D |
| IC1602 | | 8-759-198-31 | IC | µPC1093J-1-T |

<COIL>

| | | | | |
|---|---|---|---|---|
| L1601 | | 1-412-525-31 | INDUCTOR | 10µH |
| L1604 | | 1-412-525-31 | INDUCTOR | 10µH |
| L1606 | | 1-412-525-31 | INDUCTOR | 10µH |
| L1607 | | 1-412-525-31 | INDUCTOR | 10µH |
| L1608 | | 1-412-525-31 | INDUCTOR | 10µH |
| L1609 | | 1-406-659-11 | INDUCTOR | 10µH |
| L1610 | | 1-406-971-21 | INDUCTOR | 10µH |
| L1612 | | 1-406-659-11 | INDUCTOR | 10µH |
| L1616 | | 1-406-984-21 | INDUCTOR | 1.5mH |

<PHOTO COUPLER>

| | | | | |
|---|---|---|---|---|
| PH1601 | ! | 8-749-924-35 | PHOTO COUPLER | ON3171-R |

The components identified by shading and mark [ ! ] are critical for safety. Replace only with part number specified.

Les composants identifi□s par un tram□ et une marque [ ! ] sont critiques pour la s□curit□. Ne les remplacer que par une pi□ce portant le num□ro sp□cifi□.

| REF. NO. | | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|---|
| | | | <IC LINK> | | | |
| PS1601 | ! | 1-576-390-91 | IC LINK 2.5A 50V | | | |
| PS1602 | ! | 1-576-390-91 | IC LINK 2.5A 50V | | | |
| | | | <TRANSISTOR> | | | |
| Q1601 | | 8-729-046-40 | TRANSISTOR 2SK2663 | | | |
| Q1602 | | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| Q1603 | | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| Q1604 | | 8-729-216-22 | TRANSISTOR 2SA1162-G | | | |
| Q1605 | | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| Q1606 | | 8-729-052-32 | TRANSISTOR IRFIB7N50A | | | |
| Q1607 | | 8-729-052-32 | TRANSISTOR IRFIB7N50A | | | |
| | | | <RESISTOR> | | | |
| R1601 | | 1-260-302-51 | CARBON | 6.8 | 5% | 1/2W |
| R1603 | | 1-216-045-00 | RES-CHIP | 680 | 5% | 1/10W |
| R1604 | | 1-240-205-91 | METAL | 22M | 5% | 1/2W |
| R1605 | | 1-216-009-91 | RES-CHIP | 22 | 5% | 1/10W |
| R1606 | | 1-249-389-11 | CARBON | 4.7 | 5% | 1/4W |
| R1607 | | 1-249-417-11 | CARBON | 1K | 5% | 1/4W |
| R1608 | | 1-216-073-91 | RES-CHIP | 10K | 5% | 1/10W |
| R1609 | | 1-216-041-00 | RES-CHIP | 470 | 5% | 1/10W |
| R1610 | | 1-260-131-11 | CARBON | 470K | 5% | 1/2W |
| R1611 | | 1-260-131-11 | CARBON | 470K | 5% | 1/2W |
| R1612 | | 1-215-485-00 | METAL | 470K | 1% | 1/4W |
| R1613 | ! | 1-202-933-61 | FUSIBLE | 0.1 | 10% | 1/2W |
| R1616 | | 1-249-393-11 | CARBON | 10 | 5% | 1/4W |
| R1617 | ! | 1-249-377-11 | CARBON | 0.47 | 5% | 1/4W |
| R1618 | ! | 1-202-933-61 | FUSIBLE | 0.1 | 10% | 1/2W |
| R1619 | ! | 1-202-933-61 | FUSIBLE | 0.1 | 10% | 1/2W |
| R1620 | | 1-216-073-91 | RES-CHIP | 10K | 5% | 1/10W |
| R1621 | | 1-216-065-91 | RES-CHIP | 4.7K | 5% | 1/10W |
| R1622 | | 1-216-073-91 | RES-CHIP | 10K | 5% | 1/10W |
| R1623 | | 1-216-049-11 | RES-CHIP | 1K | 5% | 1/10W |
| R1624 | | 1-215-481-00 | METAL | 330K | 1% | 1/4W |
| R1625 | | 1-215-481-00 | METAL | 330K | 1% | 1/4W |
| R1626 | | 1-215-481-00 | METAL | 330K | 1% | 1/4W |
| R1627 | | 1-215-859-00 | METAL OXIDE | 22 | 5% | 1W |
| R1628 | | 1-216-679-11 | METAL CHIP | 15K | 0.5% | 1/10W |
| R1629 | | 1-216-674-11 | METAL CHIP | 9.1K | 0.5% | 1/10W |
| R1630 | | 1-216-073-91 | RES-CHIP | 10K | 5% | 1/10W |
| R1631 | | 1-216-073-91 | RES-CHIP | 10K | 5% | 1/10W |
| R1632 | | 1-249-393-11 | CARBON | 10 | 5% | 1/4W |
| R1633 | | 1-216-073-91 | RES-CHIP | 10K | 5% | 1/10W |
| R1634 | | 1-249-393-11 | CARBON | 10 | 5% | 1/4W |
| R1635 | | 1-216-073-91 | RES-CHIP | 10K | 5% | 1/10W |
| R1638 | | 1-202-965-11 | METAL | 0.02 | 10% | 2W |
| R1640 | | 1-216-350-11 | METAL OXIDE | 1.2 | 5% | 1W |
| R1641 | | 1-216-049-11 | RES-CHIP | 1K | 5% | 1/10W |
| R1642 | | 1-216-051-00 | RES-CHIP | 1.2K | 5% | 1/10W |
| R1643 | | 1-216-659-11 | METAL CHIP | 2.2K | 0.5% | 1/10W |
| R1644 | | 1-216-025-11 | RES-CHIP | 100 | 5% | 1/10W |
| R1645 | | 1-216-017-91 | RES-CHIP | 47 | 5% | 1/10W |
| R1646 | | 1-216-057-00 | RES-CHIP | 2.2K | 5% | 1/10W |
| R1647 | | 1-216-041-00 | RES-CHIP | 470 | 5% | 1/10W |
| R1648 | | 1-216-089-91 | RES-CHIP | 47K | 5% | 1/10W |
| R1649 | | 1-216-049-11 | RES-CHIP | 1K | 5% | 1/10W |
| R1650 | | 1-216-658-11 | METAL CHIP | 2K | 0.5% | 1/10W |
| R1651 | ! | 1-240-303-11 | CEMENTED | 0.22 | 5% | 10W |
| R1652 | ! | 1-240-303-11 | CEMENTED | 0.22 | 5% | 10W |
| R1653 | ! | 1-202-844-00 | SOLID | 330K | 20% | 1/2W |
| R1654 | ! | 1-260-288-11 | CARBON | 0.47 | 5% | 1/2W |
| R1655 | ! | 1-260-288-11 | CARBON | 0.47 | 5% | 1/2W |
| R1656 | | 1-215-904-11 | METAL OXIDE | 100K | 5% | 2W |
| R1657 | | 1-215-904-11 | METAL OXIDE | 100K | 5% | 2W |
| R1659 | | 1-216-295-91 | SHORT CHIP | 0 | | |
| R1662 | ! | 1-218-265-11 | METAL | 8.2M | 5% | 1W |
| R1664 | | 1-216-295-91 | SHORT CHIP | 0 | | |
| R1675 | | 1-216-049-11 | RES-CHIP | 1K | 5% | 1/10W |
| | | | <RELAY> | | | |
| RY1601 | ! | 1-755-388-11 | RELAY (AC POWER) | | | |
| | | | <TRANSFORMER> | | | |
| T1601 | ! | 1-431-852-11 | TRANSFORMER, CONVERTER (SRT) | | | |
| T1603 | ! | 1-435-512-12 | TRANSFORMER, CONVERTER (PIT) | | | |
| T1605 | ! | 1-433-900-11 | TRANSFORMER, LINE FILTER | | | |
| T1606 | ! | 1-433-900-11 | TRANSFORMER, LINE FILTER | | | |
| | | | <THERMISTOR> | | | |
| TH1601 | | 1-803-586-41 | THERMISTOR | | | |
| | | | <VARISTOR> | | | |
| VD1601 | ! | 1-801-074-41 | VARISTOR ERZV10D271 | | | |

**********

* A-1401-405-A H1 BOARD, COMPLETE
**********

| | | | | | | |
|---|---|---|---|---|---|---|
| | | | <CAPACITOR> | | | |
| C4305 | | 1-162-968-11 | CERAMIC CHIP | 0.0047μF | 10% | 50V |
| C4307 | | 1-162-968-11 | CERAMIC CHIP | 0.0047μF | 10% | 50V |
| C4309 | | 1-162-927-11 | CERAMIC CHIP | 100pF | 5% | 50V |
| C4310 | | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% | 25V |
| C4311 | | 1-126-959-11 | ELECT | 0.47μF | 20% | 50V |
| C4312 | | 1-126-964-11 | ELECT | 10μF | 20% | 50V |
| C4313 | | 1-126-964-11 | ELECT | 10μF | 20% | 50V |
| C4314 | | 1-126-959-11 | ELECT | 0.47μF | 20% | 50V |
| | | | <CONNECTOR> | | | |
| CN4303 | | 1-564-593-11 | PLUG, CONNECTOR 14P | | | |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| | | <DIODE> | | | |
| D4301 | 8-719-016-73 | DIODE STZ6.8TT146 | | | |
| D4302 | 8-719-016-73 | DIODE STZ6.8TT146 | | | |
| D4303 | 8-719-016-73 | DIODE STZ6.8TT146 | | | |
| D4304 | 8-719-016-73 | DIODE STZ6.8TT146 | | | |
| D4305 | 8-719-016-73 | DIODE STZ6.8TT146 | | | |
| D4306 | 8-719-016-73 | DIODE STZ6.8TT146 | | | |
| | | <JACK> | | | |
| J4301 | 1-750-515-11 | TERMINAL BLOCK, S 3P (VIDEO 2 IN) | | | |
| | | <RESISTOR> | | | |
| R4306 | 1-218-285-11 | METAL CHIP | 75 | 5% | 1/10W |
| R4307 | 1-216-853-11 | METAL CHIP | 470K | 5% | 1/10W |
| R4308 | 1-216-853-11 | METAL CHIP | 470K | 5% | 1/10W |
| R4310 | 1-218-285-11 | METAL CHIP | 75 | 5% | 1/10W |
| R4312 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R4313 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R4314 | 1-218-285-11 | METAL CHIP | 75 | 5% | 1/10W |
| R4315 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |

**********

* A-1401-407-A H2 BOARD, COMPLETE
**********

| | | | | | |
|---|---|---|---|---|---|
| | | <CONNECTOR> | | | |
| CN4401 * | 1-564-518-11 | PLUG, CONNECTOR 3P | | | |
| | | <RESISTOR> | | | |
| R4401 | 1-218-684-11 | METAL CHIP | 470 | 0.5% | 1/10W |
| R4402 | 1-218-688-11 | METAL CHIP | 680 | 0.5% | 1/10W |
| R4403 | 1-218-692-11 | METAL CHIP | 1K | 0.5% | 1/10W |
| R4404 | 1-218-700-11 | METAL CHIP | 2.2K | 0.5% | 1/10W |
| R4406 | 1-218-684-11 | METAL CHIP | 470 | 0.5% | 1/10W |
| R4407 | 1-218-688-11 | METAL CHIP | 680 | 0.5% | 1/10W |
| R4408 | 1-218-692-11 | METAL CHIP | 1K | 0.5% | 1/10W |
| R4409 | 1-218-700-11 | METAL CHIP | 2.2K | 0.5% | 1/10W |
| R4410 | 1-218-708-11 | METAL CHIP | 4.7K | 0.5% | 1/10W |
| R4411 | 1-216-789-11 | METAL CHIP | 2.2 | 5% | 1/10W |
| | | <SWITCH> | | | |
| S4401 | 1-692-431-21 | SWITCH, TACTILE (VOLUME -) | | | |
| S4402 | 1-692-431-21 | SWITCH, TACTILE (VOLUME +) | | | |
| S4403 | 1-692-431-21 | SWITCH, TACTILE (CHANNEL -) | | | |
| S4404 | 1-692-431-21 | SWITCH, TACTILE (CHANNEL +) | | | |
| S4405 | 1-692-431-21 | SWITCH, TACTILE (TV/VIDEO) | | | |
| S4406 | 1-692-431-21 | SWITCH, TACTILE (SELECT) | | | |
| S4407 | 1-692-431-21 | SWITCH, TACTILE (RIGHT) | | | |
| S4408 | 1-692-431-21 | SWITCH, TACTILE (DOWN) | | | |
| S4409 | 1-692-431-21 | SWITCH, TACTILE (UP) | | | |
| S4410 | 1-692-431-21 | SWITCH, TACTILE (LEFT) | | | |
| S4411 | 1-692-431-21 | SWITCH, TACTILE (MENU) | | | |

**********

* A-1401-408-A H3 BOARD, COMPLETE
**********

| | | | | | |
|---|---|---|---|---|---|
| | | <CAPACITOR> | | | |
| C4501 | 1-162-974-11 | CERAMIC CHIP | 0.01µF | | 50V |
| C4502 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C4503 | 1-162-974-11 | CERAMIC CHIP | 0.01µF | | 50V |
| C4504 | 1-126-964-11 | ELECT | 10µF | 20% | 50V |
| C4505 | 1-162-974-11 | CERAMIC CHIP | 0.01µF | | 50V |
| | | <CONNECTOR> | | | |
| CN4502 * | 1-564-524-11 | PLUG, CONNECTOR 9P | | | |
| CN4503 * | 1-564-519-11 | PLUG, CONNECTOR 4P | | | |
| CN4504 | 1-695-915-11 | TAB (CONTACT) | | | |
| | | <DIODE> | | | |
| D4503 | 8-719-053-43 | DIODE SLR-325VCT31 (TIMER) | | | |
| D4505 | 8-719-053-43 | DIODE SLR-325VCT31 (STANDBY/STEREO) | | | |
| D4510 | 8-719-053-43 | DIODE SLR-325VCT31 (LAMP) | | | |
| | | <IC> | | | |
| IC4501 | 8-742-129-00 | HYB IC SBX1971-51P | | | |
| | | <TRANSISTOR> | | | |
| Q4503 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | | | |
| Q4508 | 1-801-806-11 | TRANSISTOR DTC144EKA | | | |
| Q4509 | 1-801-806-11 | TRANSISTOR DTC144EKA | | | |
| | | <RESISTOR> | | | |
| R4502 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R4504 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R4506 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R4507 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |
| R4509 | 1-216-819-11 | METAL CHIP | 680 | 5% | 1/10W |
| R4512 | 1-216-819-11 | METAL CHIP | 680 | 5% | 1/10W |
| R4513 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R4520 | 1-216-864-11 | SHORT CHIP | 0 | | |
| | | <SWITCH> | | | |
| S4501 | 1-572-198-11 | SWITCH, KEYBOARD (POWER) | | | |

**********

M

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| * | A-1300-699-A | M BOARD, COMPLETE | | | |
| | | ********** | | | |
| * | 4-042-408-01 | PIN, COATING LEAD | | | |
| | | <CAPACITOR> | | | |
| C9001 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% 25V | |
| C9002 | 1-126-964-11 | ELECT | 10μF | 20% 50V | |
| C9004 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% 16V | |
| C9007 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% 25V | |
| C9008 | 1-126-933-11 | ELECT | 100μF | 20% 16V | |
| C9009 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% 16V | |
| C9010 | 1-126-933-11 | ELECT | 100μF | 20% 16V | |
| C9011 | 1-162-919-11 | CERAMIC CHIP | 22pF | 5% 50V | |
| C9012 | 1-162-919-11 | CERAMIC CHIP | 22pF | 5% 50V | |
| C9013 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% 16V | |
| C9014 | 1-162-915-11 | CERAMIC CHIP | 10pF | 0.50pF 50V | |
| C9015 | 1-162-915-11 | CERAMIC CHIP | 10pF | 0.50pF 50V | |
| C9017 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% 25V | |
| C9018 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% 16V | |
| C9019 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% 25V | |
| C9020 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% 25V | |
| C9021 | 1-126-964-11 | ELECT | 10μF | 20% 50V | |
| C9022 | 1-128-499-11 | ELECT | 220μF | 20% 16V | |
| C9023 | 1-162-915-11 | CERAMIC CHIP | 10pF | 0.50pF 50V | |
| C9024 | 1-162-915-11 | CERAMIC CHIP | 10pF | 0.50pF 50V | |
| C9025 | 1-115-467-11 | CERAMIC CHIP | 0.22μF | 10% 10V | |
| C9035 | 1-128-499-11 | ELECT | 220μF | 20% 16V | |
| C9037 | 1-126-964-11 | ELECT | 10μF | 20% 50V | |
| C9038 | 1-126-947-11 | ELECT | 47μF | 20% 16V | |
| C9039 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% 16V | |
| C9040 | 1-126-947-11 | ELECT | 47μF | 20% 16V | |
| C9041 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% 16V | |
| C9042 | 1-128-499-11 | ELECT | 220μF | 20% 16V | |
| C9043 | 1-128-499-11 | ELECT | 220μF | 20% 16V | |
| C9044 | 1-115-156-11 | CERAMIC CHIP | 1μF | 10V | |
| C9045 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% 25V | |
| C9047 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% 25V | |
| C9048 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% 25V | |
| C9049 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% 25V | |
| C9050 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% 25V | |
| C9051 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% 25V | |
| C9052 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% 25V | |
| C9053 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% 25V | |
| C9054 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% 25V | |
| C9055 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% 25V | |
| C9503 | 1-162-964-11 | CERAMIC CHIP | 0.001μF | 10% 50V | |
| C9504 | 1-126-964-11 | ELECT | 10μF | 20% 50V | |
| C9505 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% 16V | |
| C9506 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% 25V | |
| C9519 | 1-164-315-11 | CERAMIC CHIP | 470pF | 5% 50V | |
| C9520 | 1-164-315-11 | CERAMIC CHIP | 470pF | 5% 50V | |
| C9521 | 1-164-315-11 | CERAMIC CHIP | 470pF | 5% 50V | |
| C9523 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% 16V | |
| C9524 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% 25V | |
| C9525 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% 25V | |
| C9527 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% 25V | |
| C9528 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% 25V | |
| C9530 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% 25V | |
| C9531 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% 25V | |
| C9532 | 1-162-927-11 | CERAMIC CHIP | 100pF | 5% 50V | |
| C9533 | 1-162-927-11 | CERAMIC CHIP | 100pF | 5% 50V | |
| C9534 | 1-126-964-11 | ELECT | 10μF | 20% 50V | |
| C9535 | 1-162-917-11 | CERAMIC CHIP | 15pF | 5% 50V | |
| C9536 | 1-162-917-11 | CERAMIC CHIP | 15pF | 5% 50V | |
| C9540 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% 16V | |
| C9541 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% 25V | |
| C9542 | 1-162-970-11 | CERAMIC CHIP | 0.01μF | 10% 25V | |
| C9546 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% 16V | |
| C9547 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% 16V | |
| C9548 | 1-162-915-11 | CERAMIC CHIP | 10pF | 0.50pF 50V | |
| C9549 | 1-162-915-11 | CERAMIC CHIP | 10pF | 0.50pF 50V | |
| | | <CONNECTOR> | | | |
| CN9001 | 1-766-382-21 | PIN, CONNECTOR (1.5mm)(SMD)10P | | | |
| CN9002 | 1-815-870-11 | CONNECTOR, BOARD TO BOARD 50P | | | |
| CN9501 | 1-815-870-11 | CONNECTOR, BOARD TO BOARD 50P | | | |
| | | <DIODE> | | | |
| D9001 | 8-719-941-86 | DIODE DAN202U | | | |
| D9002 | 8-719-941-09 | DIODE DAP202U | | | |
| D9004 | 8-719-941-86 | DIODE DAN202U | | | |
| D9005 | 8-719-941-09 | DIODE DAP202U | | | |
| D9008 | 8-719-941-86 | DIODE DAN202U | | | |
| D9012 | 8-719-404-50 | DIODE MA111-TX | | | |
| D9013 | 8-719-404-50 | DIODE MA111-TX | | | |
| D9014 | 8-719-404-50 | DIODE MA111-TX | | | |
| D9015 | 8-719-404-50 | DIODE MA111-TX | | | |
| D9016 | 8-719-404-50 | DIODE MA111-TX | | | |
| D9017 | 8-719-941-86 | DIODE DAN202U | | | |
| D9018 | 8-719-941-86 | DIODE DAN202U | | | |
| D9019 | 8-719-404-50 | DIODE MA111-TX | | | |
| D9020 | 8-719-404-50 | DIODE MA111-TX | | | |
| D9021 | 8-719-404-50 | DIODE MA111-TX | | | |
| D9022 | 8-719-404-50 | DIODE MA111-TX | | | |
| D9023 | 8-719-404-50 | DIODE MA111-TX | | | |
| D9024 | 8-719-404-50 | DIODE MA111-TX | | | |
| D9025 | 8-719-404-50 | DIODE MA111-TX | | | |
| D9026 | 8-719-404-50 | DIODE MA111-TX | | | |
| D9027 | 8-719-404-50 | DIODE MA111-TX | | | |
| D9028 | 8-719-404-50 | DIODE MA111-TX | | | |
| D9029 | 8-719-404-50 | DIODE MA111-TX | | | |
| D9030 | 8-719-404-50 | DIODE MA111-TX | | | |
| D9031 | 8-719-404-50 | DIODE MA111-TX | | | |
| D9032 | 8-719-404-50 | DIODE MA111-TX | | | |
| D9033 | 8-719-404-50 | DIODE MA111-TX | | | |
| D9501 | 8-719-404-50 | DIODE MA111-TX | | | |
| D9502 | 8-719-025-31 | DIODE 02CZ5.6-TE85L | | | |
| D9503 | 8-719-404-50 | DIODE MA111-TX | | | |

| REF. NO. | PART NO. | DESCRIPTION | REMARK |
|---|---|---|---|
| | | <FILTER> | |
| FL9001 | 1-233-736-21 | FILTER, EMI | |
| FL9002 | 1-233-736-21 | FILTER, EMI | |
| | | <IC> | |
| IC9001 | 6-801-375-01 | IC PST9129NL | |
| IC9002 | 8-759-682-41 | IC M24C32-WMN6T(A) | |
| IC9004 | 6-802-464-01 | IC M306VSMG-501FP | |
| IC9005 | 8-759-349-11 | IC PST9145NL | |
| IC9007 | 8-759-547-54 | IC TC7SET00FU(TE85R) | |
| IC9008 | 8-759-570-08 | IC TC7SET32FU(TE85R) | |
| IC9009 | 8-759-570-08 | IC TC7SET32FU(TE85R) | |
| IC9010 | 8-759-570-08 | IC TC7SET32FU(TE85R) | |
| IC9011 | 8-759-196-96 | IC TC7SH08FU-TE85R | |
| IC9012 | 8-759-485-79 | IC TC7SET08FU(TE85R) | |
| IC9013 | 8-759-547-54 | IC TC7SET00FU(TE85R) | |
| IC9014 | 8-759-547-54 | IC TC7SET00FU(TE85R) | |
| IC9015 | 8-759-641-26 | IC NJM2391DL1-33(TE1) | |
| IC9016 | 8-759-485-79 | IC TC7SET08FU(TE85R) | |
| IC9017 | 8-759-485-79 | IC TC7SET08FU(TE85R) | |
| IC9502 | 6-801-725-01 | IC MB94918RpF-G-148-BND | |
| IC9503 | 8-759-485-79 | IC TC7SET08FU(TE85R) | |
| IC9504 | 6-700-149-01 | IC M24C04-MN6T(A) | |
| IC9505 | 8-759-349-11 | IC PST9145NL | |
| IC9506 | 8-759-009-06 | IC MC14052BFEL | |
| IC9507 | 8-759-675-64 | IC M24C08-MN6T(A) | |
| IC9508 | 8-759-485-79 | IC TC7SET08FU(TE85R) | |
| IC9509 | 8-759-271-84 | IC TC7SH02FU | |
| IC9510 | 8-759-196-97 | IC TC7SH32FU-TE85R | |
| IC9514 | 8-759-485-79 | IC TC7SET08FU(TE85R) | |
| IC9515 | 8-759-485-79 | IC TC7SET08FU(TE85R) | |
| | | <COIL> | |
| L9001 | 1-412-943-11 | INDUCTOR 2.2μH | |
| L9002 | 1-412-058-11 | INDUCTOR 10μH | |
| L9501 | 1-412-003-21 | INDUCTOR 5.6μH | |
| | | <TRANSISTOR> | |
| Q9003 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q9004 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q9005 | 8-729-027-23 | TRANSISTOR DTA114EKA-T146 | |
| Q9006 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q9007 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q9008 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q9009 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q9010 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q9011 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q9012 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q9013 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q9014 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q9015 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q9016 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q9017 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q9018 | 1-801-806-11 | TRANSISTOR DTC144EKA | |
| Q9019 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q9020 | 8-729-027-23 | TRANSISTOR DTA114EKA-T146 | |
| Q9021 | 1-801-806-11 | TRANSISTOR DTC144EKA | |
| Q9022 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q9023 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q9025 | 8-729-027-23 | TRANSISTOR DTA114EKA-T146 | |
| Q9026 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q9027 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q9028 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q9029 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q9502 | 8-729-900-53 | TRANSISTOR DTC114EK | |
| Q9505 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q9506 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q9507 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q9508 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q9509 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q9510 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q9511 | 8-729-027-23 | TRANSISTOR DTA114EKA-T146 | |
| Q9516 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q9517 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q9518 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q9519 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q9520 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q9521 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q9522 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q9523 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q9524 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q9525 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q9526 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q9527 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| | | <RESISTOR> | |
| R9002 | 1-216-809-11 | METAL CHIP 100 5% 1/10W | |
| R9004 | 1-216-809-11 | METAL CHIP 100 5% 1/10W | |
| R9005 | 1-216-809-11 | METAL CHIP 100 5% 1/10W | |
| R9006 | 1-216-809-11 | METAL CHIP 100 5% 1/10W | |
| R9007 | 1-216-841-11 | METAL CHIP 47K 5% 1/10W | |
| R9008 | 1-216-809-11 | METAL CHIP 100 5% 1/10W | |
| R9009 | 1-216-825-11 | METAL CHIP 2.2K 5% 1/10W | |
| R9011 | 1-218-708-11 | METAL CHIP 4.7K 0.5% 1/10W | |
| R9012 | 1-216-821-11 | METAL CHIP 1K 5% 1/10W | |
| R9013 | 1-216-809-11 | METAL CHIP 100 5% 1/10W | |
| R9014 | 1-216-801-11 | METAL CHIP 22 5% 1/10W | |
| R9015 | 1-216-801-11 | METAL CHIP 22 5% 1/10W | |
| R9016 | 1-216-833-11 | METAL CHIP 10K 5% 1/10W | |
| R9017 | 1-216-809-11 | METAL CHIP 100 5% 1/10W | |
| R9018 | 1-216-845-11 | METAL CHIP 100K 5% 1/10W | |
| R9019 | 1-216-841-11 | METAL CHIP 47K 5% 1/10W | |
| R9020 | 1-216-833-11 | METAL CHIP 10K 5% 1/10W | |
| R9021 | 1-216-864-11 | SHORT CHIP 0 | |
| R9022 | 1-216-841-11 | METAL CHIP 47K 5% 1/10W | |
| R9023 | 1-216-809-11 | METAL CHIP 100 5% 1/10W | |
| R9024 | 1-216-809-11 | METAL CHIP 100 5% 1/10W | |
| R9025 | 1-216-827-11 | METAL CHIP 3.3K 5% 1/10W | |
| R9026 | 1-216-827-11 | METAL CHIP 3.3K 5% 1/10W | |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| R9027 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R9028 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9029 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R9030 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R9031 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R9032 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R9033 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9034 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9036 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R9037 | 1-216-823-11 | METAL CHIP | 1.5K | 5% | 1/10W |
| R9038 | 1-216-823-11 | METAL CHIP | 1.5K | 5% | 1/10W |
| R9039 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9041 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9042 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9043 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R9044 | 1-218-867-11 | METAL CHIP | 6.8K | 5% | 1/10W |
| R9045 | 1-216-835-11 | METAL CHIP | 15K | 5% | 1/10W |
| R9046 | 1-216-815-11 | METAL CHIP | 330 | 5% | 1/10W |
| R9047 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9048 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9049 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9050 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9051 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9052 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9053 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R9054 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9055 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R9056 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R9057 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9058 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R9059 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R9061 | 1-216-842-11 | METAL CHIP | 56K | 5% | 1/10W |
| R9062 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9063 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R9064 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9065 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9066 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R9067 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R9068 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9069 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9070 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9071 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9072 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9073 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9074 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9075 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9076 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9077 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9078 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9079 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R9080 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9081 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9082 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9083 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9084 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9085 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R9086 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9087 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9088 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R9089 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R9090 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9091 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9092 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9093 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9094 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9096 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9097 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R9098 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9099 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9100 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9101 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R9102 | 1-216-849-11 | METAL CHIP | 220K | 5% | 1/10W |
| R9103 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9105 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9107 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R9108 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R9109 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R9110 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R9112 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R9113 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9114 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R9115 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9116 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R9117 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9118 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R9119 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9120 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R9121 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R9122 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9123 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9124 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9125 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R9126 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R9129 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R9130 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9131 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R9132 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9133 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R9134 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R9135 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R9136 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9137 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9138 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R9139 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |
| R9140 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R9141 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9142 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9143 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R9145 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9146 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R9147 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R9148 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R9149 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R9150 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| R9151 | 1-216-836-11 | METAL CHIP | 18K | 5% | 1/10W |
| R9152 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R9153 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9154 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R9155 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9158 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9160 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R9161 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9162 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R9164 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9165 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R9168 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9169 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R9171 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9172 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R9173 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R9174 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9175 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9176 | 1-216-836-11 | METAL CHIP | 18K | 5% | 1/10W |
| R9177 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9178 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R9179 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R9506 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9507 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R9508 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9510 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9511 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R9512 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R9513 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R9514 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R9515 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9516 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9517 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9518 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9519 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9520 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R9521 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R9522 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |
| R9523 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9525 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9526 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9527 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9528 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9529 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9531 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9532 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R9533 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9534 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9535 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9536 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9537 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R9538 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9539 | 1-216-813-11 | METAL CHIP | 220 | 5% | 1/10W |
| R9540 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9541 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R9542 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R9543 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9546 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R9547 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R9548 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9549 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R9550 | 1-216-824-11 | METAL CHIP | 1.8K | 5% | 1/10W |
| R9551 | 1-216-824-11 | METAL CHIP | 1.8K | 5% | 1/10W |
| R9552 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R9553 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R9554 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R9555 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R9556 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R9557 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9558 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9559 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R9560 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R9561 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9563 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R9564 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9565 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R9567 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R9568 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R9569 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R9571 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R9572 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9573 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9574 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R9575 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R9576 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R9577 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9578 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9579 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9580 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9581 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9582 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R9583 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9584 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9585 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R9586 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9587 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R9588 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R9589 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R9591 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9592 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R9593 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R9594 | 1-216-813-11 | METAL CHIP | 220 | 5% | 1/10W |
| R9598 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9600 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9601 | 1-216-815-11 | METAL CHIP | 330 | 5% | 1/10W |
| R9602 | 1-216-815-11 | METAL CHIP | 330 | 5% | 1/10W |
| R9603 | 1-216-815-11 | METAL CHIP | 330 | 5% | 1/10W |
| R9613 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R9617 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9623 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9624 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9625 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R9626 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| R9627 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R9628 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R9629 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R9630 | 1-216-813-11 | METAL CHIP | 220 | 5% | 1/10W |
| R9631 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9632 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R9633 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R9634 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9635 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R9636 | 1-216-813-11 | METAL CHIP | 220 | 5% | 1/10W |
| R9637 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9638 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R9639 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R9640 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9641 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R9642 | 1-216-813-11 | METAL CHIP | 220 | 5% | 1/10W |
| R9643 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9644 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R9645 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R9646 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9647 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R9648 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R9649 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R9650 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R9651 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R9652 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R9653 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| | | <CRYSTAL> | | | |
| X9002 | 1-579-358-11 | VIBLATOR, CRYSTAL 10MHz | | | |
| X9501 | 1-760-014-11 | VIBRATOR, CERAMIC 20MHz | | | |

**********

| | | | |
|---|---|---|---|
| * | A-1401-406-A | T BOARD, COMPLETE | |
| | | ********** | |
| | | <CONNECTOR> | |
| CN8001 | * 1-564-506-11 | PLUG, CONNECTOR 3P | |
| | | <SWITCH> | |
| S8001 | 1-570-245-11 | SWITCH, MICRO (LAMP COVER) | |

**********

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| * | A-1300-700-A | U BOARD, COMPLETE | | | |
| | | ********** | | | |
| | | <CAPACITOR> | | | |
| C2001 | 1-109-982-11 | CERAMIC CHIP | 1μF | 10% | 10V |
| C2002 | 1-109-982-11 | CERAMIC CHIP | 1μF | 10% | 10V |
| C2003 | 1-126-960-11 | ELECT | 1μF | 20% | 50V |
| C2004 | 1-126-960-11 | ELECT | 1μF | 20% | 50V |
| C2005 | 1-109-982-11 | CERAMIC CHIP | 1μF | 10% | 10V |
| C2006 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2007 | 1-109-982-11 | CERAMIC CHIP | 1μF | 10% | 10V |
| C2008 | 1-109-982-11 | CERAMIC CHIP | 1μF | 10% | 10V |
| C2009 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2010 | 1-126-960-11 | ELECT | 1μF | 20% | 50V |
| C2011 | 1-126-960-11 | ELECT | 1μF | 20% | 50V |
| C2012 | 1-126-960-11 | ELECT | 1μF | 20% | 50V |
| C2013 | 1-126-960-11 | ELECT | 1μF | 20% | 50V |
| C2014 | 1-162-917-11 | CERAMIC CHIP | 15pF | 5% | 50V |
| C2015 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |
| C2016 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C2017 | 1-162-964-11 | CERAMIC CHIP | 0.001μF | 10% | 50V |
| C2018 | 1-164-227-11 | CERAMIC CHIP | 0.022μF | 10% | 25V |
| C2019 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C2020 | 1-126-964-11 | ELECT | 10μF | 20% | 50V |
| C2021 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C2022 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C2023 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2024 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C2025 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C2026 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |
| C2027 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |
| C2028 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C2029 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2030 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2031 | 1-162-917-11 | CERAMIC CHIP | 15pF | 5% | 50V |
| C2032 | 1-162-917-11 | CERAMIC CHIP | 15pF | 5% | 50V |
| C2033 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |
| C2034 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C2035 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C2036 | 1-162-913-11 | CERAMIC CHIP | 8pF | 0.50pF | 50V |
| C2037 | 1-125-837-91 | CERAMIC CHIP | 1μF | 10% | 6.3V |
| C2038 | 1-125-837-91 | CERAMIC CHIP | 1μF | 10% | 6.3V |
| C2039 | 1-162-913-11 | CERAMIC CHIP | 8pF | 0.50pF | 50V |
| C2040 | 1-109-982-11 | CERAMIC CHIP | 1μF | 10% | 10V |
| C2041 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C2042 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2043 | 1-109-982-11 | CERAMIC CHIP | 1μF | 10% | 10V |
| C2044 | 1-125-837-91 | CERAMIC CHIP | 1μF | 10% | 6.3V |
| C2045 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |
| C2046 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2047 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2048 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2049 | 1-126-960-11 | ELECT | 1μF | 20% | 50V |
| C2050 | 1-126-960-11 | ELECT | 1μF | 20% | 50V |
| C2051 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| C2052 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2053 | 1-126-941-11 | ELECT | 470μF | 20% | 25V |
| C2054 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2055 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |
| C2056 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C2057 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |
| C2060 | 1-125-837-91 | CERAMIC CHIP | 1μF | 10% | 6.3V |
| C2061 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |
| C2062 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C2063 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |
| C2064 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |
| C2065 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |
| C2066 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |
| C2067 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |
| C2068 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |
| C2069 | 1-126-960-11 | ELECT | 1μF | 20% | 50V |
| C2070 | 1-126-960-11 | ELECT | 1μF | 20% | 50V |
| C2071 | 1-126-960-11 | ELECT | 1μF | 20% | 50V |
| C2072 | 1-126-960-11 | ELECT | 1μF | 20% | 50V |
| C2073 | 1-126-960-11 | ELECT | 1μF | 20% | 50V |
| C2074 | 1-126-960-11 | ELECT | 1μF | 20% | 50V |
| C2075 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2076 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |
| C2077 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2078 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |
| C2500 | 1-162-966-11 | CERAMIC CHIP | 0.0022μF | 10% | 50V |
| C2501 | 1-162-966-11 | CERAMIC CHIP | 0.0022μF | 10% | 50V |
| C2502 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2503 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2506 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |
| C2507 | 1-162-960-11 | CERAMIC CHIP | 220pF | 10% | 50V |
| C2510 | 1-162-966-11 | CERAMIC CHIP | 0.0022μF | 10% | 50V |
| C2511 | 1-135-834-91 | CERAMIC CHIP | 2.2E+06pF | 6.3V | |
| C2512 | 1-162-966-11 | CERAMIC CHIP | 0.0022μF | 10% | 50V |
| C2513 | 1-162-960-11 | CERAMIC CHIP | 220pF | 10% | 50V |
| C2514 | 1-162-966-11 | CERAMIC CHIP | 0.0022μF | 10% | 50V |
| C2515 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2516 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2517 | 1-126-786-11 | ELECT | 47μF | 20% | 16V |
| C2519 | 1-162-960-11 | CERAMIC CHIP | 220pF | 10% | 50V |
| C2520 | 1-135-834-91 | CERAMIC CHIP | 2.2E+06pF | 6.3V | |
| C2522 | 1-126-786-11 | ELECT | 47μF | 20% | 16V |
| C2523 | 1-162-962-11 | CERAMIC CHIP | 470pF | 10% | 50V |
| C2525 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |
| C2527 | 1-135-834-91 | CERAMIC CHIP | 2.2E+06pF | 6.3V | |
| C2528 | 1-135-834-91 | CERAMIC CHIP | 2.2E+06pF | 6.3V | |
| C2530 | 1-126-786-11 | ELECT | 47μF | 20% | 16V |
| C2531 | 1-162-960-11 | CERAMIC CHIP | 220pF | 10% | 50V |
| C2532 | 1-162-962-11 | CERAMIC CHIP | 470pF | 10% | 50V |
| C2533 | 1-135-834-91 | CERAMIC CHIP | 2.2E+06pF | 6.3V | |
| C2534 | 1-135-834-91 | CERAMIC CHIP | 2.2E+06pF | 6.3V | |
| C2536 | 1-126-786-11 | ELECT | 47μF | 20% | 16V |
| C2537 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2538 | 1-162-915-11 | CERAMIC CHIP | 10pF | 0.50pF | 50V |
| C2539 | 1-162-915-11 | CERAMIC CHIP | 10pF | 0.50pF | 50V |
| C2540 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2541 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2542 | 1-126-794-11 | ELECT | 4.7μF | 20% | 25V |
| C2543 | 1-162-966-11 | CERAMIC CHIP | 0.0022μF | 10% | 50V |
| C2544 | 1-162-966-11 | CERAMIC CHIP | 0.0022μF | 10% | 50V |
| C2545 | 1-126-382-11 | ELECT | 100μF | 20% | 16V |
| C2546 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2547 | 1-126-786-11 | ELECT | 47μF | 20% | 16V |
| C2549 | 1-126-794-11 | ELECT | 4.7μF | 20% | 25V |
| C2550 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C2551 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2552 | 1-126-786-11 | ELECT | 47μF | 20% | 16V |
| C2554 | 1-126-786-11 | ELECT | 47μF | 20% | 16V |
| C2556 | 1-126-794-11 | ELECT | 4.7μF | 20% | 25V |
| C2557 | 1-126-794-11 | ELECT | 4.7μF | 20% | 25V |
| C2559 | 1-126-382-11 | ELECT | 100μF | 20% | 16V |
| C2561 | 1-126-786-11 | ELECT | 47μF | 20% | 16V |
| C2563 | 1-126-933-11 | ELECT | 100μF | 20% | 16V |
| C2564 | 1-126-961-11 | ELECT | 2.2μF | 20% | 50V |
| C2565 | 1-126-961-11 | ELECT | 2.2μF | 20% | 50V |
| C2566 | 1-125-837-91 | CERAMIC CHIP | 1μF | 10% | 6.3V |
| C2567 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2570 | 1-162-966-11 | CERAMIC CHIP | 0.0022μF | 10% | 50V |
| C2571 | 1-126-961-11 | ELECT | 2.2μF | 20% | 50V |
| C2573 | 1-164-156-11 | CERAMIC CHIP | 0.1μF | | 25V |
| C2574 | 1-162-966-11 | CERAMIC CHIP | 0.0022μF | 10% | 50V |
| C2575 | 1-126-964-11 | ELECT | 10μF | 20% | 50V |
| C2576 | 1-126-960-11 | ELECT | 1μF | 20% | 50V |
| C2577 | 1-126-960-11 | ELECT | 1μF | 20% | 50V |
| C2578 | 1-126-964-11 | ELECT | 10μF | 20% | 50V |
| C2582 | 1-107-826-11 | CERAMIC CHIP | 0.1μF | 10% | 16V |
| C2587 | 1-126-786-11 | ELECT | 47μF | 20% | 16V |

<CONNECTOR>

| | | | |
|---|---|---|---|
| CN2001 * | 1-793-923-11 | CONNECTOR, DIN (PLUG) 64P | |
| CN2002 * | 1-564-526-11 | PLUG, CONNECTOR 11P | |

<DIODE>

| | | | |
|---|---|---|---|
| D2001 | 8-719-977-28 | DIODE | UDZSTE-1710B |
| D2002 | 8-719-977-28 | DIODE | UDZSTE-1710B |
| D2003 | 8-719-977-28 | DIODE | UDZSTE-1710B |
| D2004 | 8-719-977-28 | DIODE | UDZSTE-1710B |
| D2005 | 8-719-977-28 | DIODE | UDZSTE-1710B |
| D2006 | 8-719-977-28 | DIODE | UDZSTE-1710B |
| D2007 | 8-719-977-28 | DIODE | UDZSTE-1710B |
| D2008 | 8-719-977-28 | DIODE | UDZSTE-1710B |
| D2009 | 8-719-977-28 | DIODE | UDZSTE-1710B |
| D2010 | 8-719-977-28 | DIODE | UDZSTE-1710B |
| D2011 | 8-719-977-28 | DIODE | UDZSTE-1710B |
| D2012 | 8-719-977-28 | DIODE | UDZSTE-1710B |
| D2013 | 8-719-977-28 | DIODE | UDZSTE-1710B |
| D2014 | 8-719-977-28 | DIODE | UDZSTE-1710B |
| D2015 | 8-719-977-28 | DIODE | UDZSTE-1710B |
| D2016 | 8-719-977-28 | DIODE | UDZSTE-1710B |
| D2017 | 8-719-977-28 | DIODE | UDZSTE-1710B |
| D2018 | 8-719-977-28 | DIODE | UDZSTE-1710B |
| D2019 | 8-719-977-28 | DIODE | UDZSTE-1710B |

| REF. NO. | PART NO. | DESCRIPTION | REMARK |
|---|---|---|---|
| D2020 | 8-719-977-28 | DIODE UDZSTE-1710B | |
| D2027 | 8-719-977-28 | DIODE UDZSTE-1710B | |
| D2028 | 8-719-977-28 | DIODE UDZSTE-1710B | |
| D2029 | 8-719-977-28 | DIODE UDZSTE-1710B | |
| D2030 | 8-719-977-28 | DIODE UDZSTE-1710B | |
| D2031 | 8-719-977-28 | DIODE UDZSTE-1710B | |
| D2032 | 8-719-977-28 | DIODE UDZSTE-1710B | |
| D2033 | 8-719-977-28 | DIODE UDZSTE-1710B | |
| D2034 | 8-719-977-28 | DIODE UDZSTE-1710B | |
| D2035 | 8-719-977-28 | DIODE UDZSTE-1710B | |
| D2036 | 8-719-977-28 | DIODE UDZSTE-1710B | |
| D2500 | 8-719-404-50 | DIODE MA111-TX | |
| D2500 | 8-719-988-61 | DIODE 1SS355TE-17 | |
| | | <FERRITE BEAD> | |
| FB2001 | 1-414-229-11 | FERRITE 0μH | |
| FB2002 | 1-414-229-11 | FERRITE 0μH | |
| FB2500 | 1-414-229-11 | FERRITE 0μH | |
| FB2502 | 1-414-229-11 | FERRITE 0μH | |
| FB2504 | 1-414-229-11 | FERRITE 0μH | |
| FB2508 | 1-414-229-11 | FERRITE 0μH | |
| FB2511 | 1-414-229-11 | FERRITE 0μH | |
| FB2512 | 1-414-229-11 | FERRITE 0μH | |
| FB2514 | 1-414-229-11 | FERRITE 0μH | |
| FB2516 | 1-414-229-11 | FERRITE 0μH | |
| FB2517 | 1-414-229-11 | FERRITE 0μH | |
| FB2518 | 1-414-229-11 | FERRITE 0μH | |
| FB2519 | 1-414-229-11 | FERRITE 0μH | |
| | | <FILTER> | |
| FL2001 | 1-239-848-21 | FILTER, LOW PASS | |
| FL2002 | 1-239-848-21 | FILTER, LOW PASS | |
| FL2003 | 1-239-848-21 | FILTER, LOW PASS | |
| | | <IC> | |
| IC2001 | 8-752-394-69 | IC CXD2073Q-T4 | |
| IC2002 | 8-752-080-04 | IC CXA2069Q | |
| IC2003 | 8-759-548-56 | IC M52055FP | |
| IC2500 | 8-759-394-57 | IC PST593C-MMP-4P | |
| IC2502 | 6-801-750-01 | IC TC94A04F-014 | |
| IC2503 | 8-759-331-71 | IC NJM4558E(TE2) | |
| IC2504 | 8-759-331-71 | IC NJM4558E(TE2) | |
| | | <JACK> | |
| J2001 | 1-573-967-12 | BLOCK, (S) TERMINAL (VIDEO IN 1/3) | |
| J2002 | 1-750-517-21 | JACK BLOCK, PIN 3P (VIDEO IN 4) | |
| J2003 | 1-750-517-21 | JACK BLOCK, PIN 3P (MONITOR OUT) | |
| J2004 | 1-750-516-21 | JACK BLOCK, PIN 2P (AUDIO OUT (VAR/FIX)) | |
| J2005 | 1-750-516-21 | JACK BLOCK, PIN 2P (DVI-HDTV IN: AUDIO) | |
| J2006 | 1-764-143-11 | JACK (CONTROL S IN) | |
| J2007 | 1-764-143-11 | JACK (CONTROL S OUT) | |
| J2008 | 1-815-015-11 | JACK BLOCK, PIN (HD/DVD IN 5) | |
| J2009 | 1-815-015-11 | JACK BLOCK, PIN (HD/DVD IN 6) | |

| REF. NO. | PART NO. | DESCRIPTION | REMARK |
|---|---|---|---|
| | | <COIL> | |
| L2001 | 1-469-555-21 | INDUCTOR 10μH | |
| L2002 | 1-469-555-21 | INDUCTOR 10μH | |
| L2003 | 1-469-555-21 | INDUCTOR 10μH | |
| L2004 | 1-469-555-21 | INDUCTOR 10μH | |
| L2005 | 1-469-555-21 | INDUCTOR 10μH | |
| L2006 | 1-469-555-21 | INDUCTOR 10μH | |
| L2007 | 1-469-555-21 | INDUCTOR 10μH | |
| L2008 | 1-469-555-21 | INDUCTOR 10μH | |
| L2009 | 1-469-555-21 | INDUCTOR 10μH | |
| L2502 | 1-412-537-31 | INDUCTOR 100μH | |
| | | <TRANSISTOR> | |
| Q2001 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2002 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2003 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q2004 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2005 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2006 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q2007 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2008 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2009 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2010 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2011 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2012 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q2013 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2014 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q2015 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q2016 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2017 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q2018 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2019 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2020 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q2021 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q2022 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2023 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q2024 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2025 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2500 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2501 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2502 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2503 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2504 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2505 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2506 | 8-729-216-22 | TRANSISTOR 2SA1162-G | |
| Q2507 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| Q2508 | 8-729-422-33 | TRANSISTOR 2SD601A-Q-TX | |
| | | <RESISTOR> | |
| R2002 | 1-218-665-11 | METAL CHIP 75 0.5% 1/10W | |
| R2003 | 1-216-853-11 | METAL CHIP 470K 5% 1/10W | |
| R2004 | 1-216-853-11 | METAL CHIP 470K 5% 1/10W | |
| R2006 | 1-218-665-11 | METAL CHIP 75 0.5% 1/10W | |
| R2007 | 1-218-665-11 | METAL CHIP 75 0.5% 1/10W | |
| R2008 | 1-218-665-11 | METAL CHIP 75 0.5% 1/10W | |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| R2009 | 1-216-853-11 | METAL CHIP | 470K | 5% | 1/10W |
| R2010 | 1-216-853-11 | METAL CHIP | 470K | 5% | 1/10W |
| R2011 | 1-218-665-11 | METAL CHIP | 75 | 0.5% | 1/10W |
| R2012 | 1-218-665-11 | METAL CHIP | 75 | 0.5% | 1/10W |
| R2013 | 1-218-665-11 | METAL CHIP | 75 | 0.5% | 1/10W |
| R2014 | 1-216-853-11 | METAL CHIP | 470K | 5% | 1/10W |
| R2015 | 1-216-853-11 | METAL CHIP | 470K | 5% | 1/10W |
| R2017 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2018 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2019 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2020 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2021 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2022 | 1-218-686-11 | METAL CHIP | 560 | 0.5% | 1/10W |
| R2023 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R2024 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R2025 | 1-218-686-11 | METAL CHIP | 560 | 0.5% | 1/10W |
| R2026 | 1-218-692-11 | METAL CHIP | 1K | 0.5% | 1/10W |
| R2027 | 1-218-708-11 | METAL CHIP | 4.7K | 0.5% | 1/10W |
| R2028 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2029 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2030 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2031 | 1-218-734-11 | METAL CHIP | 56K | 0.5% | 1/10W |
| R2032 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2033 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R2034 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R2035 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |
| R2036 | 1-216-839-11 | METAL CHIP | 33K | 5% | 1/10W |
| R2037 | 1-216-812-11 | METAL CHIP | 180 | 5% | 1/10W |
| R2039 | 1-216-811-11 | METAL CHIP | 150 | 5% | 1/10W |
| R2041 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R2042 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |
| R2043 | 1-216-839-11 | METAL CHIP | 33K | 5% | 1/10W |
| R2044 | 1-218-704-11 | METAL CHIP | 3.3K | 0.5% | 1/10W |
| R2046 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2047 | 1-218-704-11 | METAL CHIP | 3.3K | 0.5% | 1/10W |
| R2048 | 1-218-700-11 | METAL CHIP | 2.2K | 0.5% | 1/10W |
| R2049 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R2050 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R2051 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R2052 | 1-218-686-11 | METAL CHIP | 560 | 0.5% | 1/10W |
| R2053 | 1-218-686-11 | METAL CHIP | 560 | 0.5% | 1/10W |
| R2054 | 1-218-710-11 | METAL CHIP | 5.6K | 0.5% | 1/10W |
| R2055 | 1-218-710-11 | METAL CHIP | 5.6K | 0.5% | 1/10W |
| R2056 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R2057 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R2058 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R2059 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R2060 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2061 | 1-216-824-11 | METAL CHIP | 1.8K | 5% | 1/10W |
| R2062 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R2063 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2064 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2065 | 1-216-824-11 | METAL CHIP | 1.8K | 5% | 1/10W |
| R2066 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R2067 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2068 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2069 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| R2070 | 1-216-830-11 | METAL CHIP | 5.6K | 5% | 1/10W |
| R2071 | 1-216-830-11 | METAL CHIP | 5.6K | 5% | 1/10W |
| R2072 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2073 | 1-216-830-11 | METAL CHIP | 5.6K | 5% | 1/10W |
| R2074 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2075 | 1-216-830-11 | METAL CHIP | 5.6K | 5% | 1/10W |
| R2076 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2077 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2078 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2079 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2080 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2081 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R2082 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R2083 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R2084 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R2085 | 1-216-830-11 | METAL CHIP | 5.6K | 5% | 1/10W |
| R2086 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2087 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2088 | 1-216-830-11 | METAL CHIP | 5.6K | 5% | 1/10W |
| R2089 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R2090 | 1-216-806-11 | METAL CHIP | 56 | 5% | 1/10W |
| R2091 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2092 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2093 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2094 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R2095 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R2096 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2097 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2098 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2099 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2100 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2101 | 1-216-830-11 | METAL CHIP | 5.6K | 5% | 1/10W |
| R2104 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R2105 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2106 | 1-216-842-11 | METAL CHIP | 56K | 5% | 1/10W |
| R2107 | 1-216-857-11 | METAL CHIP | 1M | 5% | 1/10W |
| R2108 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2109 | 1-216-830-11 | METAL CHIP | 5.6K | 5% | 1/10W |
| R2110 | 1-216-853-11 | METAL CHIP | 470K | 5% | 1/10W |
| R2111 | 1-216-853-11 | METAL CHIP | 470K | 5% | 1/10W |
| R2112 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2113 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2114 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2115 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2116 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2117 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R2118 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2119 | 1-216-853-11 | METAL CHIP | 470K | 5% | 1/10W |
| R2120 | 1-218-665-11 | METAL CHIP | 75 | 0.5% | 1/10W |
| R2121 | 1-216-830-11 | METAL CHIP | 5.6K | 5% | 1/10W |
| R2122 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2123 | 1-216-813-11 | METAL CHIP | 220 | 5% | 1/10W |
| R2124 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2125 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R2126 | 1-216-830-11 | METAL CHIP | 5.6K | 5% | 1/10W |
| R2127 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R2128 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| R2129 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R2130 | 1-216-830-11 | METAL CHIP | 5.6K | 5% | 1/10W |
| R2131 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2132 | 1-216-830-11 | METAL CHIP | 5.6K | 5% | 1/10W |
| R2133 | 1-216-830-11 | METAL CHIP | 5.6K | 5% | 1/10W |
| R2134 | 1-216-830-11 | METAL CHIP | 5.6K | 5% | 1/10W |
| R2135 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2136 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2137 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2138 | 1-216-807-11 | METAL CHIP | 68 | 5% | 1/10W |
| R2139 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2140 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2141 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2142 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2143 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2154 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2155 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2156 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R2157 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R2158 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R2159 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R2160 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R2161 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R2162 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R2163 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R2164 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R2165 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R2166 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R2167 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R2168 | 1-216-853-11 | METAL CHIP | 470K | 5% | 1/10W |
| R2169 | 1-216-853-11 | METAL CHIP | 470K | 5% | 1/10W |
| R2170 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R2171 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R2172 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R2173 | 1-216-853-11 | METAL CHIP | 470K | 5% | 1/10W |
| R2174 | 1-216-853-11 | METAL CHIP | 470K | 5% | 1/10W |
| R2175 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R2176 | 1-216-813-11 | METAL CHIP | 220 | 5% | 1/10W |
| R2177 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R2178 | 1-216-853-11 | METAL CHIP | 470K | 5% | 1/10W |
| R2179 | 1-216-853-11 | METAL CHIP | 470K | 5% | 1/10W |
| R2181 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2182 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2183 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2184 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2185 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R2186 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R2500 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R2501 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R2502 | 1-216-836-11 | METAL CHIP | 18K | 5% | 1/10W |
| R2503 | 1-218-708-11 | METAL CHIP | 4.7K | 0.5% | 1/10W |
| R2504 | 1-218-723-11 | METAL CHIP | 20K | 0.5% | 1/10W |
| R2505 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2506 | 1-216-836-11 | METAL CHIP | 18K | 5% | 1/10W |
| R2507 | 1-218-696-11 | METAL CHIP | 1.5K | 0.5% | 1/10W |
| R2508 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R2509 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| R2510 | 1-218-723-11 | METAL CHIP | 20K | 0.5% | 1/10W |
| R2511 | 1-216-836-11 | METAL CHIP | 18K | 5% | 1/10W |
| R2512 | 1-218-708-11 | METAL CHIP | 4.7K | 0.5% | 1/10W |
| R2513 | 1-218-696-11 | METAL CHIP | 1.5K | 0.5% | 1/10W |
| R2514 | 1-218-723-11 | METAL CHIP | 20K | 0.5% | 1/10W |
| R2516 | 1-216-836-11 | METAL CHIP | 18K | 5% | 1/10W |
| R2517 | 1-218-723-11 | METAL CHIP | 20K | 0.5% | 1/10W |
| R2518 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R2519 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R2521 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R2522 | 1-216-825-11 | METAL CHIP | 2.2K | 5% | 1/10W |
| R2523 | 1-216-857-11 | METAL CHIP | 1M | 5% | 1/10W |
| R2524 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2525 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2526 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R2527 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R2528 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R2529 | 1-216-813-11 | METAL CHIP | 220 | 5% | 1/10W |
| R2530 | 1-216-813-11 | METAL CHIP | 220 | 5% | 1/10W |
| R2531 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R2532 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R2534 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2535 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2536 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R2539 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2540 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2541 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |
| R2544 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2546 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R2547 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2548 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |
| R2549 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2550 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2551 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R2552 | 1-216-845-11 | METAL CHIP | 100K | 5% | 1/10W |
| R2553 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R2554 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R2555 | 1-216-813-11 | METAL CHIP | 220 | 5% | 1/10W |
| R2556 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R2559 | 1-216-817-11 | METAL CHIP | 470 | 5% | 1/10W |
| R2561 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2562 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R2565 | 1-216-813-11 | METAL CHIP | 220 | 5% | 1/10W |
| R2567 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2569 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |
| R2570 | 1-216-837-11 | METAL CHIP | 22K | 5% | 1/10W |
| R2571 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2572 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R2573 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R2574 | 1-216-853-11 | METAL CHIP | 470K | 5% | 1/10W |
| R2575 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2576 | 1-216-841-11 | METAL CHIP | 47K | 5% | 1/10W |
| R2577 | 1-216-853-11 | METAL CHIP | 470K | 5% | 1/10W |
| R2578 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2579 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R2580 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R2581 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| R2583 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2584 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2585 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R2591 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| | | <VARISTOR> | | | |
| VD2024 | 1-803-974-21 | VARISTOR, CHIP | (1608) | | |
| VD2025 | 1-803-974-21 | VARISTOR, CHIP | (1608) | | |
| VD2026 | 1-803-974-21 | VARISTOR, CHIP | (1608) | | |
| VD2029 | 1-803-974-21 | VARISTOR, CHIP | (1608) | | |
| VD2030 | 1-803-974-21 | VARISTOR, CHIP | (1608) | | |
| VD2031 | 1-803-974-21 | VARISTOR, CHIP | (1608) | | |
| | | <CRYSTAL> | | | |
| X2500 | 1-767-639-21 | VIBRATOR, CRYSTAL 24.576MHz | | | |

**********

* A-1300-324-A UD BOARD, COMPLETE
**********

| | | | | | |
|---|---|---|---|---|---|
| | | <CAPACITOR> | | | |
| C7001 | 1-126-395-11 | ELECT CHIP | 22µF | 20% | 16V |
| C7002 | 1-162-917-11 | CERAMIC CHIP | 15pF | 5% | 50V |
| C7004 | 1-162-970-11 | CERAMIC CHIP | 0.01µF | 10% | 25V |
| C7005 | 1-162-970-11 | CERAMIC CHIP | 0.01µF | 10% | 25V |
| C7006 | 1-124-779-00 | ELECT CHIP | 10µF | 20% | 16V |
| C7007 | 1-162-917-11 | CERAMIC CHIP | 15pF | 5% | 50V |
| C7008 | 1-162-970-11 | CERAMIC CHIP | 0.01µF | 10% | 25V |
| C7010 | 1-162-970-11 | CERAMIC CHIP | 0.01µF | 10% | 25V |
| C7011 | 1-162-970-11 | CERAMIC CHIP | 0.01µF | 10% | 25V |
| C7012 | 1-124-779-00 | ELECT CHIP | 10µF | 20% | 16V |
| C7013 | 1-162-970-11 | CERAMIC CHIP | 0.01µF | 10% | 25V |
| C7014 | 1-162-970-11 | CERAMIC CHIP | 0.01µF | 10% | 25V |
| C7015 | 1-162-970-11 | CERAMIC CHIP | 0.01µF | 10% | 25V |
| C7016 | 1-162-970-11 | CERAMIC CHIP | 0.01µF | 10% | 25V |
| C7017 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7018 | 1-162-923-11 | CERAMIC CHIP | 47pF | 5% | 50V |
| C7019 | 1-162-923-11 | CERAMIC CHIP | 47pF | 5% | 50V |
| C7020 | 1-162-923-11 | CERAMIC CHIP | 47pF | 5% | 50V |
| C7021 | 1-124-779-00 | ELECT CHIP | 10µF | 20% | 16V |
| C7022 | 1-115-416-11 | CERAMIC CHIP | 0.001µF | 5% | 25V |
| C7023 | 1-162-927-11 | CERAMIC CHIP | 100pF | 5% | 50V |
| C7024 | 1-124-779-00 | ELECT CHIP | 10µF | 20% | 16V |
| C7025 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7026 | 1-124-779-00 | ELECT CHIP | 10µF | 20% | 16V |
| C7027 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7028 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7029 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7030 | 1-162-927-11 | CERAMIC CHIP | 100pF | 5% | 50V |
| C7031 | 1-162-927-11 | CERAMIC CHIP | 100pF | 5% | 50V |
| C7032 | 1-162-927-11 | CERAMIC CHIP | 100pF | 5% | 50V |
| C7033 | 1-124-779-00 | ELECT CHIP | 10µF | 20% | 16V |
| C7034 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7035 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7036 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7037 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7038 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7039 | 1-126-395-11 | ELECT CHIP | 22µF | 20% | 16V |
| C7040 | 1-162-921-11 | CERAMIC CHIP | 33pF | 5% | 50V |
| C7041 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7042 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7043 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7044 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7045 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7046 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7047 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7048 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7049 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7050 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7051 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7052 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7053 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7056 | 1-126-395-11 | ELECT CHIP | 22µF | 20% | 16V |
| C7057 | 1-162-921-11 | CERAMIC CHIP | 33pF | 5% | 50V |
| C7058 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7059 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7060 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7061 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7062 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7064 | 1-126-395-11 | ELECT CHIP | 22µF | 20% | 16V |
| C7065 | 1-162-970-11 | CERAMIC CHIP | 0.01µF | 10% | 25V |
| C7066 | 1-162-970-11 | CERAMIC CHIP | 0.01µF | 10% | 25V |
| C7067 | 1-162-970-11 | CERAMIC CHIP | 0.01µF | 10% | 25V |
| C7068 | 1-162-970-11 | CERAMIC CHIP | 0.01µF | 10% | 25V |
| C7069 | 1-162-970-11 | CERAMIC CHIP | 0.01µF | 10% | 25V |
| C7070 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7071 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7078 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7079 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| C7080 | 1-164-156-11 | CERAMIC CHIP | 0.1µF | | 25V |
| | | <CONNECTOR> | | | |
| CN7001 * | 1-816-228-21 | CONNECTOR, DIV (DVI/HDTV IN: VIDEO) | | | |
| CN7002 * | 1-564-526-11 | PLUG, CONNECTOR 11P | | | |
| CN7004 * | 1-564-519-11 | PLUG, CONNECTOR 4P | | | |
| | | <DIODE> | | | |
| D7001 | 8-719-914-43 | DIODE DAN202K | | | |
| D7002 | 8-719-036-94 | DIODE MM3Z5V6ST1 | | | |
| D7002 | 8-719-069-55 | DIODE UDZSTE-175.6B | | | |
| D7003 | 8-719-036-94 | DIODE MM3Z5V6ST1 | | | |
| D7003 | 8-719-069-55 | DIODE UDZSTE-175.6B | | | |
| D7004 | 8-719-036-94 | DIODE MM3Z5V6ST1 | | | |
| D7004 | 8-719-069-55 | DIODE UDZSTE-175.6B | | | |
| D7006 | 8-719-036-94 | DIODE MM3Z5V6ST1 | | | |
| D7006 | 8-719-069-55 | DIODE UDZSTE-175.6B | | | |

| REF. NO. | PART NO. | DESCRIPTION | | | REMARK |
|---|---|---|---|---|---|
| | | <FERRITE BEAD> | | | |
| FB7001 | 1-414-760-21 | FERRITE | 0μH | | |
| FB7002 | 1-414-760-21 | FERRITE | 0μH | | |
| FB7003 | 1-414-760-21 | FERRITE | 0μH | | |
| FB7004 | 1-414-760-21 | FERRITE | 0μH | | |
| | | <FILTER> | | | |
| FL7001 | 1-400-087-21 | FILTER, EMI REMOVAL (SMD) | | | |
| FL7002 | 1-234-560-21 | FILTER, LOW PASS | | | |
| FL7003 | 1-234-559-21 | FILTER, LOW PASS | | | |
| FL7004 | 1-234-559-21 | FILTER, LOW PASS | | | |
| | | <IC> | | | |
| IC7001 | 8-759-640-39 | IC BR24C02F-WE2 | | | |
| IC7002 | 8-749-015-18 | IC PQ07VZ012ZP | | | |
| IC7003 | 8-749-015-18 | IC PQ07VZ012ZP | | | |
| IC7004 | 6-702-080-01 | IC GM7030-H | | | |
| IC7005 | 6-802-346-01 | IC ST72631K4M1/NNLTR | | | |
| IC7006 | 8-759-641-86 | IC BR24C16F-E2 | | | |
| IC7007 | 6-500-224-01 | DIODE I06LC-T13 | | | |
| IC7007 | 6-702-170-01 | IC PACDN006S | | | |
| IC7008 | 6-500-224-01 | DIODE I06LC-T13 | | | |
| IC7008 | 6-702-170-01 | IC PACDN006S | | | |
| IC7009 | 6-702-170-01 | IC PACDN006S | | | |
| | | <COIL> | | | |
| L7001 | 1-412-058-11 | INDUCTOR | 10μH | | |
| L7002 | 1-412-058-11 | INDUCTOR | 10μH | | |
| | | <RESISTOR> | | | |
| R7003 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R7004 | 1-218-852-11 | METAL CHIP | 1.6K | 5% | 1/10W |
| R7007 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R7012 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R7013 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R7014 | 1-216-821-11 | METAL CHIP | 1K | 5% | 1/10W |
| R7015 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R7016 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R7020 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R7021 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R7023 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R7024 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R7025 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R7026 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R7029 | 1-218-692-11 | METAL CHIP | 1K | 0.5% | 1/10W |
| R7030 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R7032 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R7034 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R7036 | 1-218-704-11 | METAL CHIP | 3.3K | 0.5% | 1/10W |
| R7037 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R7041 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R7043 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R7044 | 1-216-829-11 | METAL CHIP | 4.7K | 5% | 1/10W |
| R7045 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R7047 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R7051 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R7053 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R7054 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R7056 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R7057 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R7058 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R7059 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R7060 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R7061 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R7062 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R7063 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R7064 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R7065 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R7066 | 1-218-694-11 | METAL CHIP | 1.2K | 0.5% | 1/10W |
| R7067 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R7068 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R7069 | 1-216-801-11 | METAL CHIP | 22 | 5% | 1/10W |
| R7071 | 1-216-803-11 | METAL CHIP | 33 | 5% | 1/10W |
| R7072 | 1-216-803-11 | METAL CHIP | 33 | 5% | 1/10W |
| R7075 | 1-218-676-11 | METAL CHIP | 220 | 0.5% | 1/10W |
| R7080 | 1-218-704-11 | METAL CHIP | 3.3K | 0.5% | 1/10W |
| R7087 | 1-218-680-11 | METAL CHIP | 330 | 0.5% | 1/10W |
| R7096 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R7097 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R7098 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R7099 | 1-216-809-11 | METAL CHIP | 100 | 5% | 1/10W |
| R7101 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R7106 | 1-216-833-11 | METAL CHIP | 10K | 5% | 1/10W |
| R7108 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R7109 | 1-216-805-11 | METAL CHIP | 47 | 5% | 1/10W |
| R7111 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R7112 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R7113 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R7114 | 1-218-700-11 | METAL CHIP | 2.2K | 0.5% | 1/10W |
| R7115 | 1-218-700-11 | METAL CHIP | 2.2K | 0.5% | 1/10W |
| R7116 | 1-218-700-11 | METAL CHIP | 2.2K | 0.5% | 1/10W |
| R7117 | 1-218-668-11 | METAL CHIP | 100 | 0.5% | 1/10W |
| R7119 | 1-218-668-11 | METAL CHIP | 100 | 0.5% | 1/10W |
| R7121 | 1-216-864-11 | SHORT CHIP | 0 | | |
| R7123 | 1-218-704-11 | METAL CHIP | 3.3K | 0.5% | 1/10W |
| R7124 | 1-218-680-11 | METAL CHIP | 330 | 0.5% | 1/10W |
| R7125 | 1-218-700-11 | METAL CHIP | 2.2K | 0.5% | 1/10W |
| R7126 | 1-216-864-11 | SHORT CHIP | 0 | | |
| | | <CRYSTAL> | | | |
| X7001 | 1-795-568-21 | VIBRATOR, CRYSTAL | | | |
| X7002 | 1-795-567-21 | VIBRATOR, CRYSTAL | | | |

**********

The components identified by shading and mark [ ! ] are critical for safety. Replace only with part number specified.

Les composants identifi s par un tram et une marque [ ! ] sont critiques pour la s curit . Ne les remplacer que par une pi ce portant le num ro sp cifi .

| REF. NO. | PART NO. | DESCRIPTION | REMARK |
|---|---|---|---|
| | | MISCELLANEOUS | |
| | | ********** | |
| | 1-419-661-11 | COIL, CHOKE 4.0mH | |
| ! | 1-468-510-13 | POWER BLOCK | |
| | 1-500-386-11 | FILTER, CLAMP (FERRITE CORE) | |
| | 1-500-603-11 | CLAMP, FERRITE | |
| | 1-543-653-11 | CORE ASSY, BEAD(DIVISION TYPE) (60XBR800) | |
| * | 1-557-056-31 | CABLE, P-P | |
| ! | 1-698-696-21 | FAN, DC | |
| ! | 1-769-837-11 | CORD, POWER (WITH NOISE FILTER) | |
| | 1-771-787-13 | SWITCH, RF ANTENNA | |
| ! | 1-900-253-70 | CONNECTOR ASSY, SMP-B 2P | |
| ! | A-1601-753-A | LAMP BLOCK ASSY (RP) | |
| ! * | A-1603-611-A | OPTICS UNIT BLOCK ASSY (IRP) (60XBR800) | |
| ! * | A-1603-624-A | OPTICS UNIT BLOCK ASSY (IRP) (50XBR800) | |
| | | ACCESSORIES & PACKING MATERIALS | |
| | | ********** | |
| | 3-701-910-00 | SCREW, SPECIAL (DIA. 3.8X20) | |
| * | 4-030-895-01 | JOINT | |
| * | 4-042-463-01 | SHEET, PROTECTION | |
| * | 4-090-860-01 | INDIVIDUAL CARTON (60XBR800) | |
| * | 4-090-861-01 | TRAY (60XBR800) | |
| * | 4-090-862-01 | BOARD, TOP (60XBR800) | |
| * | 4-090-863-01 | BOARD, BOTTOM (60XBR800) | |
| * | 4-090-864-01 | CUSHION, UPPER (60XBR800) | |
| * | 4-090-865-01 | CUSHION, LOWER (60XBR800) | |
| * | 4-090-866-01 | CUSHION, FRONT (60XBR800) | |
| * | 4-091-040-01 | PAD (50XBR800) | |
| * | 4-091-041-01 | CUSHION (UPPER MIDDLE) (60XBR800) | |
| * | 4-091-048-01 | CUSHION, UPPER (50XBR800) | |
| * | 4-091-049-01 | CUSHION, LOWER (50XBR800) | |
| * | 4-091-050-01 | CUSHION, FRONT (50XBR800) | |
| * | 4-091-051-01 | INDIVIDUAL CARTON (50XBR800) | |
| * | 4-091-052-01 | TRAY (50XBR800) | |
| * | 4-091-131-01 | BOARD, BOTTOM (50XBR800) | |
| | 4-091-169-11 | MANUAL, INSTRUCTION | |
| | 4-091-169-21 | MANUAL, INSTRUCTION | |
| | 4-091-169-31 | MANUAL, INSTRUCTION | |
| * | 4-091-526-01 | BAG, PROTECTION (50XBR800) | |
| | 4-392-004-01 | CLIP | |
| | X-403-343-01 | WRENCH, HEXAGON | |
| | X-4033-430-1 | WRENCH ASSY | |
| | X-4040-886-1 | ASSY, CLEANING CLOTH | |

| REF. NO. | PART NO. | DESCRIPTION | REMARK |
|---|---|---|---|
| | | REMOTE COMMANDER | |
| | | ********** | |
| | 1-477-670-11 | REMOTE COMMANDER (RM-Y912) | |


©2005.6

Self Diagnosis Supported model

# SERVICE MANUAL LA-1A CHASSIS

| MODEL | COMMANDER | DEST | CHASSIS NO. |
|---|---|---|---|
| KF-50XBR800 | RM-Y912 | US | |
| KF-50XBR800 | RM-Y912 | Canadian | |
| KF-60XBR800 | RM-Y912 | US | |
| KF-60XBR800 | RM-Y912 | Canadian | |

## CORRECTION - 1

SUBJECT: M BOARD ADDED EXPLODED VIEW AND ELECTRICAL PARTS LIST

Correct the service manual as shown.
File this Correction with the service manual.

☛ : Corrected Item

SECTION 5: EXPLODED VIEWS
5-3.MAIN SECTION (PAGE 140)

INCORRECT

| REF. NO. | PART NO. | DESCRIPTION |
|---|---|---|
| 166 | Needs to be added | |
| 166 | A-1300-699-A | M BOARD, COMPLETE |

CORRECT

| | REF. NO. | PART NO. | DESCRIPTION |
|---|---|---|---|
| ☛ | | A-1300-943-B | M BOARD, COMPLETE (FOR KF-50XBR800 ONLY) |
| ☛ | | A-1300-699-B | M BOARD, COMPLETE (FOR KF-60XBR800 ONLY) |

SECTION 6: ELECTRICAL PARTS LIST (PAGE 166)

INCORRECT

| REF. NO. | PART NO. | DESCRIPTION |
|---|---|---|
| | Needs to be added | |
| | A-1300-699-A | M BOARD, COMPLETE |

CORRECT

| | REF. NO. | PART NO. | DESCRIPTION |
|---|---|---|---|
| ☛ | | A-1300-943-B | M BOARD, COMPLETE (FOR KF-50XBR800 ONLY) |
| ☛ | | A-1300-699-B | M BOARD, COMPLETE (FOR KF-60XBR800 ONLY) |

LCD PROJECTION TV

SONY®

**Sony Corporation**
**Sony Technology Center**
**Technical Services**
**Service Promotion Department**

**English**
**2003DJWEB-1**
**©2003.04**

**9-965-350-91**

SONY

4-091-169-**12**(1)

# GRAND WEGA

LCD Projection TV
HD-Monitor
Operating Instructions

## KF-50XBR800
## KF-60XBR800

DRC Digital Reality Creation

CineMotion reverse 3-2 pull down technology

© 2002 Sony Corporation

## WARNING

**To prevent fire or shock hazard, do not expose the LCD Projection TV to rain or moisture.**




This symbol is intended to alert the user to the presence of uninsulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

### CAUTION

To prevent electric shock, do not use this polarized AC plug with an extension cord, receptacle or other outlet unless the blades can be fully inserted to prevent blade exposure.

### Note on Caption Vision

This television receiver provides display of television closed captioning in accordance with §15.119 of the FCC rules.

### Note to CATV system installer

This reminder is provided to call the CATV system installer’s attention to Article 820-40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.

Use of this television receiver for other than private viewing of programs broadcast on UHF, VHF, transmitted by cable companies or satellite for the use of the general public may require authorization from the broadcaster/cable company and/or program owner.

### NOTIFICATION

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference with radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antennas.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

> You are cautioned that any changes or modifications not expressly approved in this manual could void your warranty and your authority to operate this equipment.

This document is for the remote control RM-Y912.
MODEL: KF-50XBR800, KF-60XBR800
Please keep this notice with the instruction manual.

## Safety

- Operate the LCD Projection TV only on 120 V AC.
- The plug is designed, for safety purposes, to fit into the wall outlet only one way. If you are unable to insert the plug fully into the outlet, contact your dealer.
- If any liquid or solid object should fall inside the cabinet, unplug the LCD Projection TV immediately and have it checked by qualified service personnel before operating it further.
- If you will not be using the LCD Projection TV for several days, disconnect the power by pulling the plug itself. Never pull on the cord.

  For details concerning safety precautions, see "Important Safeguards" on page 4.

## Installing

- To prevent internal heat buildup, do not block the ventilation openings.
- Do not install the LCD Projection TV in a hot or humid place, or in a place subject to excessive dust or mechanical vibration.
- Avoid operating the LCD Projection TV at temperature below 41°F (5°C).
- If the LCD Projection TV is transported directly from a cold to a warm location, or if the room temperature changes suddenly, the picture may be blurred or show poor color. In this case, please wait a few hours to let the moisture evaporate before turning on the LCD Projection TV.
- To obtain the best picture, do not expose the screen to direct illumination or direct sunlight. It is recommended to use spot lighting directed down from the ceiling or to cover the windows that face the screen with opaque drapery. It is desirable to install the LCD Projection TV in a room where the floor and walls are not of a reflective material.

As an ENERGY STAR® Partner, Sony Corporation has determined that this product meets the ENERGY STAR® guidelines for energy efficiency.

ENERGY STAR® is a U.S. registered mark.

TruSurround and the ( ● ) symbol are trademarks of SRS Labs, Inc.

TruSurround technology is incorporated under license from SRS Labs, Inc.

BBE and BBE Symbol are trademarks of BBE Sound, Inc. and are licensed by BBE Sound, Inc. under U.S. Patent No. 4,638,258 and 4,482,866.

## ATTENTION

Pour prévenir les chocs électriques, ne pas utiliser cette fiche polarisée avec un prolongateur, une prise de courant ou une autre sortie de courant, sauf si les lames peuvent tre inserées à fond sans en laisser aucune partie à decouvert.

## Owner's Record

The model and serial numbers are located at the rear of the LCD Projection TV, below the Sony logo, on the sticker, and also on the TV box (white label). Record these numbers in the spaces provided below. Refer to them whenever you call upon your Sony dealer regarding this product.

Model No._____

Serial No._____

# Important Safety Instruction

1) Read these instructions.
2) Keep these instructions.
3) Heed all warnings.
4) Following all instructions.
5) Do not use this apparatus near water.
6) Clean only with dry cloth.
7) Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8) Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9) Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10) Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11) Only use attachments/accessories specified by the manufacturer.
12) Use only with the cart stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13) Unplug this apparatus during lightning storms or when unused for long periods of time.
14) Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15) Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.

# Important Safeguards

For your protection, please read these instructions completely, and keep this manual for future reference.

Carefully observe and comply with all warnings, cautions and instructions placed on the set or described in the operating instructions or service manual.

## WARNING

To guard against injury, the following basic safety precautions should be observed in the installation, use and servicing of the set.

## Use

### Power Sources

This set should be operated only from the type of power source indicated on the serial/model plate. If you are not sure of the type of electrical power supplied to your home, consult your dealer or local power company. For those sets designed to operate from battery power, refer to the operating instructions.

### Grounding or Polarization

This set is equipped with a polarized AC power cord plug (a plug having one blade wider than the other), or with a three-wire grounding type plug (a plug having a third pin for grounding). Follow the instructions below:

### For the set with a polarized AC power cord plug



This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug still fails to fit, contact your electrician to have a suitable outlet installed. Do not defeat the safety purpose of the polarized plug by forcing it in.

### Alternate Warning for the set with a three-wire grounding type AC plug



This plug will only fit into a grounding-type power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to have a suitable outlet installed. Do not defeat the safety purpose of the grounding plug.

## Overloading



Do not overload wall outlets, extension cords or convenience receptacles beyond their capacity, since this can result in fire or electric shock.

Always turn the set off when it is not being used. When the set is left unattended and unused for long periods of time, unplug it from the wall outlet as a precaution against the possibility of an internal malfunction that could create a fire hazard.

If a snapping or popping sound from a TV set is continuous or frequent while the TV is operating, unplug the TV and consult your dealer or service technician. It is normal for some TV sets to make occasional snapping or popping sounds, particularly when being turned on or off.

## Object and Liquid Entry



Never push objects of any kind into the set through the cabinet slots as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the set.

## Attachments



Do not use attachments not recommended by the manufacturer, as they may cause hazards.

## Cleaning

Clean the cabinet of the LCD Projection TV with a dry soft cloth. To remove dust from the screen, wipe it gently with a soft cloth. Stubborn stains may be removed with a cloth slightly dampened with solution of mild soap and warm water. Never use strong solvents such as thinner or benzine for cleaning.

If the picture becomes dark after using the LCD Projection TV for a long period of time, it may be necessary to clean the inside of the LCD Projection TV. Consult qualified service personnel.

## On contamination on the screen surface

The screen surface has a special coating to reduce a picture displayed by reflecting. If you clean the screen surface in the wrong way, the screen may be damaged. To clean the screen, do as follows:

- Clean the screen with a soft cloth, such as the supplied cleaning cloth or a glass cleaning cloth.
- To remove hard contamination, use the supplied cleaning cloth or a glass cleaning cloth moistened with a solution of mild detergent and water.
- Do not use any type of abrasive pad, alkaline cleaner, acid cleaner, scouring powder, chemical cloth, or solvent such as alcohol, benzene or thinner, as these may scratch the screen's coating.

# Installation

## Water and Moisture

Do not use power-line operated sets near water — for example, near a bathtub, washbowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool, etc.

## Accessories

Do not place the set on an unstable cart, stand, table or shelf. The set may fall, causing serious injury to a child or an adult and serious damage to the set. Use only a cart or stand recommended by the manufacturer for the specific model of LCD Projection TV. An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.

## Ventilation

The slots and openings in the cabinet and in the back or bottom are provided for necessary ventilation. To ensure reliable operation of the set, and to protect it from overheating, these slots and openings must never be blocked or covered.

- Never cover the slots and openings with a cloth or other materials.

- Never block the slots and openings by placing the set on a bed, sofa, rug or other similar surface.

- Never place the set in a confined space, such as a bookcase or built-in cabinet, unless proper ventilation is provided.

- Do not place the set near or over a radiator or heat register, or where it is exposed to direct sunlight.

## Power-Cord Protection

Do not allow anything to rest on or roll over the power cord, and do not place the set where the power cord is subject to wear or abuse.

## Antennas

## Outdoor Antenna Grounding

If an outdoor antenna is installed, follow the precautions below. An outdoor antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can come in contact with such power lines or circuits.

WHEN INSTALLING AN OUTDOOR ANTENNA SYSTEM, EXTREME CARE SHOULD BE TAKEN TO KEEP FROM CONTACTING SUCH POWER LINES OR CIRCUITS AS CONTACT WITH THEM IS ALMOST INVARIABLY FATAL.

Be sure the antenna system is grounded so as to provide some protection against voltage surges and built-up static charges.

Section 810 of the National Electrical Code (NEC) in USA and Section 54 of the Canadian Electrical Code in Canada provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.

## Antenna Grounding According to the NEC

Refer to section 54-300 of Canadian Electrical Code for Antenna Grounding.


Antenna lead-in wire
Ground clamp
Antenna lead-in wire (NEC Section 810-20)
Electrical service equipment
Grounding conductors (NEC section 810-21)
Ground clamps
Power service grounding electrode system (NEC Art 250 Part H)
NEC: National Electrical Code

## Lightning

For added protection for this television receiver during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna. This will prevent damage to the receiver due to lightning and power-line surges.

# Service

## Damage Requiring Service

Unplug the set from the wall outlet and refer servicing to qualified service personnel under the following conditions:




- When the power cord or plug is damaged or frayed.
- If liquid has been spilled into the set.

- If the set has been exposed to rain or water.
- If the set has been subject to excessive shock by being dropped, or the cabinet has been damaged.

- If the set does not operate normally when following the operating instructions. Adjust only those controls that are specified in the operating instructions. Improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the set to normal operation.

- When the set exhibits a distinct change in performance, it indicates a need for service.

## Servicing

Do not attempt to service the set by yourself since opening the cabinet may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

## Replacement Parts

When replacement parts are required, be sure the service technician certifies in writing that he has used replacement parts specified by the manufacturer that have the same characteristics as the original parts.

Unauthorized substitutions may result in fire, electric shock or other hazards.

## Safety Check

Upon completion of any service or repairs to the set, ask the service technician to perform routine safety checks (as specified by the manufacturer) to determine that the set is in safe operating condition, and to so certify. When the set reaches the end of its useful life, improper disposal could result in a picture tube implosion. Ask a qualified service technician to dispose of the set.

# For Safety

## Be careful when moving the LCD Projection TV



When you place the LCD Projection TV in position, be careful not to drop it on your foot or fingers.

Watch your footing while installing the LCD Projection TV.

## Carry the LCD Projection TV in the specified manner

If you carry the LCD Projection TV in a manner other than the specified manner and without the specified number of persons, it may drop and a serious injury may be caused. Be sure to follow the instructions mentioned below.

- Carry the LCD Projection TV with the specified number of persons (see page 18).
- Do not carry the LCD Projection TV holding the speaker grill.
- Hold the LCD Projection TV tightly when carrying it.

## About the LCD Projection TV

Although the LCD projection TV is made with high-precision technology, black dots may appear or bright points of light (red, blue, or green) may appear constantly on the LCD screen. This is a structural property of the LCD panel and is not a malfunction.

## Installation

- If direct sunlight or other strong illumination shines on the screen, part of the screen appears white due to reflections from behind the screen. This is a structural property of the LCD Projection TV.
  Do not expose the screen to direct illumination or direct sunlight.
- The picture quality may be affected by your viewing position. If you view the TV close to you, you may suffer from eye fatigue.
  For the best picture quality, install your LCD projection TV according to the operating instructions.
  Sit at least 1.8 m (approx. 6 ft.) for KF-50XBR800 or 2.2 m (approx. 7 ft.) for KF-60XBR800 away from your LCD projection TV, and within 60° of the vertical viewing area, and 130° of the horizontal viewing area.
- When installing your LCD Projection TV against a wall, keep it at least 10 cm (4 inches) from the wall.

### Projection lamp

- Your LCD projection TV uses a projection lamp as its light source. When the projection lamp wears out after using the LCD projection TV for a long period of time, the screen image becomes dark, or no image will appear on the display. If the lamp replacement indicator of the front panel blinks in red, replace the lamp with a new one (not supplied). In some cases, the lamp bursts inside the lamp unit noisily, but the lamp unit is securely designed so that the pieces of broken glass remain inside the lamp unit. (See “Replacing the Lamp” on page 13.)

### Cooling fan

- This LCD projection TV uses a cooling fan to prevent the internal temperature from heating up. You might hear the noise from the cooling fan, depending on the place you install the LCD projection TV.

# Contents


## Introducing the Sony LCD Projection TV

Presenting the Sony LCD Projection TV.....9
Using This Manual.....10
Enjoying Your LCD Projection TV.....11
Replacing the Lamp.....13

## Installing and Connecting the LCD Projection TV

Contents.....17
Inserting Batteries into the Remote Control.....17
Carrying Your LCD Projection TV.....18
To Prevent the LCD Projection TV from Falling Down.....19
When Installing Your LCD Projection TV Against a Wall.....19
Recommended Viewing Area.....20
LCD Projection TV Controls and Connectors.....21
Connector Types.....24
Basic Connections (Connecting Cable TV or Antenna).....25
Connecting a VCR and Cable.....29
Connecting a VCR and Cable Box.....30
Connecting Two VCRs for Tape Editing.....32
Connecting a Satellite Receiver.....33
Connecting a Satellite Receiver with a VCR.....34
Connecting an Audio Receiver.....36
Connecting a DVD Player with Component Video Connectors.....37
Connecting a DVD Player with A/V Connectors..38
Connecting a Digital TV Receiver with component connectors.....39
Connecting a Digital TV Receiver with DVI-HDTV connector.....40
Connecting a Camcorder.....41
Connecting Two VCRs for Tape Editing.....42
Using the CONTROL S Feature.....43
Setting Up the LCD projection TV Automatically.....44

## Using the Features

Using the Remote Control.....45
Watching the TV.....47
Watching Digital TV.....49
Using Favorite Channels.....50
Using Twin View™.....51
Using the Freeze Function.....54
Using Scrolling Channel Index.....55
Using Wide Screen Mode.....57
Using the Memory Stick Picture Viewer.....58

## Using the Menus

Overview.....66
Using the Video Menu.....67
Using the Audio Menu.....69
Using the Screen Menu.....71
Using the Channel Menu.....73
Using the Parent Menu.....75
Using the Setup Menu.....79

## Other Information

Programming the Remote Control.....82
Operating Other Components with Your LCD Projection TV Remote Control.....84
Notes on Using Memory Stick Media.....86
Troubleshooting.....87
Flashing Indicators on the Front of the Monitor....90
Specifications.....91

# Introducing the Sony LCD Projection TV



## Presenting the Sony LCD Projection TV

Thank you for purchasing the Sony LCD Projection TV.
This manual is for models KF-50XBR800 and KF-60XBR800.

### Features

Some of the features that you will enjoy with your new LCD projection TV include:

- **HD-Monitor**: Enables you to receive the 1080i, 720p, 480p and 480i digital TV format signals.
  By using the HD/DVD IN jacks, you can connect a DTV (digital television) receiver to view DTV programs.
- **DRC™ (Digital Reality Creation) Multifunction UI:** Unlike conventional line doublers, the DRC feature converts frames reproduced every 1/60th of a second in real time, minimizing the blur or ghost of the motion images (for NTSC signals only).
- **CineMotion™:** Using the reverse 3-2 pull down technology, the CineMotion feature allows you to obtain a smooth picture movement when playing back movies or other video sources on film.
- **Twin View™:** Using Multi-Image Driver (MID-X), Twin View allows you to watch two programs side by side with the ability to zoom in on one picture and listen to the program in the selected window. You can watch pictures from two different sources (1080i, 720p, 480p or 480i) simultaneously.
- **Memory Stick® Picture Viewer:** Allows you to view on your LCD Projection TV screen digital images that are stored on Memory Stick media.
- **Parental Control:** V-Chip technology allows parents to block unsuitable programming for younger viewers.
- **Digital Visual Interface (DVI):** Can accommodate a copy-protected digital connection (HDCP*) to other devices (such as digital set-top boxes) that have compatible interfaces. The DVI-HDTV input terminal is compliant with the EIA-861 standard and is not intended for use with personal computers.

* High-bandwidth Digital Content Protection

*(Continued)*

- **Component Video Inputs:** Offers the best video quality for DVD (480p, 480i) and Digital Set-top box (1080i, 720p, 480p, 480i) connections.
- **S-VIDEO Inputs:** Provides a high-quality image for connected equipment.
- **Favorite Channel Preview:** Preview up to eight favorite channels without leaving the current channel.
- **Scrolling Channel Index:** Allows you to view and choose channels from scrolling pictures without leaving the current channel.
- **Wide Screen Mode:** Allows you to watch 4:3 normal broadcasts in wide screen mode (16:9 aspect ratio).
- **Auto Wide:** Allows you to select the wide screen mode automatically.

## Using This Manual

We recommend that you carefully review the contents of the following three sections in the order shown to ensure that you fully understand the operation of your new LCD projection TV.

1 Installing and Connecting the LCD Projection TV
This section guides you through your initial setup. It shows you how to install your LCD projection TV, to connect your new components and to connect the antenna and cable.

2 Using the Features
This section shows you how to begin using your new LCD projection TV. It also shows you how to use your remote control functions.

3 Using the menus
This section teaches you how to access on-screen menus and adjust your LCD projection TV settings.

Instructions in this manual are written for the remote control. Similar controls are also found on the LCD projection TV console.

# Enjoying Your LCD Projection TV






### Indicators

The indicators show the current status of your LCD projection TV. If the LAMP indicator flashes, see “Flashing Indicators on the Front of the Monitor” on page 90.

### Screen

To minimize screen reflection, its surface has a special coating. Read the instructions “Use of the Cleaning Cloth” on page 12 carefully before cleaning.

Inappropriate cleaning methods could damage the finishing.

### Projection lamp

Your LCD projection TV uses a projection lamp as its light source. Note the following:

- After turning on your LCD projection TV, it may take a while before the picture appears (1 minute or less).
- When the projection lamp wears out, the screen image becomes dark. Replace the lamp with a new Sony XL-2000U replacement lamp (not supplied).

✍ Be sure to attach the lamp cover securely; otherwise, your LCD projection TV will not turn on. For details on lamp replacement, see “Replacing the Lamp” on page 13.

✍ The light emitted from the lamp is quite bright when your LCD projection TV is in use. To avoid eye discomfort or injury, do not look into the housing when the power is on.

## Notes on the LCD Projection TV

### To enjoy clear pictures

- Be sure not to allow sunlight or light from a lamp to shine directly onto the screen.
- The screen surface is easily scratched. Do not rub, touch, or tap it with a sharp or abrasive object (see "Use of the Cleaning Cloth" below).

### On moisture condensation

- If your LCD projection TV is transported directly from a cold to a warm location, is placed in a humid room, or if the room temperature changes suddenly, the picture may be blurred or show poor color. This is because moisture has condensed on the lenses inside. If this happens, leave the power on and let the moisture evaporate before using your LCD projection TV.

### When the LCD projection TV will not be used for a long period of time

- Turn off the main power on the front of your LCD projection TV before going to sleep or going out. Disconnect the AC plug if idle for more than 7 days.

### When turning off the power

- Be sure to turn off the power switch on the main unit or on the remote control. After turning off the power, the fan will continue to blow for about two minutes. Be sure to wait for several minutes after turning the power off when unplugging from the outlet or switching the breaker off.

## Use of the Cleaning Cloth

To remove dust from the front of the screen, wipe with the supplied Cleaning Cloth.

- Do not use any type of abrasive pad, alkaline cleaner, scouring powder, window cleaners or solvent such as alcohol or benzene. Otherwise, this type of contact may result in a damaged screen.
- To clean the screen, please use the supplied Cleaning Cloth lightly moistened with water diluted mild detergent solution. Do not apply heavy press when cleaning.
- The supplied Cleaning Cloth is washable with warm water and a mild detergent solution, and can be used repeatedly.

# Replacing the Lamp

The projection lamp has a limited life which illuminates the picture.

If the screen becomes dark, the color looks unusual, or the LAMP indicator on the front of the LCD projection TV flashes, it is time to replace the lamp with a new one (not supplied).

**⚠ WARNING**
Electric appliances can cause fire or high temperature, resulting in injury or death. Be sure to follow the instructions below.

- Use a Sony XL-2000U replacement lamp (not supplied) for replacement. Failure to do so may damage the LCD projection TV.
- Do not remove the lamp for any purpose other than replacement. Failure to do so may cause fire or a skin burn.
- Before replacing the lamp, turn the power off on the main unit, then several minutes later, unplug the power cord. (The cooling fan will continue to blow for about two minutes after turning the power off.)
- Before replacing the lamp, let it cool down completely, as the surface of the lamp remains extremely hot for at least 30 minutes after the power has been turned off.
- Do not leave the removed lamp near flammable materials or within the reach of children.
- Do not pour water onto the removed lamp, or put any object inside the lamp. Doing so may cause the lamp to burst.
- Do not put flammable materials and metal objects inside the lamp receptacle of the LCD projection TV after removing the lamp. Doing so may cause fire or electrical shock. Also, be sure not to touch the receptacle, because it may cause a skin burn.
- Mount the new lamp securely, otherwise the screen may become dark, or it may cause a fire.
- Do not touch the glass with your fingers on the new lamp.

### Collecting the used lamp

For environmental conservation, Sony collects the used lamps. Please put the used lamp in the lamp box and give it to your Sony dealer where you bought the lamp.

✍ Do not touch the front glass of a new lamp or the glass of the lamp receptacle. This may reduce picture quality or lamp life.

*(Continued)*

**1** Turn off the power switch on the LCD projection TV and after several minutes, unplug the power cord.
(The cooling fan will continue to blow for about two minutes after turning the power off.)

✍ Do not touch the front glass of a new lamp or the glass of the lamp receptacle. This may reduce picture quality or lamp life.

**2** Unplug the power cord after turning off the main power. Wait at least 30 minutes to allow the lamp to cool down before replacing it.
Take the new lamp out of the box.

**3** Remove the front panel.



**Hold the LCD projection TV firmly so that it does not move.**



**Grasping the right end of the front panel with your fingers, pull the panel towards you.**

**4** Loosen the screw with a coin or similar object to remove the lamp cover.



**5** Loosen the two screws that secure the lamp, then pull out the lamp.
The lamp is very hot immediately after use. Never touch the front glass of the lamp or the surrounding parts.



**Loosen the two screws with the hex key supplied with the lamp.**



**Hold the handle and pull straight out.**

✍ After it has cooled, place the removed lamp into the empty box of the replacement lamp. Never put the removed lamp into a plastic bag.

**6** Mount the new lamp.
Be sure to attach the new lamp securely.



**Mount the new lamp securely into the lamp receptacle.**




**Tighten the two screws securely in the order of ① to ②, as shown in the illustration using the supplied hex key.**

**7** Mount the lamp cover and tighten the screw.
Make sure that the lamp cover is mounted securely, otherwise the power will not turn on.



**Match the projection of the right side of the lamp cover with the hole of the unit, and replace the lamp cover as it was.**

✍ If the lamp cover is not mounted securely, the self-diagnostic function works and the STAND BY indicator flashes for three times (See page 90).

*(Continued)*

**8** Mount the front panel in the order of ① to ②, as shown in the illustration.




✍ Consult your Sony dealer for a Sony XL-2000U replacement lamp.

✍ Take great care when replacing the lamp or plugging in/unplugging the connecting cords. If you handle them roughly, the LCD projection TV may fall or be moved, and the TV stand or floor surfaces may be scratched.

# Installing and Connecting the LCD Projection TV



## Contents

The box contains your new LCD projection TV, a remote control and two AAA batteries. No peripheral cables are included. If you intend to add additional equipment to your LCD projection TV, please check the hookup instructions for your desired setup before you begin. You may need to purchase cables and/or splitters to complete the hookup properly.

## Inserting Batteries into the Remote Control

Insert two size AAA batteries (supplied) by matching the + and – on the batteries to the diagram inside the battery compartment.




✍ Remove the batteries to avoid damage from possible battery leakage whenever you anticipate that the remote control will not be used for an extended period.

✍ Handle the remote control with care. Avoid dropping it, getting it wet, or placing it in direct sunlight, near a heater, or where the humidity is high.

✍ Your remote control can be programmed to operate most video equipment. (See “Programming the Remote Control” on page 82.)

# Carrying Your LCD Projection TV

Carrying the LCD projection TV requires at least two people. Do not grasp the pedestal or the front panel of the LCD projection TV, otherwise these parts might break off.

When moving the LCD projection TV, support the screen bottom with one hand while grasping the top part with the other hand, as shown in the illustration below.






# To Prevent the LCD Projection TV from Falling Down

Pay special attention to children around the LCD projection TV. If children should climb onto or push the LCD projection TV or its stand, it may fall down.

As a protective measure, secure the LCD projection TV as follows.

### Using supplied brackets

1. Mount the two brackets with the screws (supplied) to the upper rear sides of the LCD projection TV (left and right sides).
2. Pass a strong cord or chain (not supplied) through each bracket and then secure it to a wall or a pillar, etc.




### Using the LCD projection TV stand with support belts

- You can also use the LCD projection TV stand SU-GW1 (not supplied) with support belts.



# When Installing Your LCD Projection TV Against a Wall

Keep your LCD projection TV at least 10 cm (4 inches) from the wall.

# Recommended Viewing Area

The picture quality may be affected by your viewing position.

For the best picture quality, install your LCD projection TV within the areas shown below.

Sit at least 1.8 m (approx. 6 ft.) for KF-50XBR800 or 2.2 m (approx. 7 ft.) for KF-60XBR800 away from your LCD projection TV, and within 60° of the vertical viewing area, and 130° of the horizontal viewing area.

## Horizontal Viewing Area




## Vertical Viewing Area



# LCD Projection TV Controls and Connectors

## Front Panel Menu Controls

The front panel menu controls allow access to the on-screen menus without the use of a remote control. Pressing MENU brings up the on-screen menus. The arrow buttons move the on-screen cursor in the menus and by pressing the ⊹ button selects the menu item.




### How to open and close the front panel




(Continued)

| Item | Description |
|---|---|
| 1 MEMORY STICK | Memory Stick insertion slot. For details, see “Inserting and Removing a Memory Stick” on page 60. |
| 2 MEMORY STICK ACCESS LED | When lit, indicates that the Memory Stick is being read. (Do not remove the Memory Stick when the indicator is lit.) |

## LCD Projection TV Rear and Side Panel Connectors




Left side of LCD projection TV



| Connection | Description |
|---|---|
| 1 AUX | Allows you to view local and cable channels if your cable provider does not feature local channels. You can switch between local and cable channels easily by pressing ANT on the remote control. Devices connected to the AUX input cannot be viewed in Twin View. |
| 2 TO CONVERTER | This is a VHF/UHF OUT jack that lets you set up your LCD projection TV to switch between scrambled channels (through a cable box) and normal cable channels (CATV). Use this jack instead of a splitter to get better picture quality when switching between scrambled and unscrambled cable channels. |
| 3 VHF/UHF (Primary RF input) | Connects to your VHF/UHF antenna or cable. |
| 4 S VIDEO (Rear and side) | Connects to the S VIDEO OUT jack of your VCR or other S VIDEO-equipped video component. Provides better picture quality than the VHF/UHF jacks or the Video IN jack. |
| 5 VIDEO/ (L/R) AUDIO (Rear and side) | Connects to the audio and video OUT jacks on your VCR or other video component. A fourth video input (VIDEO 2) is located on the side panel of the LCD projection TV. |
| 6 HD/DVD IN (1080i, 720p, 480p, 480i) | Connects to your DVD player's or Digital Set-top box's component video (Y, PB, PR) and audio (L/R) jacks. |
| 7 MONITOR OUT | Lets you record the program you are watching to a VCR. When two VCRs are connected, you can use the TV as a monitor for tape-to-tape editing (not available with 480p, 720p, or 1080i when the input is set to VIDEO 5-7). |
| 8 AUDIO OUT (VAR/FIX) L (MONO)/R | Connects to the left and right audio inputs of your audio or video component. |
| 9 CONTROL S IN/OUT | To control other Sony equipment with the LCD projection TV's remote control, connect the CONTROL S IN jack of the equipment to the CONTROL S OUT jack on the LCD projection TV with the CONTROL S cable.<br>To control the LCD projection TV with a remote control for another Sony product, connect the CONTROL S OUT jack of the equipment to the CONTROL S IN jack on the LCD projection TV with the CONTROL S cable. |
| 10 DVI-HDTV VIDEO AUDIO R/L (VIDEO 7 IN) | Can accommodate a copy-protected digital connection (HDCP*) to other devices (such as digital set-top boxes) that have compatible interfaces. The DVI-HDTV input terminal is compliant with the EIA-861 standard and is not intended for use with personal computers. See the instruction manual that came with your equipment for details about connecting and using it with the LCD projection TV. |

* High-bandwidth Digital Content Protection

# Connector Types

You may find it necessary to use some of the following connector types during set up.

### Coaxial cable

Standard TV cable and antenna cable

**Plug Type**

**Screw-on Type**

### S Video cable

High quality video cable for enhanced picture quality

### Audio/Video cable

Video - Yellow
Audio (Left) - White
Audio (Right) - Red

Some DVD Players are equipped with the following three video connectors:

Y - Green
$P_B$ ($C_B$, $C_b$ or B–Y) - Blue
$P_R$ ($C_R$, $C_r$ or R–Y) - Red

### CONTROL S cable

CONTROL S connections are exclusive to Sony products and allow greater control of all Sony equipment.

# Basic Connections (Connecting Cable TV or Antenna)

## Connecting Directly to Cable or an Antenna

The connection you choose depends on the cable found in your home. Newer homes are equipped with standard coaxial cable (see A); older homes probably have 300-ohm twin lead cable (see B); other homes may contain both (see C).

### A VHF Only or VHF/UHF or Cable

### B VHF Only or UHF Only or VHF/UHF




### C VHF and UHF




✍ It is highly recommended to connect the antenna using a 75-ohm coaxial cable to get optimum picture quality. A 300-ohm twin lead cable can be easily affected by radio noise and the like, resulting in signal deterioration. If you use a 300-ohm twin lead cable, keep it away as far as possible from the LCD projection TV.

✍ Do not use an indoor antenna because it is especially susceptible to radio noise.

## Cable and Antenna

If your cable provider does not feature local channels, you may find this set up convenient.




Select CABLE or antenna (ANT) mode by pressing ANT on the remote control.

✍ To receive channels with an antenna, you need to turn your Cable to OFF (see page 73) and perform the Auto Program function (see page 73).

## Cable Box Connections

### Cable Box and Cable

This is the preferred basic cable TV hookup to use if:

- Your cable TV company scrambles some channels, but not all of them (pay channels vs. regular cable channels) and you need to use a cable box, and
- You want to enjoy the Twin View feature.

With this setup you can:

- Use the LCD projection TV remote control to change channels using your cable box when the signal is scrambled.
- Use the LCD projection TV remote control to change channels using your LCD projection TV when the signal is not scrambled. (Your LCD projection TV's tuner provides a better signal than the cable box.)
- Use the Twin View feature. (When all channels are routed through your cable box, only one channel is sent to the LCD projection TV, so you can not use the Twin View or Channel Index features for your cable box.)

1. Connect the Cable TV cable to the LCD projection TV's VHF/UHF jack.
2. Using a coaxial cable, connect the LCD projection TV's TO CONVERTER jack to the cable box's IN jack. The LCD projection TV's internal converter allows you to switch between unscrambled signals coming straight into the LCD projection TV and scrambled signals coming in through the cable box, eliminating the need for an external splitter.

**3** Using a coaxial cable, connect the cable box's OUT jack to the LCD projection TV's AUX jack.




✍ Pressing ANT on the remote control switches between the channels coming in through the cable box (scrambled) and those coming directly to the TV (unscrambled).

### Cable Box Only

Use this hookup if:

- You subscribe to a cable TV system that uses scrambled or encoded signals requiring a cable box to view all channels, and
- You do not intend to hook up any other audio or video equipment to your LCD projection TV.

When all channels are routed through your cable box, only one unscrambled channel is sent to the LCD projection TV, so you cannot use the Twin View feature. If some channels are scrambled, but others are not, consider using the hookup on page 26 instead.

**1** Connect the coaxial connector from your cable service to the cable box's IN jack.

**2** Using a coaxial cable, connect the cable box's OUT jack to the LCD projection TV's VHF/UHF jack.




Also, set Cable to ON in the Channel menu (see page 73).

✍ Your Sony remote control can be programmed to operate your cable box (see "Programming the Remote Control" on page 82).

✍ To change channels using the cable box, set your LCD projection TV to channel 3 or 4 depending on the cable box channel output. If you will be controlling all channel selection through your cable box, consider using the Channel Fix feature to set your LCD projection TV to channel 3 or 4 (see page 73).

Setting the Channel Fix feature in the Channel menu (see "Using the Channel Menu" on page 73), ensures that you do not accidentally switch the channels using your LCD projection TV.

# Connecting a VCR and Cable

Use this hookup if:

- ❑ You have cable TV that does not require a cable box.

**Disconnect all power sources before making any connections.**

1. Connect the cable TV cable to the VCR's IN jack.
2. Using a coaxial cable, connect the VCR's OUT jack to the LCD projection TV's VHF/UHF jack.
3. Using AUDIO and S VIDEO cables, connect the VCR's Audio and S Video OUT jacks to the LCD projection TV's AUDIO and S VIDEO IN jacks.




✍ If your VCR is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.

# Connecting a VCR and Cable Box

Use this hookup if:

- Your cable TV company scrambles some channels, but not all of them (pay channels vs. regular cable channels) and you need to use a cable box, and
- You want to enjoy the Twin View feature.

With this setup you can:

- Use the LCD projection TV remote control to change channels on your cable box when the signal is scrambled. To program your Sony remote control to operate your cable box, see “Programming the Remote Control” on page 82.
- Use the LCD projection TV remote control to change channels using your LCD projection TV when the signal is not scrambled. Your LCD projection TV’s tuner provides a better signal than the cable box.
- Use the Twin View feature. (When all channels are routed through your cable box, only one signal is sent to the LCD projection TV, so you cannot use the Twin View feature.)

**Disconnect all power sources before making any connections.**

1. Connect the Cable TV cable to the LCD projection TV’s VHF/UHF jack.
2. Using a coaxial cable, connect the LCD projection TV’s TO CONVERTER jack to the cable box’s IN jack. The LCD projection TV’s internal converter allows you to switch between unscrambled signals coming straight into the LCD projection TV and scrambled signals coming in through the cable box, eliminating the need for an external splitter.
3. Using a coaxial cable, connect the cable box’s OUT jack to the VCR’s IN jack.
4. Using AUDIO and S VIDEO cables, connect the VCR’s AUDIO and S VIDEO OUT jacks to the LCD projection TV’s AUDIO and S VIDEO IN jacks.
5. Using a coaxial cable, connect the VCR’s OUT jack to the LCD projection TV’s AUX jack.

✍ To view scrambled channels, set your LCD projection TV to AUX 3 or 4 (depending on your cable box output). Change channels using your cable box.




Rear of LCD projection TV

✍ If your VCR is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.

✍ You will not be able to change channels on the VCR. Set your LCD projection TV and VCR to channel 3 or 4, depending on your cable box channel output.

✍ Pressing ANT on the remote control switches between the channels coming in through the cable box (scrambled) and those coming directly to the LCD projection TV (unscrambled).

# Connecting Two VCRs for Tape Editing

If you connect two VCRs, you can record from one VCR to the other while using your LCD projection TV to monitor what is being recorded.

**Disconnect all power sources before making any connections.**

1. Using AUDIO and VIDEO cables, connect the playback VCR's Audio and Video OUT jacks to the recording VCR's Audio and Video IN jacks.
2. Using AUDIO and VIDEO cables, connect the recording VCR's AUDIO and Video OUT jacks to the LCD projection TV's AUDIO and VIDEO IN jacks.




✍ To perform tape editing, set the LCD projection TV to the video input intended for playback by pressing TV/VIDEO on the remote control.

✍ You may need to change the video input on your VCR. Consult your VCR's operating manual for instructions.

✍ If your VCRs have an S VIDEO jack: For best picture quality, use an S VIDEO connection instead of the yellow video cable on your combined A/V cable.
Using an S VIDEO cable, connect the playback VCR's S VIDEO OUT jack to the recording VCR's S VIDEO IN jack. S VIDEO does not provide audio, so audio cables must be connected to provide sound.

✍ You cannot record signals from equipment connected to the Y, $P_B$, $P_R$ input.

# Connecting a Satellite Receiver

**Disconnect all power sources before making any connections.**

1. Connect the satellite antenna cable to the satellite receiver's SATELLITE IN jack.
2. Using AUDIO and S VIDEO cables, connect the satellite receiver's AUDIO and S VIDEO OUT jacks to the LCD projection TV's AUDIO and S VIDEO IN jacks.
3. Connect a coaxial cable from your cable or antenna to the LCD projection TV's VHF/UHF jack.

✍ If your satellite receiver is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.



# *Connecting a Satellite Receiver with a VCR*

**Disconnect all power sources before making any connections.**

1. Connect the satellite antenna cable to the satellite receiver's SATELLITE IN jack.
2. Connect the CATV cable to the VCR's VHF/UHF IN jack.
3. Using a coaxial cable, connect the VCR's OUT jack to the LCD projection TV's VHF/UHF jack.
4. Using AUDIO and S VIDEO cables, connect the satellite receiver's AUDIO and S VIDEO OUT jacks to the VCR's AUDIO and S VIDEO IN jacks.
5. Using AUDIO and S VIDEO cables, connect the VCR's AUDIO and S VIDEO OUT jacks to the LCD projection TV's AUDIO and S VIDEO IN jacks.



✍ Be sure your VCR's video input is set correctly. Consult your VCR's operating manual for instructions.

✍ Use TV/VIDEO to select
- VIDEO 1 to watch satellite TV or the VCR (your VCR must be turned on).
- VHF/UHF to watch cable TV.

✍ If your VCR or satellite receiver is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.

# Connecting an Audio Receiver

**Disconnect all power sources before making any connections.**

Using audio cables, connect the LCD projection TV's AUDIO OUT (VAR/FIX) jacks to the audio receiver's audio LINE IN jacks.



# Connecting a DVD Player with Component Video Connectors

This is the preferred hookup to use if:

- Your DVD player has component (Y, B-Y, R-Y) jacks.

**Disconnect all power sources before making any connections.**

**1** Using three separate component video cables, connect the DVD player's Y, B-Y and R-Y jacks to the Y, PB and PR jacks on the LCD projection TV. Use the HD/DVD IN 5 or 6 connections.

✍ The Y, B-Y and R-Y jacks on your DVD player are sometimes labeled Y, CB and CR, or Y, PB and PR. If so, connect the cables to like colors.

**2** Using an audio cable, connect the DVD player's Audio OUT jacks to the LCD projection TV's AUDIO IN jacks. Be sure to use the same row of inputs that you used for the video connection (HD/DVD IN 5 or 6).




✍ To take advantage of the Wide Screen modes, set the TV's aspect ratio to 16:9 on your DVD player. For details, refer to the operating instructions supplied with your DVD player.

# *Connecting a DVD Player with A/V Connectors*

Use this hookup if:

- ❑ Your DVD player does not have component (Y, PB, PR) jacks.

✍ If your DVD player has video component output connectors: for best picture quality use the connection described on page 37.

**Disconnect all power sources before making any connections.**

**1** Using audio cables, connect the DVD player's Audio OUT jacks to the LCD projection TV's AUDIO IN jacks.

**2** Using an S VIDEO cable, connect the DVD player's S VIDEO jack to the LCD projection TV's S VIDEO jack.




✍ To take advantage of the Wide Screen modes, set the TV's aspect ratio to 16:9 on your DVD player. For details, refer to the operating instructions supplied with your DVD player.

✍ Use TV/VIDEO on the remote control to switch between the VCR, DVD player and cable TV inputs.

✍ If your VCR is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.

# Connecting a Digital TV Receiver with component connectors

**Disconnect all power sources before making any connections.**

Be sure to read the Set-top box manual.

**1** Using three separate component video cables, connect the Digital TV Set-top box's Y, PB and PR jacks to the LCD projection TV.

✍ The Y, PB and PR jacks do not provide audio, so audio cables must be connected to provide sound.

✍ Component video connection is necessary to view 480i, 480p, 720p, and 1080i formats. You may also use the S VIDEO or Composite Video connections, however, component video (Y, PB, PR) will provide the best picture quality for all format types.

**2** Using an audio cable, connect the Digital TV Set-top box's Audio OUT jacks to the LCD projection TV's AUDIO IN jacks.




✍ You cannot record the signal from any equipment connected into the Y, PB and PR connectors.

✍ This LCD projection TV is not compatible with digital TV receivers configured with RGB or VGA output connectors.

# Connecting a Digital TV Receiver with DVI-HDTV connector

Disconnect all power sources before making any connections.

Be sure to read the Set-top box manual.

**1** Using a DVI-D single link cable, connect the Digital TV Set-top box's DVI-HDTV connector to the LCD projection TV.

> The DVI-HDTV VIDEO connector does not provide audio, so audio cables must be connected to provide sound.

**2** Using an audio cable, connect the Digital TV Set-top box's Audio OUT jacks to the LCD projection TV's DVI-HDTV AUDIO jacks.



# Connecting a Camcorder

For easy connection of the camcorder, the LCD projection TV has side Audio and Video inputs (shown below). However, if you prefer, you can also connect the camcorder to the LCD projection TV's rear Audio and Video IN jacks.

Using AUDIO and S VIDEO cables, connect the camcorder's Audio and S VIDEO OUT jacks to the LCD projection TV's AUDIO and S VIDEO IN jacks.

✍ If you have a mono camcorder, connect its left audio output to the LCD projection TV's AUDIO L (MONO) jack.

✍ If your camcorder is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.



# Connecting Two VCRs for Tape Editing

Connecting two VCRs lets you record from one VCR to the other. By connecting them as shown below, you can view (monitor) what is being recorded.

1. Using the AUDIO and VIDEO cable, connect the AUDIO and VIDEO IN jacks to the playback VCR's AUDIO and VIDEO OUT jacks.
2. Using the AUDIO and VIDEO cable, connect the MONITOR OUT jacks to the recording VCR's AUDIO and VIDEO IN jacks.




When the playback VCR is equipped with the S VIDEO OUT jack, connect the S VIDEO jack to the playback VCR's S VIDEO OUT jack.

# Using the CONTROL S Feature

CONTROL S allows you to control your LCD projection TV system and other Sony equipment with one remote control. In addition to allowing you to control multiple devices with one remote control, the CONTROL S feature allows you to always point your remote control at your LCD projection TV, instead of having to point it at the other equipment, which might be hidden or out of direct line of sight.



# Setting Up the LCD projection TV Automatically

After you finish connecting your LCD projection TV, you can run Auto Setup to set up your channels. The Auto Setup screen appears when you turn your LCD projection TV on for the first time after installing it. If you do not want to set up the channels at this time, you can do it later by using the Auto Program feature in the Channel menu (see page 73).

✍ The Auto Setup feature does not apply for installations that use a cable box for all channel selection.

## Using Auto Setup

1. Press POWER on the front panel of your LCD projection TV or on the remote control to turn on the LCD projection TV.
2. Press FUNCTION on the remote control until the TV indicator lights up.
3. Press CH+ on your LCD projection TV to run Auto Setup, or press CH– to exit. If you use the channel buttons on your remote control, be sure to use .

LCD projection TV front panel




✍ You can run Auto Program by selecting it in the Channel menu, as described on page 73.

# Using the Features

## Using the Remote Control

The following table describes the buttons on the remote control that are for more advanced functions.



### Button Descriptions




| | Button | Description |
|---|---|---|
| 1 | MUTING | Press to mute the sound. Press again or press VOL + to restore the sound. |
| 2 | ANT | Changes between the VHF/UHF input and the AUX input. |
| 3 | DISPLAY | Press once to display the current time and channel label (if set) and channel number. Press again to turn Display off. See page 81 for details on setting the time. |
| 4 | JUMP | Press to jump back and forth between two channels. The LCD projection TV alternates between the current channel and the last channel that was selected. |
| 5 | FUNCTION | Select the equipment (TV, SAT/CABLE, DVD/VCR) that you want to operate. The indicator lights up momentarily when pushed to show which device the remote control is operating. |
| 6 | PICTURE MODE | Press repeatedly to step through the available video picture modes: Vivid, Standard, Pro and Mild. Also available in the Video menu. For details, see “Selecting Video Options” on page 67. |
| 7 | WIDE MODE | Press to step through the wide screen modes: Wide Zoom, Normal, Full and Zoom. For details, see “Using Wide Screen Mode” on page 57. |
| 8 | ↑/↓/←/→<br>II/■/◀◀/▶▶ | When the menu is displayed, move the on-screen cursor.<br>II: Pause<br>■: Stop<br>◀◀: Rewind<br>▶▶: Fast-Forward |
| 9 | | ▷: Playback<br>: When the menu is displayed, select the item. |
| 10 | | Turns on/off Twin View. For details, see “Using Twin View™” on page 51. |
| | GUIDE | Displays the program guide of your satellite. |
| 11 | INDEX | Press to enter the Scrolling Channel Index mode. You can view and select from all receivable channels scrolling on the screen without leaving the current one. |

*(Continued)*




| | Button | Description |
|---|---|---|
| 12 | VOL +/– | Adjusts the volume. |
| 13 | POWER buttons (GREEN) | Turn on and off the LCD projection TV and other audio/video equipment you have programmed into the remote control. For instructions, see “Programming the Remote Control” on page 82. |
| 14 | TV/VIDEO | Cycles through the video equipment connected to your LCD projection TV’s video inputs: TV, VIDEO 1, VIDEO 2, VIDEO 3, VIDEO 4, VIDEO 5, VIDEO 6 and VIDEO 7. |
| 15 | 0 – 9 and ENTER | Press 0 - 9 to select a channel, the channel changes after 2 seconds. Press ENTER to select immediately. |
| 16 | ● REC<br>RESET | Record<br>Press when in a menu to reset the settings to the factory defaults. |
| 17 | FAVORITES | Displays the Favorite Channels list. For details, see “Using Favorite Channels” on page 50. |
| 18 | FREEZE | Freezes the window picture. Press again to restore the picture. |
| 19 | MEMORY STICK | Press to display the Memory Stick Menu. For details, see “Using the Memory Stick Picture Viewer” on page 58 |
| 20 | MTS/SAP | Press to scroll through the Multi-channel TV Sound (MTS) options: Stereo, Auto SAP, and Mono. |
| 21 | CH +/– | Scan through channels.<br>To scan rapidly through the channels, press and hold down CH+ or CH–. |
| 22 | MENU | Press to display the LCD projection TV on-screen menu. Press again to exit from the menu. |

# Watching the TV

Many TV features can be accessed directly through the remote control. The following will explain the function of some of the buttons found on your remote control.



## Buttons for LCD Projection TV Operations




**1 FUNCTION**
Press until the TV indicator lights up.
This activates the remote control for use with the LCD projection TV.

**2 ANT— (AUX input)**
Press to change between the VHF/UHF input and the AUX input.

**3 POWER**
Turns the LCD projection TV on and off. If a video input indication (e.g., VIDEO 1, VIDEO 2) appears on the screen, press TV/VIDEO or CH +/ – until a channel number appears.

**4 0-9 and ENTER**
Use for direct channel selection. Press 0-9 to select a channel (for example, to select channel 10, press 1 and 0). The channel will change after 2 seconds, or you can press ENTER for immediate selection.

**5 CH +/–**
Press to scan through the channels (+ up or – down).

**6 VOL +/–**
Press to adjust the volume (+ up or – down).

**7 JUMP**
Press to alternate or jump back and forth between two channels. The LCD projection TV will jump between the current channel and the last channel selected.

**8 MUTING**
Press to mute the sound. “MUTING” will appear on the screen and will dim three seconds later. To restore the sound, press again or press VOL +.

**9 FREEZE**
This is useful when you need to copy down information that appears on the LCD projection TV’s screen (see “Using the Freeze Function” on page 54).

**10 DISPLAY**
Press to display the channel number, current time and channel label (if set).

To turn the display off, press DISPLAY again.

*(Continued)*




### 11 TV/VIDEO

Press repeatedly to scroll through available video inputs: TV, VIDEO 1, VIDEO 2, VIDEO 3, VIDEO 4, VIDEO 5, VIDEO 6 and VIDEO 7.

If you select Skip as a Video Label in the Setup menu, your LCD projection TV will skip the video input you selected (see "Video Label" on page 80).

### 12 MTS/SAP

Press to scroll through the Multi-channel TV Sound (MTS) options (see "MTS" on page 69).

### 13 PICTURE MODE

Press PICTURE MODE repeatedly to directly choose one of four different video modes that best suits the program you are watching.

Vivid: Select for enhanced picture contrast and sharpness.

Standard: Select to display a standard picture for normal viewing environments.

Pro: Select to display a picture with minimum enhancements.

Mild: Select to smooth the outline of digital image.

When you select each mode, you can also adjust the picture quality (such as Brightness, Color, etc.) to suit your taste. For details, see "Mode" on page 67.

# Watching Digital TV

When you have connected the DTV receiver, you can enjoy digital TV programs. This LCD projection TV is capable of receiving the 1080i, 720p, 480p and 480i digital TV formats.

### To view a digital TV program

1. Connect the DTV receiver to HD/DVD IN 5 or 6 on the LCD projection TV (for details, see page 39).
2. Press TV/VIDEO to select HD/DVD IN 5 or 6.
3. Select a digital channel on the DTV receiver. For details, see the Operating Manual of the DTV receiver.
4. Adjust the volume of the LCD projection TV as necessary.

# Using Favorite Channels

The Favorite Channel feature lets you select programs from a list of favorite channels that you preset.

## Creating a List of Favorite Channels

1. Press MENU to display the Menu.
2. Press ← or → to highlight the Channel icon and press ⊕.
3. Press ⊕ to select Favorite Channels.
4. Press ↑ or ↓ to highlight a Favorite Channel number (1-8) and press ⊕.
5. Press ↑ or ↓ to highlight a channel you want to assign to the Favorite Channel number. A preview of the highlighted channel appears in the upper right of the screen.

   Press ⊕ to select that channel as a Favorite Channel.
6. To add more channels to your favorites list, repeat steps 4-5.

   To clear a Favorite Channel, press ↑ or ↓ to highlight the channel you want to clear. Press ⊕ and then press RESET.
7. Press MENU to exit the Menu.

For details on using the Channel Menu, see page 73.

## Displaying a List of Favorite Channels

1. Press FAVORITES.

   The Favorite Channel options appear.

2. Press ↑ or ↓ to highlight the channel you want to watch. The program of that channel appears in the preview window. Press ⊕ to select.

✍ When the remote control mode is set to other than TV mode, you can display the Favorite Channels. However, you cannot select the channel by using ↑ or ↓.

To assign Channel Labels (e.g., ABC, HBO, MTV, etc.) to channel numbers, as shown at right, use the Channel Label feature in the Channel Menu (see page 74).

# Using Twin View™

Twin View enables you to watch two programs at the same time. You can also change the size of both the left and right pictures.

## Activating Twin Pictures

### To display twin pictures

1. Make sure your LCD projection TV is tuned to a working channel.
2. Press ◨.



### To cancel twin pictures

❑ Press ◨ again (or press ⏻).

## Activating the Picture

Although two pictures appear on the screen at the same time, only one picture is active. Change the picture size by using the ↑ or ↓ button. For an active picture, you can:

- ❑ Change channels.
- ❑ Adjust the volume.
- ❑ Switch the input sources from VHF/UHF to cable by pressing ANT or TV/VIDEO to switch the video input.

### To activate the right picture

❑ Press →.



### To activate the left picture

❑ Press ←.

✍ Hookups that affect your ability to use Twin View:

- If you are viewing all channels through the cable box, the Twin View feature will not work. The cable box only unscrambles one signal at a time, so the right picture will be the same as the left picture.
- You can watch a scrambled cable channel and another video source. Be sure your DVD player, VCR or satellite receiver are connected to one of the VIDEO IN 1-7 and AUX inputs on the rear of the LCD projection TV. Pictures from equipment connected to HD/DVD IN 5 and 6, DVI-HDTV IN 7, and AUX will only appear in the left picture, not in the right.

✍ The active picture is highlighted in cyan.

### Factors Affecting Twin View

- If you use a cable box to view all channels, the same channel appears in both windows because the cable box unscrambles only one channel at a time.
- If you use a cable box, you can view the cable box output in one window and view a different source (such as a VCR or DVD player) in the second window by using the TV/VIDEO button.
- Sources connected to the AUX, VIDEO 5, VIDEO 6, and VIDEO 7 inputs display in the left window, but not the right.
- If you are viewing a 4:3 source and a 16:9 enhanced source (such as a DVD) side by side, the 4:3 source appears larger.
- Twin View does not display channels that are blocked by parental settings (see page 75).

## Changing the Picture Size

The zoom feature lets you change the size of the left and right pictures.

### To enlarge the left picture (reduce the right)

1. Press ← to activate the left picture (if not already activated).
2. Press ↑ to enlarge the picture and ↓ to reduce the picture.

### To enlarge the right picture (reduce the left)

1. Press → to activate the right picture (if not already activated).
2. Press ↑ to enlarge the picture and ↓ to reduce the picture.

✍ When you adjust the twin screen sizes, the LCD projection TV memorizes the change. The next time you use the Twin View function, the memorized sizes appear.

# Using the Freeze Function

The FREEZE button allows you to temporarily capture a program's picture. You can use this feature to write down information such as phone numbers, recipes, etc.

### To use the Freeze function

1. When the program information you want to capture is displayed, press FREEZE.
2. The LCD projection TV switches to Twin View mode and displays the "frozen" picture on the right, while the current program continues on the left.

3. To cancel and return to normal viewing, press FREEZE.

✍ Freeze feature is not available if you are already in Favorite Channel (see page 50), Twin View™ (see page 51), or Channel Index (see page 55) mode.

# Using Scrolling Channel Index

Scrolling Channel Index allows you to view and select from all receivable channels scrolling on the screen without leaving the current channel.

✍ Scrolling Channel Index will not function when Parental Lock is activated.



### To use the Scrolling Channel Index function

**1** Press ▢.
The current channel will be reduced in size and displayed on the left in normal motion picture format. The first channel is briefly displayed on the bottom-right side of the screen, then frozen. It scrolls up and the next channel appears on the bottom-right, and the process is repeated with the other channels.

**2** Press ↑ and ↓ so that the channel you wish to view is displayed in the cyan frame, and press ⊕.
To return to scrolling, press ↑ and ↓ again.

To change the direction of scrolling, press ↑ or ↓ once.
To increase scrolling speed, hold pressing ↑ or ↓.

**3** To enlarge the selected channel into the left frame, press ⊕ again.
The selected channel will be displayed in normal motion picture, and the sound also switches to this channel.

*(Continued)*

**4** Press ▢.
The selected channel will be enlarged for normal viewing.

### To cancel Scrolling Channel Index

Press ▢ again to resume normal viewing.

# Using Wide Screen Mode

Wide Screen Mode lets you watch 4:3 normal broadcasts in several Wide Screen Modes (16:9 aspect ratio).

❑ Press WIDE MODE repeatedly to toggle through the following Screen Mode settings.

You can also access the Screen Mode settings in the Screen menu. For details, see page 71.

Wide Zoom

Wide Zoom enlarges the 4:3 picture to fill the 16:9 screen, keeping the original image as much as possible.

Normal

Normal returns the 4:3 picture to its original size.

Full

Full Mode stretches the 4:3 picture horizontally only, to fill the 16:9 screen.

Zoom

Zoom Mode enlarges the 4:3 picture horizontally and vertically to an equal aspect ratio that fills the 16:9 screen. Useful for watching Letterbox movies.

When you change channels or inputs, the Screen Mode settings revert to Wide Zoom (or the 4:3 Default setting in the Wide menu). To retain the current Screen Mode setting as channels and inputs are changed, set 4:3 Default to Off. For details, see page 72.

# Using the Memory Stick Picture Viewer

## About Memory Stick




Memory Stick (sold separately) is a new, compact, portable, and versatile Integrated Circuit recording medium with a data capacity that exceeds that of a floppy disk. Memory Stick is specially designed for exchanging and sharing digital data among Memory Stick compatible products such as digital cameras and digital video cameras. Because it is removable, Memory Stick can also be used for external data storage.

✍ You cannot write to Memory Stick media using the LCD projection TV.

Memory Stick technology allows you to view on your TV screen digital (jpeg) images that are stored on Memory Stick media. You can choose from an index of the images stored on the Memory Stick, or you can run a slideshow of those images. You can also customize the features of the slideshow by selecting the length of time that each image is displayed, toggling the display of file information, and rotating each image.

For more information about the using Memory Stick media, see “Notes on Using Memory Stick Media” on page 86.

## Supported Image Types

This LCD projection TV's Memory Stick viewer can display only still images that have been recorded on Memory Stick media by Sony brand digital still and video cameras.

✍ The LCD projection TV's Memory Stick viewer is compatible with Memory Sticks up to and including 128MB It is not compatible with Memory Sticks that exceed 128MB.

Recorded images must also meet the following specifications:

- Compression format: JPEG
- File name format: DCF compliant

✍ JPEG stands for "Joint Photographic Experts Group," which is the organization that implemented this format. DCF stands for "Design Rules for Camera File Systems," which are specifications established by the Japan Electronic Industry Development Association (JEIDA).

### About DCF File Names

Most Sony brand digital still and video cameras automatically record still images using DCF compliant directory and file names, as shown in the following example:




✍ Do not rename directories. If the names are changed, the still images cannot be displayed on your LCD projection TV.

## *Unsupported Image Types*

This LCD projection TV's Memory Stick viewer cannot display any of the following:

- Images recorded on digital still cameras and digital video cameras that are not Sony brand
- Images recorded using products that are not DCF compliant, including the following Sony products:

| | |
|---|---|
| Digital still | DSC-D700, DSC-D770 |
| Digital video cameras | DCR-TRV900/DSR-PD100A |

- Images stored on a Memory Stick that has a capacity that exceeds 128MB
- Images stored in TIFF or any other non-JPEG compression format
- Images in directories that were modified or renamed on a computer
- Images with less than 16 horizontal and/or vertical lines per dot
- Images with more than 4096 horizontal and/or vertical lines per dot
- Movie clips

## Inserting and Removing a Memory Stick

### To insert a Memory Stick

1 Locate the Memory Stick slot (see pages 21-22) and insert the Memory Stick into the Memory Stick slot as illustrated below.
When inserted properly, it should slide in with little resistance and click into place.




✍ Be sure to insert the Memory Stick in the correct direction. If the Memory Stick is forced in the wrong way, it may become damaged.

Insert only Memory Stick media into the Memory Stick slot. Attempting to insert other objects into the slot may damage the LCD projection TV.

### To remove a Memory Stick

1 Check that the Memory Stick indicator is off. (When the light is on, this indicates that the LCD projection TV is reading data from the Memory Stick.)

**2** Push the Memory Stick gently into the slot, and then release it.
The Memory Stick media is ejected.




**3** Pull the Memory Stick completely out of the slot.

When removing the Memory Stick, do not attempt to just pull it from its slot.



To protect small children from injury from Memory Stick Media, remove all Memory Stick media from the LCD projection TV's Memory Stick slot and store it in a safe location when it is not in use.

## Displaying the Memory Stick Menu

When the remote control mode is set to other than TV mode, you can display the Memory Stick Menu. However, you cannot select the menu item by using ↑/↓/←/→ or ⊕.

**1** Insert a Memory Stick that contains the images you want to view.
For details, see page 60.

**2** Press MEMORY STICK on the remote control. The Memory Stick Menu appears.




**3** To select an option, press ↑ or ↓ to highlight the option and press .

| Option | Description |
|---|---|
| Index | Displays an index of thumbnail images that are on the Memory Stick. For details, see "Using the Memory Stick Index" on page 62. |
| Slideshow | Displays a slideshow of images that are on the Memory Stick. For details, see "Using the Memory Stick Slideshow" on page 64. |
| Setup | Allows you to change slideshow options and rotate images. For details, see "Changing the Memory Stick Setup Options" on page 64. |

**4** To exit the Memory Stick Menu, press CH +/–, TV/VIDEO, ANT, or use the 0-9 buttons and ENTER (or wait 3 seconds) to select a channel.

✍ Memory Stick functions are not available while using Twin View, Freeze or Favorite Channel functions.

## Using the Memory Stick Index

The Memory Stick Index lets you view images that are on the Memory Stick in an index of thumbnail images.

✍ There is no audio signal available while viewing images on Memory Stick.

**1** Insert a Memory Stick that contains the images you want to view. For details, see page 60.

**2** Press MEMORY STICK on the remote control. The Memory Stick Menu appears.

**3** Press ↑ or ↓ to highlight Index and press ⊕. The Memory Stick Index appears.




The Page and folder ( ) buttons are available only if the Memory Stick contains more images or folders than can be displayed on one screen.

**4** Press ↑ ↓ ← → to highlight an image and press ⊕ to select the image. Selecting an image displays that image at full size. While an image is displayed full size, you can do any of the following:

| To Do This ... | Do This ... |
|---|---|
| Display the previous image | Press ←. |
| Display the next image | Press →. If you press → while viewing the last image, the first image is displayed. If you press ← while viewing the first image, the last image is displayed. |
| Display the Memory Stick Index | Press ⊕ |

Larger images will take longer to display on screen.

**5** To return to the Memory Stick Menu, press the arrow button to Menu ⮌ and press ⊕.

If a blank square appears instead of a thumbnail image, this indicates that the image does not support a thumbnail view. Selecting the icon, however, displays the full-size image on the screen. It could also indicate that both the thumbnail and full-size images are corrupted or not supported.

## Using the Memory Stick Slideshow

The Memory Stick Slideshow lets you watch a slideshow of the images that are on the Memory Stick.

1. Insert a Memory Stick that contains the images you want to view. For details, see page 60.
2. Press MEMORY STICK on the remote control. The Memory Stick Menu appears.
3. Press ↑ or ↓ to highlight Slideshow and press ⊕. The slideshow starts.
4. To end the slideshow, press ⊕. The Memory Stick Menu is displayed.

## Changing the Memory Stick Setup Options

1. Press MEMORY STICK on the remote control. The Memory Stick Menu appears.
2. Press ↑ or ↓ to highlight Setup and press ⊕. The Memory Stick Setup Menu appears.




3. Press the arrow button to highlight an option and press ⊕

| Option | Description |
|---|---|
| Menu | Returns to the Memory Stick Menu. |
| Slideshow - Interval | Decrease or increase the length of time that each image is displayed: 5 seconds, 10 seconds, 1 minute, 5 minutes, or 15 minutes. |
| Slideshow - Repeat | Select On to set the slideshow to repeat after displaying all the images recorded on the Memory Stick. Select Off to not repeat the slideshow. |
| File Information | Select On to show file information of each image while that image is being displayed. |
| Rotate Picture | Displays the Rotate Picture screen. For details, see “Using the Rotate Picture Screen” on page 65. |

4 Press → (or press ⊕), and then ↑ or ↓ to change setting.

5 Press ⊕ to enter the setting, and then ←.

6 To exit the Memory Stick Setup Menu, press the arrow button to Menu ⮌ and press ⊕.

## Using the Rotate Picture Screen

The Rotate Picture Screen lets you rotate an image from an index of thumbnails.

✍ You cannot rotate images if the LOCK switch on the Memory Stick is on. To rotate the images, first set the LOCK switch to off.

1 In the Memory Stick Setup Menu, press ↑ or ↓ to highlight Rotate Picture and press ⊕. The Rotate Picture screen appears.




The Page and folder ( ) buttons are available only if the Memory Stick contains more images or folders than can be displayed on one screen.

2 Press ↑ ↓ ← → to highlight an image that you want to rotate.

3 Press ⊕ to rotate an image 90 degrees in a clockwise direction.

4 To return to the Memory Stick Setup Menu, press the arrow button to highlight Menu ⮌ and press ⊕.

✍ If a blank square appears instead of the thumbnail image, this indicates that the image does not support a thumbnail view and cannot be rotated.

# Using the Menus

## Overview




### Opening and choosing a menu

1. Press MENU to display the menu screen.
2. Press ← or → to highlight the desired menu icon and press ⊕ to select it.
3. Use the arrow button to scroll through the features.
4. See the specific menu page for instructions on moving through the menu.

### To end a menu session

❑ Press MENU again.

### To end one menu session and move to another

❑ Press ↑ to return to the menu icons.
Press ← or → to choose the next menu icon and press ⊕ to select it.

The menu gives you access to the following features:

| Menu Icon | Description | Page |
|---|---|---|
| Video | Allows you to make adjustments to your picture settings. It also allows you to customize the Picture Mode based on the type of program you are viewing. | 67 |
| Audio | Offers enhanced audio options such as listening to second audio programming (SAP), or customizing the Effect of the sound on your LCD projection TV. | 69 |
| Screen | Allows you to set the wide screen mode, adjust the vertical center in wide mode, and set the 4:3 Default mode. | 71 |
| Channel | Allows you to set up a Favorite Channel list, run the Auto Program function, and more. | 73 |
| Parent | Lets you control the viewing of programs based on their ratings. | 75 |
| Setup | Provides several options for setting up your channels, labeling your Video inputs, and selecting the language of the on-screen menus. | 79 |

# Using the Video Menu

## To select the Video Menu

1. Press MENU.
2. Press ← or → to highlight the Video icon and press ⊕.
3. Use the arrow button to scroll through the features.
4. Press ⊕ to select a feature. That feature's adjustment appears.




5. Use the arrow button to make the desired adjustments.
6. Press ⊕ to select/set.
7. Press MENU to exit the menu screen.

## To restore the factory default settings for Picture, Brightness, Color, Hue, Sharpness and Color Temp

❑ Press RESET on the remote control when in the Video menu.

## Selecting Video Options

The Video menu includes the following options.

| Option | Description | |
|---|---|---|
| Mode<br>*Customized picture viewing* | Vivid | Select for enhanced picture contrast and sharpness. |
| | Standard | Recommended for Normal viewing conditions. |
| | Pro | Select to display a picture with minimum enhancements. |
| | Mild | Select to smooth the outline of digital image. |
| | ✍ You can alter the Video menu settings (Picture, Brightness, Color, etc.) for each Mode. | |
| | To quickly and easily change from one Video Mode to another, use PICTURE MODE on the remote control. | |
| Picture | Adjust to increase picture contrast and deepen the color or decrease picture contrast and soften the color. | |
| Brightness | Adjust to brighten or darken the picture. | |
| Color | Adjust to increase or decrease color intensity. | |
| Hue | Adjust to increase or decrease the green tones. | |
| Sharpness | Adjust to sharpen or soften the picture. | |
| Color Temp<br>*White intensity adjustment* | Choose from three color temperatures: | |
| | Cool | Select to give the white colors a blue tint. |
| | Neutral | Select to give the white colors a neutral tint. |
| | Warm | Select to give the white colors a red tint. |

*(Continued)*

| Option | Description | |
|---|---|---|
| Advanced Video | CineMotion | Obtains a smooth picture movement that approaches the original film-like quality when reproducing movies or other video sources on 24 frame per second films. |
| | | On: The LCD projection TV automatically detects the signal type of a film and processes it appropriately. |
| | | Off: Select to turn off the CineMotion mode. |
| | | ✍ When the Video Mode is set to Mild (page 67), you cannot set CineMotion to On. |
| | DRC Palette | Allows you to customize the level of detail (Reality) and smoothness (Clarity) for up to three input sources. For example, you can create one Custom setting to optimize your cable input's picture, and create another to optimize your DVD player's picture. You can switch among the three Custom settings.<br>**1** Press the arrow button to highlight Custom 1, Custom 2, or Custom 3 and then press ⊕.<br>The DRC palette appears.<br>  <br>**2** Press the arrow button to adjust the position of the marker (●). As you move the ● higher along the Reality axis, the picture becomes more detailed. As you move the ● to the right along the Clarity axis, the picture becomes smoother.<br>**3** To save the setting, press ⊕.<br>To return the Custom options to the default factorysettings, press the RESET button. |
| | | ✍ Advanced Video is unavailable when you have selected Mild picture mode, or you are watching 1080i, 720p and 480p sources with Video 5 to 7 inputs. |

# Using the Audio Menu

## To select the Audio Menu

1. Press MENU.
2. Press ← or → to highlight the Audio icon and press ⊕.
3. Use the arrow button to scroll through the options.
4. Press ⊕ to select an option. That option's settings appear.
5. Use the arrow button to scroll through the settings.
6. Press ⊕ to select the desired setting.
7. Press MENU to exit the menu screen.




## To restore the factory default settings for Treble, Bass and Balance

❑ Press RESET on the remote control when in the Audio menu.

## Selecting Audio Options

The Audio menu includes the following options:

| Option | Description | |
|---|---|---|
| Treble | Adjust to increase or decrease higher-pitched sounds. | |
| Bass | Adjust to increase or decrease lower-pitched sounds. | |
| Balance | Adjust to emphasize left or right speaker balance. | |
| Steady Sound | Auto | Select to stabilize the volume. |
| | Off | Select to turn off Steady Sound. |
| Effect | TruSurround | Select for surround sound (for stereo programs only). |
| | Simulated | Adds a surround-like effect to mono programs. |
| | Off | Normal stereo or mono reception. |
| MTS *Enjoy stereo, bilingual and mono programs* | Stereo | Select for stereo reception when viewing a program broadcast in stereo. |
| | Auto SAP | Select to automatically switch the LCD projection TV to second audio programs when a signal is received. (If no SAP signal is present, the LCD projection TV remains in Stereo mode.) |
| | Mono | Select for mono reception. (Use to reduce noise during weak stereo broadcasts.) |

*(Continued)*

| Option | Description | |
|---|---|---|
| Speaker | On | Select to turn on the LCD projection TV speakers. |
| | Off | Select to turn off the LCD projection TV speakers and listen to the LCD projection TV's sound only through your external audio system speakers. |
| Audio Out<br>*Easy control of volume adjustments* | Variable | The LCD projection TV's speakers are turned off, but the volume output from your audio system can still be controlled by the LCD projection TV's remote control. |
| | Fixed | The LCD projection TV's speakers are turned off and the volume, bass and treble output of the LCD projection TV is fixed. Use your audio receiver's volume control to adjust the volume through your audio system. |

# Using the Screen Menu

### To select the Screen menu

1. Press MENU.
2. Press ← or → to highlight the Screen icon and press ⊕.
3. Use the arrow button to scroll through the features.
4. Press ⊕ to select a feature. That feature's options appear.
5. Use the arrow button to scroll through the options.
6. Press ⊕ to select the desired option.
7. Press MENU to exit the menu screen.




## Selecting Screen Options

The Screen menu includes the following options:

To change from one Wide Mode to another, use WIDE MODE on the remote control.

| Option | Description | |
|---|---|---|
| Wide Mode<br>*Select a Screen Mode to use for 4:3 sources.* | Wide Zoom | Select to enlarge the 4:3 picture, to fill the 16:9 screen, keeping the original image as much as possible. |
| | Normal | Select to return the 4:3 picture to normal mode. |
| | Full | Select to enlarge the 4:3 picture horizontally only, to fill the wide screen. |
| | Zoom | Select to enlarge the 4:3 picture horizontally and vertically to an equal aspect ratio that fills the wide screen. |
| | Wide Mode is unavailable while in Twin View (page 51), Freeze (page 54), or Channel Index (page 55) mode.<br>Wide mode is unavailable when you are watching 720p and 1080i sources, and when viewing photos from your memory stick media. | |

| Option | Description | |
|---|---|---|
| 4:3 Default<br>*Select the default Screen Mode to use for 4:3 sources.* | Wide Zoom | Select to enlarge the 4:3 picture, to fill the 16:9 screen, keeping the original image as much as possible. |
| | Normal | Select to return the 4:3 picture to normal mode. |
| | Full | Select to enlarge the 4:3 picture horizontally only, to fill the wide screen. |
| | Zoom | Select to enlarge the 4:3 picture horizontally and vertically to an equal aspect ratio that fills the wide screen. |
| | Off | Select to continue using the current Screen Mode setting when the channel or input is changed. |
| | The 4:3 Default functions only when the LCD projection TV receives 480i and 480p signals.<br>If 4:3 Default is set to anything but Off, the Wide Mode setting changes only for the current channel. When you change channels (or inputs), Wide Mode is automatically replaced with the 4:3 Default setting. To retain the current Wide Mode setting as channels and inputs are changed, set 4:3 Default to Off. | |
| Vertical Center | Allows you to move the position of the picture up and down in the window. (Available only in Wide Zoom and Zoom modes.) Press ↑ or ↓ to choose a position and press ⊕. | |

# Using the Channel Menu

## To select the Channel Menu

1. Press MENU.
2. Press ← or → to highlight the Channel icon and press ⊕.
3. Use the arrow button to scroll through the features.
4. Press ⊕ to select a feature. That feature's options appear.
5. Use the arrow button to scroll through the options.
6. Press ⊕ to select the desired option.
7. Press MENU to exit the menu screen.




## Selecting Channel Options

The Channel menu includes the following options:

| Option | Description | |
|---|---|---|
| Favorite Channels | Let you set up a list of your favorite channels. For details, see "Using Favorite Channels" on page 50.. | |
| Cable | On | Select if you are receiving cable channels with a CATV cable. |
| | Off | Select if you are using an antenna. |
| | ✍ You should run Auto Program after changing the Cable setting. | |
| Channel Fix *Useful when you have a cable box or satellite receiver connected* | 2-6 | "Fix" your LCD projection TV's channel setting to 3 or 4 and use the cable box, VCR or satellite receiver to change channels. Select one of these settings if you have connected the device to the VHF/UHF jack. |
| | AUX 2-6 | Same as 2-6, except you select one of these settings if you have connected the device to the AUX jack (see page 23). |
| | Video 1 | Use when connecting a cable box. TV output should be connected through the cable box. |
| Auto Program | Automatically programs the LCD projection TV for all receivable channels. | |

| Option | Description |
|---|---|
| Channel Skip/Add | Removes and adds viewable channels.<br>**1** Use the arrow button to scroll through the channels until you find the channel you want to skip/add.<br>**2** Press ⊕ to select it.<br>**3** Press ▲ or ▼ to toggle between "Add" and "Skip."<br>**4** Press ⊕ to select.<br>Channels that you set to be skipped can be accessed only with the 0-9 buttons. |
| Channel Label | Allows you to assign labels (such as station call letters) to channel numbers. You can label up to 20 channels.<br>**1** Press the arrow button to highlight Channel and press ⊕.<br>**2** Press ▲ or ▼ to scroll through the channel numbers (1-125). Then press ⊕ to select the channel number that you want to assign a label.<br>**3** Press the arrow button to highlight Label and press ⊕.<br>**4** Press ▲ or ▼ to scroll through the label characters (A-Z, 0-9, etc.). Then press ⊕ to select the highlighted character.<br>**5** Repeat to add up to 5 characters to the label.<br>**6** To assign labels to more channels, repeat steps 1-4.<br>**7** Press ◀ to return to the Channel Menu, or press MENU to exit the Menus.<br>Channel Label is not available (grayed out) when watching the AUX and VIDEO inputs. |

# Using the Parent Menu

The Parent Menu allows you to set up the TV to block programs according to their content and rating levels.

### To select the Parent Menu




1. Press MENU.
2. Press ← or → to highlight the Parent icon and press ⊕.
3. Use the 0-9 buttons on the remote control to enter a four-digit password.
4. If this is the first time you are creating this password, confirm the password by entering it again. (The Parent Menu options appear.)
5. Press ↑ ↓ ← → to change settings. Press ⊕ to select the changed setting.
6. Press MENU to exit the Menu.

✍ You need your password for any future access into the Parent Menu. If you lose your password, see "Lost password" on page 88.

## Selecting Parent Options

The Parent Menu includes the following options:

| Option | | Description |
|---|---|---|
| Parental Lock<br>*Turn ratings on/off and select a rating system* | Off | Parental lock is off. No programs are blocked from viewing. |
| | Child | Maximum ratings permitted are:<br>US: TV-Y, TV-G, G<br>Canada: C, G, TV-Y |
| | Youth | Maximum ratings permitted are:<br>US: TV-PG, PG<br>Canada: C8+, PG, 8 ans+, TV-PG |
| | Y. Adult | Maximum ratings permitted are:<br>US: TV-14, PG-13<br>Canada: 14+, 13 ans+, TV-14 |
| | Custom | Select to set ratings manually.<br>US: See page 77 for details.<br>Canada: See page 78 for details. |

*(Continued)*

| Option | Description | |
|---|---|---|
| | If you are not familiar with the Parental Guideline rating system, you should select Child, Youth, or Young Adult to help simplify the rating selection. To set more restrictive ratings, select Custom. | |
| | For descriptions of Child, Youth, and Young Adult ratings, see page 77. | |
| Change Password | For changing your password. | |
| Select Country | U.S.A. | Select to use USA ratings (see page 77). |
| | Canada | Select to use Canadian ratings (see page 78). |

### To deactivate the Parental Control feature

❑ Set Parental Lock to OFF when in the Parent menu.

### To change the password

1. Select Change Password option when in the Parent menu using the arrow button, and press ⊕.
2. Enter a new four-digit password using the 0-9 buttons.
3. Confirm the new password by entering it again.
4. Press MENU to exit the menu screen.

## Viewing Blocked Programs

You can view a blocked program by entering the password.

1. Press ENTER when tuned to a blocked program.
2. Enter your password using the 0-9 buttons.
   Parental Control will be canceled temporarily until you turn your LCD projection TV off.

## Selecting Custom Rating Options

### US custom rating options

If you selected U.S.A. as the country of residence on page 76, the Custom Rating Menu includes the following options. (If you selected Canada, see page 78.)

To ensure maximum blocking capability, the age-based ratings should be blocked.

| Option | Description | |
|---|---|---|
| Movie Rating | G | All children and General Audience. |
| | PG | Parental Guidance suggested. |
| | PG-13 | Parental Guidance for children under 13. |
| | R | Restricted viewing, parental guidance is suggested for children under 17. |
| | NC-17 and X | No one 17 and under allowed. |
| TV Rating<br>*Block programs by their rating, content or both* | Age-Based Options | |
| | TV-Y | All children. |
| | TV-Y7 | Directed to older children. |
| | TV-G | General Audience. |
| | TV-PG | Parental Guidance suggested. |
| | TV-14 | Parents Strongly cautioned. |
| | TV-MA | Mature Audience only. |
| | Content-Based Options | |
| | FV | Fantasy Violence. |
| | D | Suggestive Dialogue. |
| | L | Strong Language. |
| | S | Sexual situations. |
| | V | Violence. |
| Unrated<br>*Block programs or movies that are broadcast without a rating* | Block | Blocks all programs and movies that are broadcast without a rating. |
| | Allow | Allows programs and movies that are broadcast without a rating. |
| | If you select "Block," please be aware that the following programs may be blocked: emergency broadcasts, political programs, sports, news, public service announcements, religious programs and weather. | |

The content ratings will increase depending on the level of the age-based rating. For example, a program with a TV-PG V (Violence) rating may contain moderate violence, while a TV-14 V (Violence) rating may contain more intense violence.

### Canadian custom rating options

If you selected Canada as the country of residence on page 76, the Custom Rating Menu includes the following options. (If you selected U.S.A., see page 77.)

| Option | Description | |
|---|---|---|
| English Rating | C | All children. |
| | C8+ | Children 8 years and older. |
| | G | General programming. |
| | PG | Parental Guidance. |
| | 14+ | Viewers 14 and older. |
| | 18+ | Adult programming. |
| French Rating | G | General programming. |
| | 8 ans+ | Not recommended for young children. |
| | 13 ans+ | Not recommended for ages under 13. |
| | 16 ans+ | Not recommended for ages under 16. |
| | 18 ans+ | Programming restricted to adults. |
| USA Rating | See “TV Rating” on page 77 for details. | |

# Using the Setup Menu

## To select the Setup Menu

1. Press MENU.
2. Press ← or → to highlight the Setup icon and press ⊕.
3. Use the arrow button to scroll through the features.
4. Press ⊕ to select a feature. That feature's options appear.
5. Use the arrow button to scroll through the options.
6. Press ⊕ to select the desired option.
7. Press MENU to exit the menu screen.




## Selecting Setup Options

The Setup menu includes the following options:

| Option | Description | |
|---|---|---|
| Caption Vision | Allows you to select from three closed caption modes (for programs that are broadcast with closed captioning). | |
| | CC1, CC2, CC3, CC4 | Displays a printed version of the dialog or sound effects of a program. (Should be set to CC1 for most programs.) |
| | Text1, Text2, Text3, Text4 | Displays network/station information presented using either half or the whole screen (if available). For closed captioning, set to CC1. |
| | Info | Displays the program name and the time remaining in the program (if the broadcaster offers this service). Displays when the channel is changed or the DISPLAY button is pressed. |
| | Off | Turns off Caption Vision. |

(Continued)

| Option | Description | |
|---|---|---|
| Video Label | Allows you to label the audio/video components you connected to the LCD projection TV so you can identify them when using TV/VIDEO. When in the Setup menu's Video Label feature, press ↑ or ↓ to highlight an input to label, then press ⊕ to select it. Use the arrow button to scroll through the labels. Press ⊕ to select the component you connected to each of the input jacks on the back of your LCD projection TV. Select "Skip" if you do not have a component connected to a particular set of input jacks. | |
| | Video 1/2/3/4 | VHS, DVD, Receiver, Satellite, Cable Box, 8mm, DTV, Game, LD, Web, Beta, Skip |
| | Video 5/6/7 | DVD, Satellite, Cable Box, DTV, HD, Skip |
| | If you select "Skip," your LCD projection TV skips this connection when you press TV/VIDEO. | |
| | ✍ When you select "Receiver" on Video Label, your LCD projection TV's input is fixed (for Video 1 only). | |
| Language | Select to display all on-screen menus in your language of choice: English, Español, Français. | |

| Option | Description |
|---|---|
| Clock/Timers | Select to set the clock and to program your TV to turn on and off at two scheduled viewing times. |

Timer 1
Timer 2 — You can use the Timers to programthe TV to turn on and off and tune to a specific channel at two scheduled viewing times.

Timer 1 and Timer 2 are not available to be set until you set the Current Time.

1. Press ↑ or ↓ to highlight Timer 1 or Timer 2. To set the timer, press →.
2. Press ↑ or ↓ to highlight one of the following options, then press ⊕.

| | |
|---|---|
| Program | Select to set the Timer by day, time, duration, and channel. |
| Off | Select to turn off the Timer. (Your previous settings are saved.) |

3. If you selected Program in step 2, press ↑ and ↓ to set the day(s), hour, minute, duration, and channel number. Press ⊕ or press → to confirm each setting and move to the next setting.
   Press ← to go back to the previous setting.
4. Press MENU to exit the Menu. An LED on the front panel will light, indicating the timer has been set.

✍ To go directly to programming Timer 1 or 2, press ⊕ instead of pressing →.

Current Time

1. Press ⊕ to select Current Time.
2. Press ↑ and ↓ to set the current time (day, hour, and minute). Press ⊕ (or press →) to comfirm each setting and move to the next setting. Press ← to go back the previous setting.
3. Press MENU to exit the Menu.

| | |
|---|---|
| Image Revision | Adjusts the Image on your LCD projection TV.<br>Auto: (Factory setting) Automatically adjust double images or ghosts.<br>0-3 (manual): Select the value with which double images or ghosts are improved. |
| Demo | Runs a demonstration of on-screen Menus. |

# Other Information

## Programming the Remote Control

If you have video equipment that you want to control with the LCD projection TV's remote control, use the following procedures to program the remote control.

✍ The equipment must have infrared (IR) remote capability in order to be used with the remote control.

From the “Manufacturer’s Codes” listed on page 83, select the three-digit code number for the manufacturer’s code for your component. If more than one code number is listed, start with the number listed first. Use the code number to complete the following procedure.




**1** Press FUNCTION repeatedly to select your desired input.

**2** Press SAT/CABLE for five seconds.
The indicator of the selected input flashes.

**3** Input the three-digit manufacturer's code number.

✍ When no code number is input for 30 seconds or invalid or incorrect numbers are input, the remote control is reset to the normal TV remote control mode.

### Tips

- If more than one code number is listed, try entering them one by one until you come to the correct code for your component.
- If you enter a new code number, the code number you previously entered at that setting is erased.
- In some rare cases, you may not be able to operate your component with the Sony remote control. In this case, use the component’s own remote control unit.

## Manufacturer's Codes

### VCRs

| Manufacturer | Code |
|---|---|
| Sony | 301 |
| Admiral (M. Ward) | 327 |
| Aiwa | 338, 344 |
| Audio Dynamic | 314, 337 |
| Broksonic | 319, 317 |
| Canon | 309, 308 |
| Citizen | 332 |
| Craig | 302, 332 |
| Criterion | 315 |
| Curtis Mathes | 304, 338, 309 |
| Daewoo | 341, 312, 309 |
| DBX | 314, 336, 337 |
| Dimensia | 304 |
| Emerson | 319, 320, 316, 317, 318, 341 |
| Fisher | 330, 335 |
| Funai | 338 |
| General Electric | 329, 304, 309 |
| Go Video | 322, 339, 340 |
| Goldstar | 332 |
| Hitachi | 306, 304, 305, 338 |
| Instant Replay | 309, 308 |
| JC Penney | 309, 305, 304, 330, 314, 336, 337 |
| JVC | 314, 336, 337, 345, 346, 347 |
| Kenwood | 314, 336, 332, 337 |
| LXI (Sears) | 332, 305, 330, 335, 338 |
| Magnavox | 308, 309, 310 |
| Marantz | 314, 336, 337 |
| Marta | 332 |
| Memorex | 309, 335 |
| Minolta | 305, 304 |
| Mitsubishi/ MGA | 323, 324, 325, 326 |
| Multitech | 325, 338, 321 |
| NEC | 314, 336, 337 |
| Olympic | 309, 308 |
| Optimus | 327 |
| Panasonic | 308, 309, 306, 307 |
| Pentax | 305, 304 |
| Philco | 308, 309 |
| Philips | 308, 309, 310 |
| Pioneer | 308 |
| Quasar | 308, 309, 306 |
| RCA/ PROSCAN | 304, 305, 308, 309, 311, 312, 313, 310, 329 |
| Realistic | 309, 330, 328, 335, 324, 338 |
| Sansui | 314 |
| Samsung | 322, 313, 321 |
| Sanyo | 330, 335 |
| Scott | 312, 313, 321, 335, 323, 324, 325, 326 |
| Sharp | 327, 328 |
| Shintom | 315 |
| Signature 2000 (M. Ward) | 338, 327 |
| SV2000 | 338 |
| Sylvania | 308, 309, 338, 310 |
| Symphonic | 338 |
| Tashiro | 332 |
| Tatung | 314, 336, 337 |
| Teac | 314, 336, 338, 337 |
| Technics | 309, 308 |
| Toshiba | 312, 311 |
| Wards | 327, 328, 335, 331, 332 |
| Yamaha | 314, 330, 336, 337 |
| Zenith | 331 |

### DVD Players

| Manufacturer | Code |
|---|---|
| Sony | 751 |
| Panasonic | 753 |
| Pioneer | 752 |
| RCA | 755 |
| Toshiba | 754 |

### Cable Boxes

| Manufacturer | Code |
|---|---|
| Hamlin/Regal | 222, 223, 224, 225, 226 |
| Jerrold/G. I. | 201, 202, 203, 204, 205, 206, 207, 208, 218 |
| Oak | 227, 228, 229 |
| Panasonic | 219, 220, 221 |
| Pioneer | 214, 215 |
| Scientific Atlanta | 209, 210, 211 |
| Tocom | 216, 217 |
| Zenith | 212, 213 |

### Satellite Receivers

| Manufacturer | Code |
|---|---|
| Sony | 801 |
| General Electric | 802 |
| Hitachi | 805 |
| Hughes | 804 |
| Panasonic | 803 |
| RCA/ PROSCAN | 802, 808 |
| Toshiba | 806, 807 |

# Operating Other Components with Your LCD Projection TV Remote Control

## Operating a VCR

Press FUNCTION until the DVD/VCR indicator lights up.

| To Do This ... | Press |
|---|---|
| Turn on/off | SAT/CABLE (POWER) |
| Change channels | CH +/– |
| Record | ► and REC simultaneously |
| Play | ► |
| Stop | ■ |
| Fast forward | ►► |
| Rewind the tape | ◄◄ |
| Pause | ❚❚ (press again to resume normal playback) |
| Search the picture forward or backward | ►► or ◄◄ during playback (release to resume normal playback) |

## Operating a DVD Player

Press FUNCTION until the DVD/VCR indicator lights up.

| To Do This ... | Press |
|---|---|
| Turn on/off | SAT/CABLE (POWER) |
| Play | ► |
| Stop | ■ |
| Pause | ❚❚ (press again to resume normal playback) |
| Step through different tracks of an audio disc | ►► to step forward or ◄◄ to step backward |
| Step through different chapters of a video disc | CH+ to step forward or CH– to step backward |

## Operating a Cable Box

Press FUNCTION until the SAT/CABLE indicator lights up.

| To Do This ... | Press |
|---|---|
| Turn on/off | SAT/CABLE (POWER) |
| Select Cable Box | SAT/CABLE (FUNCTION) |
| Select a channel | 0-9 buttons, ENTER |
| Change channels | CH +/– |
| Back to previous channel | JUMP |

## Operating a Satellite Receiver

Press FUNCTION until the SAT/CABLE indicator lights up.

| To Do This ... | Press |
|---|---|
| Turn on/off | SAT/CABLE (POWER) |
| Select Satellite Receiver | SAT/CABLE (FUNCTION) |
| Select a channel | 0-9 buttons, ENTER |
| Change channels | CH +/– |
| Back to previous channel | JUMP |
| Display channel number | DISPLAY |
| Display DBS menu | MENU |
| Select item |  |

# Notes on Using Memory Stick Media

## Memory Stick Precautions

When using Memory Stick media, follow these precautions:

- To avoid permanent damage to still image data, do not turn off the TV or remove Memory Stick media from the insertion slot while data is being read (as indicated by the Memory Stick indicator light being on).
- Avoid touching the terminal of Memory Stick media or bringing it into contact with a metal object.
- Do not drop, bend, or submit Memory Stick media to external shock.
- Do not disassemble or modify Memory Stick media.
- Avoid getting liquid on Memory Stick media.
- Apply labels only within the designated label area.




- To avoid permanent damage to still image data, do not use or store Memory Stick media in a location subject to:
  - High temperature (such as near a heater or inside a hot car)
  - High humidity
  - Direct sunlight
  - Corrosive substances
  - Magnetic fields
  - Excessive dust
  - Static electricity or electric noise
- Store and carry Memory Stick media in its original case to ensure protection of stored data.
- Save a backup of stored data.

# Troubleshooting

**If, after reading these operating instructions, you have additional questions related to the use of your Sony television, please call our Customer Information Services Center at 1-800-222-SONY (7669) (U.S. residents only) or (416) 499-SONY (7669) (Canadian residents only).**

| Problem | Possible Remedies |
|---|---|
| No picture (screen not lit), no sound | ❏ Make sure the LCD projection TV's power cord is connected securely to the wall outlet.<br>❏ Push the power button on the front of the LCD projection TV.<br>❏ Check to see if the TV/VIDEO setting is correct: when watching TV, set to TV, and when watching connected equipment, set to VIDEO 1, 2, 3, 4, 5, 6 or 7.<br>❏ Try another channel. It could be station trouble.<br>❏ The Parental Control feature is activated (see "Using the Parent Menu" on page 75).<br>❏ If your LCD projection TV's power is on, and LAMP (red) indication is flashing, the lamp for the light source burns out. Replace it with new Sony XL-2000U replacement lamp (see page 13).<br>❏ If your LCD projection TV does not turn on, and a red light keeps flashing, your LCD projection TV may need service. Call your local Sony Service Center. |
| Remote control does not operate | ❏ Batteries could be weak. Replace the batteries.<br>❏ Press FUNCTION until the TV indicator lights up when operating your LCD projection TV.<br>❏ Make sure the LCD projection TV's power cord is connected securely to the wall outlet.<br>❏ Locate the LCD projection TV at least 3-4 feet away from fluorescent lights.<br>❏ Check the orientation of the batteries. |
| Dark, poor or no picture (screen lit), good sound | ❏ Adjust the Picture setting in the Video menu (see page 67).<br>❏ Adjust the Brightness setting in the Video menu (see page 67).<br>❏ Check antenna/cable connections.<br>It is strongly recommended to connect the antenna using a 75-ohm coaxial cable to get optimum picture quality. A 300-ohm twin lead cable can be easily affected by radio noise and the like, resulting in signal deterioration. If you use a 300-ohm twin lead cable, keep it away as far as possible from the LCD projection TV.<br>Do not use an indoor antenna because it is especially susceptible to radio noise (see page 25). |
| Good picture, no sound | ❏ Press MUTING so that "MUTING" disappears from the screen (see page 45).<br>❏ Make sure Speaker is set to ON in the Audio menu (see page 70).<br>❏ Check the MTS setting in the Audio menu (see "MTS" on page 69). |
| Cannot receive digital channels (when a DTV receiver is connected) | ❏ Check the connections between the DTV receiver and the LCD projection TV (see page 39).<br>❏ Check your local listings to find out if you can receive digital broadcasts in your area. |
| Cannot receive upper channels (UHF) when using an antenna | ❏ Change Cable to OFF (see page 73).<br>❏ Use Auto Program in the Channel menu to add receivable channels that are not presently in TV memory (see page 73). |

| Problem | Possible Remedies |
|---|---|
| No color | ❑ Adjust the Color settings in the Video menu (see page 67). |
| Only snow and noise appear on the screen | ❑ Check the Cable setting in the Channel menu (see "Cable" on page 73).<br>❑ Check the antenna/cable connections.<br>❑ Make sure the channel is broadcasting programs.<br>❑ Press ANT to change the input mode (see page 47). |
| Dotted lines or stripes | ❑ Adjust the antenna.<br>❑ Move the LCD projection TV away from noise sources such as cars, neon signs, or hair-dryers. |
| LCD projection TV is fixed to one channel | ❑ Use Auto Program in the Channel menu to add receivable channels that are not presently in TV memory (see page 73).<br>❑ Check your Channel Fix settings (see page 73). |
| Double images, ghosts, or merged colors | ❑ Use a highly directional outdoor antenna or a cable (when the problem is caused by reflections from nearby mountains or tall buildings).<br>❑ Set the Image Revision to an appropriate value. The default setting is Auto. If ghosts, doubled images, or merged colors appear with Auto, select the best value from 0 to 3 (see page 81). |
| Cannot operate menu | ❑ If the item you want to choose appears in gray, you cannot select it.<br>❑ Turn the LCD projection TV's power off and on again. |
| Cannot receive any channels when using cable TV | ❑ Use Auto Program in the Channel menu to add receivable channels that are not presently in TV memory (see page 73).<br>❑ Check your cable settings.<br>❑ Make sure Cable is set to ON in the Channel menu (see page 73). |
| Cannot gain enough volume when using a cable box | ❑ Increase the volume of the cable box using the cable box's remote control. Then press FUNCTION until the TV indicator lights up and adjust the LCD projection TV's volume. |
| Channel Index does not display all available channels | ❑ Make sure Cable is set to ON in the Channel menu (see "Cable" on page 73).<br>❑ Use Auto Program in the Channel menu to add receivable TV channels that are not presently in TV memory (see page 73). |
| Cannot receive channels<br>Unable to select a channel | ❑ Use Auto Program in the Channel menu to add receivable TV channels that are not presently in TV memory (see page 73). |
| Lost password | ❑ In the password screen (see page 75), enter the following master password: 4357. The master password clears your previous password; it cannot be used to temporarily unblock channels. |
| Cannot change channels with the remote control | ❑ Be sure you have not inadvertently switched your LCD projection TV from channel 3 or 4 setting if you are using another device to change channels.<br>❑ If you are using another device to control channels, be sure the "function" button for that device has been pressed, or the slide switch is set correctly. For example, if you are using your cable to control channels, be sure to press SAT/CABLE. |
| Cannot cycle through the other video equipment connected to the LCD projection TV | ❑ Be sure the Video Label feature has not been set to Skip (see page 80). |

| Problem | Possible Remedies |
|---|---|
| There is a black box on the screen | ❑ You have selected a text option in the Setup menu and no text is available. (see page 79 to reset Setup selections) To turn this feature off, select OFF in the Caption Vision option. If you were trying to get closed captioning, select CC1 instead of Text 1-4. |
| There is no twin picture or it is just static | ❑ Be sure your twin picture is set to a video source/channel that has a program airing.<br>❑ You may be tuned to a video input with nothing connected to it. Try cycling through your video inputs using TV/VIDEO.<br>❑ Twin View is not set to receive a signal from the AUX input. If you have connected a VCR, DVD player or satellite receiver to the AUX input on the LCD projection TV, it will not show in the second picture. |
| You get the same program in the window picture as in the main picture | ❑ Both may be set to the same channel. Try changing channels in either the main picture or the window picture.<br>❑ You may be running all your channels through a cable box. The cable box will only unscramble one signal at a time, so you cannot use the Twin View feature. If possible, run a direct cable to your LCD projection TV's VHF/UHF input (this will only work if your cable system provides an unscrambled signal.) |
| You cannot get anything but TV channels in your second picture | ❑ Be sure the video label has not been set to skip your video inputs. See the Setup menu on page 80. |
| Some video sources do not appear when you press TV/VIDEO | ❑ Ensure that Video Label is not set to "Skip" (see "Video Label" on page 80). |
| Image does not display | ❑ Make sure the image is supported by the LCD projection TV (see page 58).<br>❑ Make sure the Memory Stick is inserted properly (see page 60).<br>❑ Memory Stick functions are not available while using Twin View, Freeze or Favorite Channel functions. |
| Blank square appears instead of a thumbnail image | ❑ This indicates that the image does not support a thumbnail view. Selecting the icon, however, displays the full-size image on the screen. It could also indicate that both the thumbnail and full-size images are corrupted or not supported |
| Cannot rotate image, no thumbnail appears | ❑ Be sure the LOCK switch on the Memory Stick is set to off.<br>❑ If a blank square appears instead of the thumbnail image, this indicates that the image does not support a thumbnail view and cannot be rotated. |
| Cannot hear audio while using Memory Stick | ❑ There is no audio available while using Memory Stick. |
| Image file name does not appear; instead, dashes (---) appear | ❑ Dashes appear instead of the file name if the image was recorded using equipment that is not DCF-compliant. Dashes also appear if a DCF-compliant file was renamed. |

# Flashing Indicators on the Front of the Monitor




The STAND BY (red) and/or LAMP (red) indicators indicate the conditions of the LCD projection TV and warnings by lighting or flashing, as follows.

**The STAND BY indicator flashes.**

- The lamp for the light source is ready to turn on.

**The STAND BY indicator flashes three times.**

- The lamp cover is not attached securely. When you correct, the STAND BY indicator goes out and the LCD projection TV enters the standby mode (see page 13).

**The LAMP indicator flashes.**

- The lamp for the light source burns out. Replace it with new one (see page 13).

If the LCD projection TV is not recovered after correcting the problems, contact with qualified Sony personnel.

# Specifications

| | | |
|---|---|---|
| Projection System | 3 LCD Panels, 1 lens projection system | |
| LCD Panel | 1.35 inch TFT LCD panel Approx. 3.15 million dots (1,049,088 pixels) | |
| Projection Lens | High Performance, large diameter hybrid lens F2.4 | |
| Antenna | 75 ohm external terminal for VHF/UHF | |
| Lamp | UHP lamp, 100W<br>XL-2000U | |
| Television System | NTSC, American TV Standard | |
| Screen Size (measured diagonally) | KF-50XBR800: 50 inches, KF-60XBR800: 60 inches | |
| Channel Coverage | | |
| VHF | 2-13 | |
| UHF | 14-69 | |
| CATV | 1-125 | |
| Power Requirements | 120V, 60 Hz | |
| Number of Inputs/Outputs | | |
| DVI-HDTV | 1 terminal, 3.3 V T.M.D.S., 50 ohms<br>The DVI-HDTV input terminal is compliant with the EIA-861 standard and is not intended for use with personal computers. | |
| Video (IN) | 4 | 1 Vp-p, 75 ohms unbalanced, sync negative |
| S Video (IN) | 3 | Y: 1 Vp-p, 75 ohms unbalanced, sync negative<br>C: 0.286 Vp-p (Burst signal), 75 ohms |
| Audio (IN) | 6 | 500 mVrms (100% modulation)<br>Impedance: 47 kiloohms |
| AUDIO (VAR/FIX) | 1 | 500 mVrms at the maximum volume setting (Variable)<br>500 mVrms (Fixed)<br>Impedance (output): 2 kiloohms |
| MONITOR OUT | 1 | Video: 1 Vp-p 75 ohms unbalanced, Sync negative<br>Audio: 500 mVrms (100% modulation)<br>Impedance (output): 1 kiloohms |
| CONTROL S (IN/OUT) | 1 | minijacks |
| Component Video Input | 2 (Y, $P_B$, $P_R$) | Y: 1.0 Vp-p, 75 ohms unbalanced, sync negative<br>$P_B$: 0.7 Vp-p, 75 ohms<br>$P_R$: 0.7 Vp-p, 75 ohms |
| RF Inputs | 2 | |
| Converter | 1 | |
| Speaker Output | 15 W × 2 | |
| Dimensions (W × H × D) | KF-50XBR800: 1,376 × 964 × 415 mm (54 1/4 × 38 × 16 3/8 inches)<br>KF-60XBR800: 1,618 × 1,103 × 542 mm (63 3/4 × 43 1/2 × 21 3/8 inches) | |
| Mass | KF-50XBR800: 50 kg (110 lb 4 oz), KF-60XBR800: 66 kg (145 lb 8 oz) | |
| Power Consumption | | |
| In Use | 220 W | |

| | |
|---|---|
| In Standby | Under 1 W |
| Supplied Accessories | |
| Remote Control | RM-Y912 |
| AAA Batteries | 2 supplied for remote control |
| Cleaning Cloth | 1 |
| Hex key wrench | 1 |
| Brackets with screws | 2 |
| Optional Accessories | |
| TV Stand | SU-GW1 |
| Lamp | XL-2000U |
| AV Cable | VMC-810/820/830 HG |
| Audio Cable | RKC-515HG |
| Control S Cable | RK-G69HG |
| Component Video Cable | VMC-10/30 HG |
| AV Receiver | STR-V555ES or equivalent |
| Memory Stick media | 8MB (MSA-8A), 16MB (MSA-16A), 32MB (MSA-32A), 64MB (MSA-64A), 128MB (MSA-128A) |

Design and specifications are subject to change without notice.

# Index


## A

Activating a Twin View screen **51**
Adding channels to the channel list **73**
Adjusting audio, Steady Sound **69**
ANT button **45**
Antenna, connecting **25**
Audio menu **66**, **69**
Audio receiver, connecting **36**
Audio/Video cable **24**
Auto Program (channel setup) **44**, **73**
Auto Setup **44**, **73**
AV receiver, connecting to MONITOR OUT **23**

## B

Balance, adjusting **69**
Bass, adjusting **69**
Batteries, inserting in remote **17**
Bilingual audio **69**
Brightness, adjusting **67**

## C

Cable
- connecting **25**–**28**
- setting ON/OFF **73**
- with VCR, connecting **29**

Cable box
- connecting with VCR **30**
- using with TV remote control **85**

Camcorder, connecting **41**
Caption Vision **79**
CATV. See Cable.
Channel list, adding channels **73**
Channel menu **66**, **73**
Channel Skip/Add **74**
Channels
- Auto Program **73**
- creating labels **74**
- setting up **44**

CineMotion **68**
Cleaning Cloth **12**
Closed caption modes **79**
Color temperature, adjusting **68**
Color, adjusting **67**
Connecting
- Audio receiver **36**
- Cable box **26**–**28**, **30**–**31**
- Cable or antenna **25**
- Camcorder **41**
- Digital TV Receiver **39**
- DVD player **37**, **38**
- Satellite receiver **33**–**35**
- VCR **30**–**32**, **34**

Connector Types **24**
Contents of box **17**
CONTROL S **43**

## D

Digital TV
- connecting **39**
- watching **49**

Digital TV program **49**
Digital TV receiver, connecting **39**
DISPLAY button **45**
Display, turning off **45**
DRC (Digital Reality Creation) Mode, described **9**
DVD player
- using with TV remote control **84**
- with A/V connectors, connecting **38**
- with component video connectors, connecting **37**

## E

Enlarging pictures, in Twin View **53**

## F

Favorite Channel
- described **10**
- setting up **73**
- using **50**

FAVORITES button **46**
Features **9**
FREEZE button **46**
Freeze, using **47**, **54**
Front Panel Controls **21**
FUNCTION button **45**

## H

Hookups **25**
Hue, adjusting **67**

## I

Image Revision **81**
Inputs, labeling **80**
Installation of the projection TV **25–43**

## J

JUMP button **45**
Jump, using **47**

## L

Label
- Channels **74**
- video inputs **80**

Lamp, replacing **13–16**

## M

Memory Stick
- Index **62**
- indicator (LED) **22**
- inserting **60**
- insertion slot **22**
- Menu **61**
- precautions **86**
- Rotate Picture **65**
- Setup Options **64**
- Slideshow **64**
- supported and unsupported Images **58**

MEMORY STICK button **46**
MENU button **46**
Menus
- Audio **66, 69**
- Channel **66, 73**
- Screen **71**
- Setup **66, 79**
- Timer **81**
- Video **66, 67**

MODE
- Mild **48**
- Movie **48**
- Standard **48**
- Vivid **48**

MTS/SAP button **46**
MTS/SAP, using **48**
Muting, using **47**

## P

Parental control, described **9**
Password, changing **76**
Picture contrast, adjusting **67**
PICTURE MODE button **45**
Picture size, adjusting in Twin View **53**
POWER buttons (GREEN) **46**
Presetting channels **44**
Problems, troubleshooting **87–90**

## R

Ratings
- setting **76**
- viewing blocked programs **76**

Rear panel controls and connections **23**
Remote control
- Function of buttons **47**
- inserting batteries **17**
- programming **82–83**

Remote control, operating other components with
- Cable box **85**
- DVD player **84**
- Satellite receiver **85**
- VCR **84**

Removing channels from the channel list **74**
RESET button **46**
Resetting
- Audio options **69**
- Video options **67**

## S

S Video cable **24**
SAT/CABLE function button **45**
SAT/CABLE power button **46**
Satellite receiver
- connecting **33**
- using with TV remote control **85**

Screen menu **71**
Setting up channels **44**
Setup menu **66, 79**
Sharpness, adjusting **67**
Specifications **91–92**
Steady Sound
- adjusting **69**

Surround sound **69**

## T

Timer
- set current **81**

Timer menu **81**
Timer setting **81**
Treble, adjusting **69**
Troubleshooting **87–90**
TV function button **45**

TV power button **46**
TV/VIDEO button **46**
Twin View™
activating a picture **51**
described **9**
using **51**

## V

VCR
using with TV remote control **84**
with cable box, connecting **30**
with cable, connecting **29**
with satellite receiver, connecting **34**
Video inputs, labeling **80**
Video menu **66, 67**
Video Modes, selecting **67**
Viewing area, recommended **20**
VOL +/– button **46**

## W

WIDE MODE button **45**

## Z

Zoom feature, with Twin View **53**

If, after reading this instruction manual, you have additional questions related to the use of your Sony projection TV, please call one of the following numbers (English only).

**Customers in the continental United States contact the Direct Response Center at:**
**1-800-222-SONY (7669)**

**Customers in Canada contact the Customer Relations Center at:**
**(416) 499-SONY (7669)**

http://www.sony.net/

Printed in U.S.A.